



ztC Edge User's Guide



For an **Always-On** World

www.stratus.com

Notice

The information contained in this document is subject to change without notice.

UNLESS EXPRESSLY SET FORTH IN A WRITTEN AGREEMENT SIGNED BY AN AUTHORIZED REPRESENTATIVE OF STRATUS TECHNOLOGIES, STRATUS MAKES NO WARRANTY OR REPRESENTATION OF ANY KIND WITH RESPECT TO THE INFORMATION CONTAINED HEREIN, INCLUDING WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PURPOSE.

Stratus Technologies assumes no responsibility or obligation of any kind for any errors contained herein or in connection with the furnishing, performance, or use of this document. Software described in Stratus documents (a) is the property of Stratus Technologies Ireland, Ltd. or the third party, (b) is furnished only under license, and (c) may be copied or used only as expressly permitted under the terms of the license.

Stratus documentation describes all supported features of the user interfaces and the application programming interfaces (API) developed by Stratus. Any undocumented features of these interfaces are intended solely for use by Stratus personnel and are subject to change without warning.

This document is protected by copyright. All rights are reserved. Stratus Technologies grants you limited permission to download and print a reasonable number of copies of this document (or any portions thereof), without charge, for your internal use only, provided you retain all copyright notices and other restrictive legends and/or notices appearing in the copied document.

Copyrights

Stratus, the Stratus logo, Stratus ztC, the Stratus Technologies logo, the Stratus 24x7 logo, and Stratus ztC Edge are trademarks of Stratus Technologies Ireland, Ltd.

UNIX is a registered trademark of The Open Group in the United States and other countries.

Intel and the Intel Inside logo are registered trademarks and Xeon is a trademark of Intel Corporation or its subsidiaries in the United States and/or other countries/regions.

Microsoft, Windows, Windows Server, and Hyper-V are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries/regions.

VMware, vSphere, and ESXi are registered trademarks or trademarks of VMware, Inc. in the United States and/or other jurisdictions.

The registered trademark Linux is used pursuant to a sublicense from the Linux Mark Institute, the exclusive licensee of Linus Torvalds, owner of the mark on a worldwide basis.

Google and the Google logo are registered trademarks of Google Inc., used with permission. The Chrome browser is a trademarks of Google Inc., used with permission.

Mozilla and Firefox are registered trademarks of the Mozilla Foundation.

Red Hat is a registered trademarks of Red Hat, Inc. in the United States and other countries.

Ubuntu and Canonical are registered trademarks of Canonical Ltd.

Debian is a registered trademark of Software in the Public Interest, Inc. and is managed by the Debian project.

All other trademarks and registered trademarks are the property of their respective holders.

Manual Name: *ztC Edge User's Guide*

Product Release Number: Stratus Redundant Linux Release 2.3.0.0

Publication Date: Monday, October 7, 2024

Stratus Technologies, Inc.

5 Mill and Main Place, Suite 500

Maynard, Massachusetts 01754-2660

© 2024 Stratus Technologies Ireland, Ltd. All rights reserved.

Table of Contents

Part 1: ztC Edge User's Guide	13
Chapter 1: Introduction to ztC Edge Systems	15
ztC Edge System Overview	15
ztC Edge System Description	16
Physical Machines and Virtual Machines	17
Administrative Operations	17
Alerts	18
Remote Support	18
Lights-Out Management	19
Third-party Management Tools	19
Modes of Operation	20
High Availability Operation	20
Fault Tolerant Operation	21
ALSR Configurations	22
ALSR and Quorum Service	22
Quorum Servers	23
Network Architecture	24
A-Link and Private Networks	24
Business and Management Networks	25
Network Segmentation Fault Detection and Remediation	25
System Usage Restrictions	26
QEMU	26
Accessing the Host Operating System	27
Chapter 2: Getting Started	29
Planning	30
Safety Precautions	30
System Requirements Overview	31
System Hardware	31
IP Addresses	34
Ports	34
Space Recommendations	34
System Specifications	35
System Specifications: ztC Edge 250i Systems	35

System Specifications: ztC Edge 200i Systems	37
System Specifications: ztC Edge 110i Systems	39
System Specifications: ztC Edge 100i Systems	40
DIN-Rail and Wall-Mount Bracket Assembly	42
DIN-Rail and Wall-Mount Bracket Assembly: ztC Edge 250i Systems	42
DIN-Rail and Wall-Mount Bracket Assembly: ztC Edge 200i Systems	45
DIN-Rail and Wall-Mount Bracket Assembly: ztC Edge 110i Systems	46
DIN-Rail and Wall-Mount Bracket Assembly: ztC Edge 100i Systems	47
Product Compliance	49
General Network Requirements and Configurations	49
Business and Management Network Requirements	50
A-Link and Private Network Requirements	52
ztC Edge Console Requirements	52
Compatible Internet Browsers	52
Power Requirements and Considerations	53
Deployment	53
Connecting Power	53
Connecting ztC Edge 200i and 250i Systems to Site DC Power (Optional)	54
Connecting a ztC Edge System to UPS Power (Optional)	55
Deploying the System	57
Connecting Ethernet Cables	59
Mapping Your Keyboard	61
Recording the Management IP Address	62
Post-Deployment Tasks	62
Obtaining System IP Information	63
Logging On to the ztC Edge Console for the First Time	63
Registering the System and Acquiring a Permanent License	66
Redeploying a ztC Edge System	70
Adding a Node to a Single-Node System	72
Connecting a Second Business Network	74
Chapter 3: Using the ztC Edge Console	77
ztC Edge Console	78
Logging On to the ztC Edge Console	79
Editing Your User Information	81
Dashboard Page	81

Resolving Outstanding Alerts on the Dashboard	82
System Page	83
Powering On the System	83
Rebooting the System	84
Shutting Down the System	85
Preferences Page	87
Specifying Owner Information	90
Managing the Product License	90
Managing Software Updates	94
Configuring IP Settings	95
Configuring Availability Settings	97
Configuring Quorum Servers	98
Configuring Date and Time	100
Configuring the Mail Server	101
Configuring Users and Groups	102
Managing Local User Accounts	103
Managing Domain User Accounts	106
Configuring Active Directory	107
Configuring Secure Connections	109
Configuring VM Devices	113
Managing IPtables	114
Configuring the Login Banner	119
Enabling ztC Advisor	120
Saving and Restoring System Preferences	121
Configuring e-Alerts	132
Configuring SNMP Settings	133
Configuring OPC Settings	138
Displaying OPC Output	141
Configuring Remote Support Settings	149
Configuring Internet Proxy Settings	151
Alerts History Page	152
Audit Logs Page	152
Support Logs Page	153
Creating a Diagnostic File	153
Uploading a Diagnostic File to Customer Support	154

Deleting a Diagnostic File	155
Physical Machines Page	156
Physical Machine Actions	157
Physical Machine States and Activities	158
Virtual Machines Page	159
Virtual Machine Actions	161
Virtual Machine States and Activities	163
Volumes Page	165
Networks Page	166
Setting the MTU	168
Virtual CDs Page	169
Upgrade Kits Page	170
Creating a USB Medium with System Software	171
Chapter 4: Upgrading Stratus Redundant Linux Software	173
Upgrading Stratus Redundant Linux Software Using an Upgrade Kit	173
Chapter 5: Managing Physical Machines	179
Maintenance Mode	179
Powering On a Physical Machine	181
Identifying a Physical Machine	182
Rebooting a Physical Machine	182
Shutting Down a Physical Machine	183
Load Balancing	185
Modes of Operation	185
Troubleshooting Physical Machines	186
Understanding ztC Edge LED States	186
SYS LED (All ztC Edge Nodes)	186
PWR LED (ztC Edge 1xxi Nodes) or Power Button (ztC Edge 2xxi Nodes)	187
HDD or SSD LED (ztC Edge 1xxi Nodes Only)	187
Recovering a Failed Physical Machine (Manual)	188
Chapter 6: Managing Virtual Machines	193
Planning Virtual Machine Resources	194
Planning Virtual Machine vCPUs	194
Planning Virtual Machine Memory	196
Planning Virtual Machine Storage	197
Planning Virtual Machine Networks	198

Creating and Migrating Virtual Machines	199
Creating a New Virtual Machine	199
Copying a Virtual Machine	204
Migrating a Physical Machine or Virtual Machine to a System	207
Importing an OVF or OVA File	217
Replacing/Restoring a Virtual Machine from an OVF File	226
Exporting a Virtual Machine	231
Mounting a USB Device or Network-mounted Folder on the ztC Edge System	235
Managing Windows Drive Labels	237
Configuring Windows-based Virtual Machines	238
Updating the VirtIO Drivers (Windows-based VMs)	239
Creating and Initializing a Disk (Windows-based VMs)	242
Installing Applications (Windows-based VMs)	243
Configuring Linux-based Virtual Machines	243
Creating and Initializing a Disk (Linux-based VMs)	244
Installing Applications (Linux-based VMs)	244
Managing the Operation of a Virtual Machine	245
Starting a Virtual Machine	245
Shutting Down a Virtual Machine	246
Powering Off a Virtual Machine	248
Opening a Virtual Machine Console Session	248
Renaming a Virtual Machine	252
Removing a Virtual Machine	252
Managing Virtual Machine Resources	253
Reprovisioning Virtual Machine Resources	254
Creating a Volume in a Virtual Machine	257
Attaching a Volume to a Virtual Machine	258
Detaching a Volume from a Virtual Machine	259
Removing a Volume from a Virtual Machine	260
Renaming a Volume on the ztC Edge System	262
Expanding a Volume on the ztC Edge System	262
Recovering Virtual Machine Resources	263
Managing Virtual CDs	264
Creating a Virtual CD	265
Inserting a Virtual CD	266

Ejecting a Virtual CD	267
Booting from a Virtual CD	267
Renaming a Virtual CD	268
Downloading a Virtual CD	268
Removing a Virtual CD	269
Advanced Topics (Virtual Machines)	269
Assigning a Specific MAC Address to a Virtual Machine	270
Selecting a Preferred PM for a Virtual Machine	271
Forcing a VM to Boot	272
Changing the Protection Level for a Virtual Machine (HA or FT)	276
Configuring the Boot Sequence for Virtual Machines	276
Resetting MTBF for a Failed Virtual Machine	277
Attaching a USB Device to a Virtual Machine	278
Chapter 7: Maintaining Physical Machines	283
Replacing Physical Machines (Automated)	283
Replacing Physical Machines (Manual)	286
Chapter 8: Monitoring the System, Windows-based VMs, and Applications	293
Monitoring the ztC Edge System	293
Monitoring Windows-based Virtual Machines	295
Monitoring Applications on Windows-based Virtual Machines	298
Part 2: Supporting Documents	303
Chapter 9: Stratus Redundant Linux Release 2.3.0.0 Release Notes	305
New Features and Enhancements	305
New in Stratus Redundant Linux Release 2.3.0.0	305
New in Stratus Redundant Linux Release 2.2.0.0	306
New in Stratus Redundant Linux Release 2.1.0.0	306
Bug Fixes	306
Bugs Fixed in Stratus Redundant Linux Release 2.3.0.0	306
Bugs Fixed in Stratus Redundant Linux Release 2.2.0.0	307
Bugs Fixed in Stratus Redundant Linux Release 2.1.0.0	307
CVE Fixes	307
Important Considerations	307
Upgrading to Release 2.3.0.0	307
Determining the Version of System Software	307
During Upgrade, Refresh Browser and Accept New Certificate	308

SNMP Disabled by Default on ztC Edge Systems	308
ztC Edge Deployment Enhancements	308
Power Connections on ztC Edge200i and 250i Nodes	308
Audio Ports Are Not Supported	309
Using Intel Active Management Technology (AMT) for Lights-Out Support	310
Deploying ztC Edge Nodes at Separate Physical Sites	310
Enabling ztC Advisor	310
Tested Guest Operating Systems	310
Maximum vCPU Limits for a Virtual Machine	310
Known Issues	311
Increasing MTU on the P1 interface Can Cause Disruption or Halt of Network Traffic	311
After Upgrading to a Dual-Node System, VMs Display Warning Icon	311
Removable Media and Migrating a PM or VM Using the P2V Client	311
"The VM name has failed to start" Alert While Running the P2V Client Is Normal	311
Maximum Path Length When Importing a VM	312
Cannot Import RHEL 8.x VMs	312
Maximum Resolution of a UEFI VM Console Session	312
Restart VMs for vmgenid Support	312
Creating VCD Fails With Microsoft Edge Console Browser	312
In a Single-Node System, VM Creation Wizard Display of Added vCPUs Is Incorrect	312
Mapping of Japanese Keyboards 106 and 109 For Console in IE10, IE11, or Firefox May Be Incorrect	313
Cannot Enable SNMP Requests Without Traps	313
Migrating a VM With Monitoring Set Causes "No response"	313
VMs Reported as Broken Instead of Degraded When A-Link Is Offline	313
Ejected VCD Still Displayed in a Linux-based VM Console	313
Some Browsers Unable to Connect a VNC When Using https	313
Reboot Required When Changing Node IP Address or Netmask Network Settings	314
Accessing Stratus Knowledge Base Articles	314
Getting Help	315
Chapter 10: System Reference Information	317
Tested Guest Operating Systems	317
Important Physical Machine and Virtual Machine Considerations	319
Virtual Machine Recommendations and Limits	319
Systems and HA or FT Operation	319

Recommended Number of CPU Cores	319
Important Considerations	321
Creating an ALSR Configuration	321
Creating the Configuration	326
A Typical ztC Edge System	326
An ALSR Configuration With a Quorum Server	326
ALSR VLAN Requirements	327
From Initial Deployment to Completing the ALSR Configuration	328
Meeting Network Requirements	329
Locating and Creating the Quorum Server	330
Locating the Quorum Computer	331
Adding an Alternate Quorum Computer	332
Quorum Computer Requirements	332
Downloading and Installing the Quorum Service Software	333
Completing the Configuration	333
Configuring the Quorum Service Port	334
Verifying the Quorum Service Port	334
Configuring the Quorum Server Within the ztC Edge Console	334
Verify the Configuration and (Re-)Join VMs	336
Understanding Quorum's Effect on System Behavior	336
Example 1: A System Without a Quorum Server Experiences a Split-brain Condition	336
A Catastrophic Fault	337
Fault Handling	337
Recovery and Repair	338
Example 2: An ALSR System With a Quorum Server Avoids a Split-brain Condition	338
A Catastrophic Fault	339
Fault Handling	339
Recovery and Repair	340
Example 2, Modified: The Quorum Server Is Unreachable During the Catastrophic Fault ...	340
Example 2, Modified: The Quorum Server Is Unreachable With No Catastrophic Fault	341
Recovering From a Power Failure	341
Accessing Knowledge Base Articles	342
Fixed CVEs	343
CVEs Fixed in Stratus Redundant Linux Release 2.3.0.0	343
CVEs Fixed in Stratus Redundant Linux Release 2.2.0.0	349

CVEs Fixed in Stratus Redundant Linux Release 2.1.0.0	353
CVEs Fixed in Stratus Redundant Linux Release 2.0.1.0	357
CVEs Fixed in Stratus Redundant Linux Release 2.0.0.0	361
REST API	362
GET /system/overview	362
Chapter 11: Security	363
Security Hardening	363
Security Guidelines	364
Ports and Protocols	365
Network Segmentation	365
IP Tables/Firewall	365
User Account Creation	366
Password Creation	366
Least Privilege	367
Active Directory	367
Time Synchronization	367
Secure Connections	368
Updating SSL Certificate	369
SNMP Configurations	369
Backups	369
Automated Local Site Recovery	370
Auditing	370
Login Banner Notice	371
Upgrades	371
Physical Security	371
Advanced Security Guidelines	372
Password Quality Recommendations	372
Concurrent User Management	373
Antivirus	373
SSH Access Restrictions	373
Best Practices and Standards of Standards Organizations	375
Chapter 12: SNMP	379
Obtaining System Information with snmptable	379

Part 1: ztC Edge User's Guide

The *ztC Edge User's Guide* describes ztC Edge systems, how to deploy them, and how to use them.

For system descriptions including modes of operation and storage and network architecture, see:

- [Introduction to ztC Edge Systems](#)

For planning and deployment information, see:

- [Getting Started](#)

The following topics describe how to administer ztC Edge systems:

- [Using the ztC Edge Console](#)
- [Upgrading Stratus Redundant Linux Software](#)
- [Managing Physical Machines](#)
- [Managing Virtual Machines](#)
- [Maintaining Physical Machines](#)
- [Monitoring the System, Windows-based VMs, and Applications](#) (on systems licensed for such monitoring)

1

Chapter 1: Introduction to ztC Edge Systems

See the following topics for an introduction to ztC Edge systems:

- [ztC Edge System Overview](#)
- [Modes of Operation](#)
- [Network Architecture](#)
- [System Usage Restrictions](#)

ztC Edge System Overview

A ztC Edge system with two nodes provides automated recovery with no lost data in the event of a hardware failure. A ztC Edge system with a single node or with two nodes provides the ability (with the appropriate license) to observe system information by monitoring the local system or remote systems.

See the following topics for descriptions of system features and capabilities.

- [ztC Edge System Description](#)
- [Physical Machines and Virtual Machines](#)
- [Administrative Operations](#)
- [Alerts](#)
- [Remote Support](#)
- [Lights-Out Management](#)
- [Third-party Management Tools](#)

ztC Edge System Description

Stratus Redundant Linux software runs on a single ztC Edge computer, also referred to as a physical machine (PM) or node. The single-node ztC Edge system provides easy installation as well as virtualization and monitoring capabilities. You can add a second PM to a single-node system to configure a dual-node ztC Edge system (after this system reconfiguration, you need to apply an updated license). On a dual-node system, you can create fault-tolerant or highly available Virtual Machines (VMs). (A single-node system is simplex, so VMs are not fault-tolerant or highly available.) Both PMs in a dual-node system:

- Run the same host operating system (CentOS)
- Contain replicated virtual machines and storage (synchronized via direct Ethernet links between the two PMs)
- Support virtual machines running tested guest operating systems

For more information about the configuration of PMs in a ztC Edge system, see [System Requirements Overview](#).

On ztC Edge systems, you can monitor information about the host operating system and, on Windows-based VMs, information about the Windows operating system and applications running on the Windows-based VMs (see [Monitoring the System, Windows-based VMs, and Applications](#)). You can also remotely monitor the system's health; for information (see [Enabling ztC Advisor](#)).

ztC Edge systems provide a secure out-of-box experience. You also have the option of implementing additional security-related configuration settings. For information, see [Security](#).

Related Topics

[System Requirements Overview](#)

[Tested Guest Operating Systems](#)

[Network Architecture](#)

Physical Machines and Virtual Machines

Stratus Redundant Linux software running on one physical machine (PM), which is also referred to as a node, creates a single-node ztC Edge system that can create a virtual machine (VM) from scratch. The system can also import existing VMs from other environments and convert them into guest VMs. You can add a node to a single-node system to create a dual-node ztC Edge system. On a dual-node system, the management software automatically provides high-availability (HA) or FT-class protection of the VM (based on the VM configuration) by creating an identical instance of the selected VM on a second host PM. The system administrator manages this single VM entity from a separate, browser-based management console called the ztC Edge Console.

Neither the application nor the user is exposed to the redundant computing resources on the two host PMs. The application sees only one hostname, one MAC address for each network interface presented to the VM, and one IP address for each VM network interface presented to the VM. A system administrator loads and configures the applications on the guest VM—just as if the system administrator were loading them onto a physical server. If a fault or failure occurs in a disk or network device, the software automatically redirects I/O to the paired host PM for continuous operation. Though redundancy is lost until the failure is repaired, the VM continues to operate normally. The application continues to execute as if nothing had happened. The redundancy, fault detection, isolation, and management are completely transparent to the Windows or Linux environment and the application running within it. Repair of the PM is equally transparent and automatic. When a failed component on the PM is repaired, the software automatically incorporates the repaired components into the protected environment of the guest VM and restores redundancy transparently.

Related Topics

[Using the ztC Edge Console](#)

[Physical Machines Page](#)

[Virtual Machines Page](#)

Administrative Operations

You can perform many administrative operations on the ztC Edge system from the ztC Edge Console, a browser-based interface that provides access to the system as a whole as well as to physical machines (PMs), virtual machines (VMs), and other resources. For information, see the [ztC Edge Console](#).






Alerts

ztC Edge system alert messages notify the system administrator whenever an item needs attention. These can include:

- Configuration tasks that should be performed
- Notification of system operational states
- System problems that require attention

Click **Dashboard** in the left-hand navigation panel to see Alert messages and their descriptions. Click **Alerts** in the left-hand navigation panel to see the Alert log.

The following icons indicate the state of an alert message.

- | | |
|---|---------------------------------------|
|  | Informational |
|  | Normal or OK state |
|  | Minor, warning, or inconsistent state |
|  | Moderate state |
|  | Broken, failed, or severe state |

Remote Support

To access the ztC Edge system's remote support features, click **Preferences** in the left-hand navigation panel. From there, you can configure support and proxy specifications by selecting the following:

- **Support Configuration**—Configure settings to allow remote support access of your system by your authorized Stratus service representative and to enable your system to send health and status notifications to your authorized Stratus service representative. See [Configuring Remote Support Settings](#) for details.
- **Proxy Configuration**—Enables you to configure a proxy server for access to the Internet. See [Configuring Internet Proxy Settings](#) for details.

Lights-Out Management

ztC Edge systems incorporate Intel[®] Active Management Technology (AMT) lights-out support, which is disabled by default. You can enable and configure this support by pressing **Ctrl-P** while the BIOS splash screen is displayed during system startup. For important information about AMT configuration and restrictions, access the Knowledge Base to search for the article *AMT and Remote Access in ztC Edge* (KB0014200). See [Accessing Knowledge Base Articles](#).

AMT features are accessible on the **P1** network port of the system.

Third-party Management Tools

You can install third-party management tools on ztC Edge systems. Examples of such tools include vendor-specific management/monitoring utilities, enterprise management/monitoring utilities, and other miscellaneous management/monitoring software. Note the following:

- In general, management tools that run on the host operating system (CentOS) should run on ztC Edge systems. Possible exceptions are tools that manage/monitor the KVM-based virtualization. To manage/monitor ztC Edge virtualization, use the integrated ztC Edge management tools.
- Before deploying your ztC Edge system, Stratus recommends that you verify that it operates properly with the management tools installed and operational.
- Stratus recommends that you set up a non-root account for third-party management tools.
- You can access your ztC Edge system via the management network using the IP address(es) specified during the installation process (or supplied by the DHCP server if the interface was configured for DHCP during install).
- If you install third-party management tools in the host operating system of a physical machine (PM) and you need to replace the PM in the future, remember to reinstall the tools on the replacement PM.



Note: Third-party management tools have the potential of destabilizing the environment of the host operating system and system software. You may need to remove management tools that consume excessive RAM or disk space, or that are otherwise suspected of destabilizing the product. Follow the recommendation of your authorized Stratus service representative.

For information about accessing the host operating system, see [Accessing the Host Operating System](#).

Related Topics

[Getting Started](#)

[System Reference Information](#)

Modes of Operation

A ztC Edge system configured with two nodes allows you to choose from the following modes of VM availability levels of operation, depending on the system model:

- [High Availability Operation](#)
- [Fault Tolerant Operation](#)

Both HA operation and FT operation achieve their respective level of redundancy by using a pair of physical machines (PMs). FT operation consumes more system resources, which could possibly slow processing of applications.

Stratus recommends configuring quorum service for both HA operation and FT operation. The quorum service prevents a condition called *split-brain* where both PMs of an HA operation and FT operation pair are running independently of each other; for information, see [Quorum Servers](#).

High Availability Operation

On a dual-node ztC Edge system, Stratus Redundant Linux software provides two user-defined availability levels for VMs: High Availability (HA) and Fault Tolerant (FT).

You select a VM's protection or availability level when you create or import the VM by using the ztC Edge Console.

In High Availability (HA) operation, Stratus Redundant Linux automatically detects, isolates, and handles most hardware faults, thereby keeping your applications running. With HA remote-support technology, the software notifies the Stratus support center of various issues, indicating the type of fault and its exact location. This combination of automatic fault detection, isolation, and remote-support technologies ensures speedy access to expert support technicians and rapid problem resolution.

HA operation offers basic failover and recovery, with some faults requiring an (automatic) VM reboot for recovery, and return to HA operation:

- Eliminates downtime for many, but not all, CPU, memory, I/O, or other physical machine (PM) failures.
- Handles failures without IT intervention.

- Provides continuous, active validation of all components.
- Assures redundancy and recovery at all times.

HA is suitable for applications that can tolerate occasional interruptions of a few minutes.

(The supported VM availability levels depend upon the system model, as listed in [Virtual Machine Recommendations and Limits](#).)

Related Topics

[Modes of Operation](#)

[Virtual Machines Page](#)

[Using the ztC Edge Console](#)

Fault Tolerant Operation

On a dual-node ztC Edge system, Stratus Redundant Linux software provides two user-defined availability levels for VMs: High Availability (HA) and Fault Tolerant (FT).

You select a VM's protection or availability level when you create or import the VM by using the ztC Edge Console.

Use Fault Tolerant (FT) operation for applications that need the highest levels of availability. In FT operation, an application continues to run without downtime during a fault. The ztC Edge software transparently protects an application by creating a redundant environment for a VM running across two physical machines (PMs). With an identical instance of the selected VM on a second host, the ztC Edge software provides FT-class protection of the VM.

When enabled, FT operation transparently protects a VM from all faults, with no downtime, and FT operation:

- Eliminates downtime due to any CPU, memory, I/O, or other physical machine (PM) failure.
- Handles failures without IT intervention.
- Ensures no data loss.
- Provides continuous, active validation of all components.
- Assures complete redundancy and recovery at all times.

(The supported VM availability levels depend upon the system model, as listed in [Virtual Machine Recommendations and Limits](#).)

Related Topics

[Modes of Operation](#)

[Virtual Machines Page](#)

[Using the ztC Edge Console](#)

ALSR Configurations

An *automated local site recovery (ALSR) configuration* connects two physical machines in two separate sites. It is a disaster-tolerant deployment that maintains hardware redundancy as well as redundancy of physical computer rooms and the buildings containing them. Because of the geographic separation, an ALSR configuration requires careful planning of component placement and more complex networking topologies. **For ALSR configurations, Stratus strongly recommends that you use the quorum service because an ALSR configuration exposes the A-Link networks to other potential failure scenarios.**

(ALSR configurations are not available to systems configured with one node.)

[Meeting Network Requirements](#) lists the requirements for networks in a ALSR configuration.

ALSR and Quorum Service

In an ALSR configuration, configure two quorum-service computers in compliance with the best practices recommended for quorum deployment (see [Quorum Servers](#) and [Locating and Creating the Quorum Server](#)). In any ALSR configuration, a preferred quorum-service computer is located in a third facility, and an alternate is located in a fourth site (or carefully placed in the third). The networks are interconnected.

Quorum-service computers should be as isolated as possible. If both must be placed in a common (third) site, make sure that they do not depend on common power sources.

Physical connectivity between an ztC Edge PM and the quorum-service computers must not route through the other PM's site.

Placing a quorum-service computer in the same site as one of the ztC Edge PMs ensures data integrity. However, some site failures may then require that the VMs be shut down until manually recovered.

The management network physically connects the ztC Edge PMs and the quorum-service computers. For this to work properly, you must configure each ztC Edge PM to use a different gateway to reach the quorum-service computers. If the two PMs use the same gateway to reach the quorum-service computers, data integrity is ensured during failures. However, some site failures may then require that the VMs be shut down until manually recovered.

Related Topics

[Creating an ALSR Configuration](#)

[Network Architecture](#)

Quorum Servers

A *quorum service* is a Windows operating system-based service deployed on a server distinct from the two servers (physical machines or PMs) of a dual-node ztC Edge system. Quorum servers provide data integrity assurances and automatic restart capabilities for specific failures in a ztC Edge environment. Stratus strongly recommends using quorum servers, especially for ALSR operation. You can configure the two PMs of a ztC Edge system with 0, 1, or 2 quorum servers.

Quorum servers ensure the integrity of VMs against multiple network failure scenarios, including split-brain, and provide for unattended startup of VMs after specific failures. Quorum server communication occurs via the management network.

Quorum servers are particularly important in ALSR configurations. Best practice for ALSR is to place a preferred quorum computer in a third facility and an alternate quorum computer in a fourth facility. However, you can also place the alternate quorum service computer with the preferred quorum computer and still obtain satisfactory service. See [ALSR Configurations](#) for additional information.

If only two sites are available (thereby preventing the best practices configuration described above) and if one PM goes down and the surviving PM is unable to communicate with the quorum server (for example, because it is on the same site as the down PM), the VMs at the surviving site are automatically shut down to avoid running in split-brain.

Related Topics

[Creating an ALSR Configuration](#), which discusses quorum servers

[Configuring Quorum Servers](#)

Network Architecture

Ethernet networks provide pathways for communications of a system. The main types of Ethernet networks are:

- *Availability Link networks*, or *A-Link networks* (on the blue (**A2** or •) and yellow (**A1** or ••) network ports) on ztC Edge systems configured with two nodes are assigned to virtual machines (VMs) and are used to synchronize data or migrate VMs between two PMs. One A-Link network (on the blue (**A2** or •) network port), is a *private network* (priv0) that connects the two ztC Edge PMs. For more information, see [A-Link and Private Networks](#). (Systems configured with one node do not provide A-Link network functionality.)
- *Business networks* (on the **P1** network port, and **P2** if enabled) on all ztC Edge systems allow your applications to connect to your existing network. One business network (on the **P1** network port) is also a *management network* (ibiz0, sometimes referred to as network0) that connects to the ztC Edge Console and is used by the quorum servers. For more information, see [Business and Management Networks](#).

A ztC Edge system also provides a network segmentation detection mechanism. For information, see [Network Segmentation Fault Detection and Remediation](#).

A-Link and Private Networks

Every ztC Edge system configured with two physical machines (PMs, which are also referred to as nodes) requires a network for private management traffic between the two PMs. This private network is referred to as *priv0*, which is a physical, direct Ethernet, or VLANed connection between the nodes. Priv0 is used for peer node discovery and can have no other entities on it that respond to IPv4 broadcasts.

In addition to priv0, each system configured with two nodes has A-Link networks to increase data-replication performance between the PMs. A-Link networks let you sync disks, shunt networks, migrate VMs, perform heartbeat checks, and sync fault-tolerant memory.

The A-Links and priv0 are connected between the PMs in the same manner. The A-Links are connected between the blue and yellow network ports of each PM, where priv0 is shared with the A-Link on the blue network.

The simplest priv0 consists of a single Ethernet cable (crossover or straight-through) that directly connects an embedded Ethernet port on each server. If a networking device other than a single Ethernet cable is used for priv0, see [ALSR Configurations](#).

Related Topics

[Business and Management Networks](#)

[A-Link and Private Network Requirements](#)

[Network Architecture](#)

Business and Management Networks

All Ethernet ports—other than those used by A-Link networks and the private network on a dual-node ztC Edge system—are considered business-network ports. Guest operating systems use business-network ports to connect to your network.

One business network is the *management* network, and each PM has a single management network that is referred to as *ibiz0* and uses the network labeled **P1**. The management network accesses the ztC Edge Console and handles miscellaneous management tasks and the quorum server. These management tasks include:

- Sending call-home messages and e-alerts
- Checking the status of licenses
- Each PM's communication with the ztC Edge Console
- Failover function of *priv0* (for systems with dual nodes)
- Communication between the two nodes (for systems with dual nodes)
- Communication with the quorum server (if one exists)

You set up the management network when you deploy the system. You can also set up business networks for any business-network ports that are physically connected during deployment. To connect a second business network after the deployment is complete, see [Connecting a Second Business Network](#).

Related Topics

[A-Link and Private Networks](#)

[Business and Management Network Requirements](#)

[Network Architecture](#)

Network Segmentation Fault Detection and Remediation

A network fault that occurs such that the two ends of a shared network cannot communicate with each other, but each side still has external network connectivity, is referred to as a *network segmentation fault*.

A dual-node ztC Edge system provides a *network segmentation detection mechanism* that places the active VM on the node that has the most external network connectivity when the system detects this fault. As part of this feature, the ztC Edge system constantly sends UDP packets over the business network interface between the active node and the stand-by node. The system's network segmentation logic detects a fault when this packet flow is interrupted while both sides still have an active network link. In this fault scenario, both nodes still have active network connections, so the fault lies in a switch that is external to the ztC Edge system.

When this case is detected, the ztC Edge system handles the fault based on logic that determines which side has better external connectivity. The ztC Edge system makes this fault-handling decision by continually monitoring incoming broadcast/multicast traffic to determine which node has the most incoming traffic. In this fault case, if the VM is not already active on the node with the most incoming network traffic, the ztC Edge system fails the VM network over to this node. The fault detection feature requires no user configuration since it is basing the decision on traffic that normally occurs on any system.

Related Topics

[Network Architecture](#)

System Usage Restrictions

Observe the restrictions to system usage that are described in the following topics:

- [QEMU](#)
- [Accessing the Host Operating System](#)

QEMU

ztC Edge dual-node systems and single-node systems support the open-sourced hypervisor QEMU ("Quick EMUlator"), which performs hardware virtualization. When used as a virtualizer, QEMU executes the guest code directly on the host CPU, achieving a high level of performance.

ztC Edge users should make no changes to the QEMU virtualization engine or to its configuration.

Accessing the Host Operating System

After you complete the ztC Edge deployment, you can access the host operating system (CentOS) locally at the PM's physical console, or you can access it remotely by using a secure shell (SSH) client.

To log on to the host operating system with an SSH client, use the management IP address specified during deployment (or supplied by the DHCP server, if the interface was configured for DHCP during deployment). If needed, you can locate the management IP address for a PM as described in this topic.



Caution: Do not update the CentOS host operating system of the ztC Edge system from any source other than Stratus. Use only the release that is installed with the Stratus Redundant Linux software.



Note: To ensure that administrative commands will work properly, log on to the physical console or IP address of the primary PM (unless you specifically need to operate on components in the secondary PM of a dual-node system). Do not connect to the system IP address, as it can move from PM to PM.



Note: The default password for the root account is **KeepRunning**. To secure the system, change the `root` password on each PM as soon as possible. The first time you log on to a PM as root, the system automatically prompts you to change the password. To change the password again in the future, issue the `passwd` command on each PM.

For information about using third-party management tools in the host operating system, see [Third-party Management Tools](#).

To locate the IP address of each PM in the ztC Edge Console

1. Click **Preferences** in the left-hand navigation panel to open the **Preferences** page.
2. Under **System**, click **IP Configuration**.
3. Record the **IP address** of each PM, **node0** and **node1** (if present).
4. Click **Physical Machines** in the left-hand navigation panel to open the **Physical Machines** page.
5. Record which PM is the primary node for the system, displayed as **noden (primary)**. In most cases, log on to the IP address of the primary node to ensure that administrative commands will work properly.

To access the host operating system from a Windows-based system

You can download and use PuTTY, a suite of open-source SSH clients:

<http://www.chiark.greenend.org.uk/~sgtatham/putty/download.html>

In particular, the `putty.exe` client allows you access a shell to execute programs on the command line of the host operating system. PuTTY also includes the `pscp.exe` command-line utility that allows you to securely transfer files from a remote system to the host operating system.

If you prefer a secure copy (SCP) client with a graphical user interface, you can also try the open-source WinSCP utility:

<http://winscp.net/eng/index.php>

To access the host operating system from a Linux-based system

On many Linux- and UNIX-based systems, SSH utilities are already installed and enabled by default. See `ssh(1)` and `scp(1)` for information about how to use these utilities.

2

Chapter 2: Getting Started

The following topics describe the ztC Edge planning, deployment, and post-deployment tasks:

- [Planning](#)
- [Deployment](#)
- [Post-Deployment Tasks](#)

Planning

See the following topics for information about planning your system configuration.

- [Safety Precautions](#)
- [System Requirements Overview](#)
- [Space Recommendations](#)
- [System Specifications](#)
- [DIN-Rail and Wall-Mount Bracket Assembly](#)
- [Product Compliance](#)
- [General Network Requirements and Configurations](#)
- [Business and Management Network Requirements](#)
- [A-Link and Private Network Requirements](#)
- [ztC Edge Console Requirements](#)
- [Compatible Internet Browsers](#)
- [Power Requirements and Considerations](#)
- [Creating an ALSR Configuration](#) (if applicable to your configuration)

After you have planned the system configuration, continue with [Deployment](#).

Safety Precautions

Before getting started, please read the following important safety precautions.



Warning: Ensure the voltage of the power source is correct before connecting the product.



Warning: Servicing to be performed by qualified service personal, no user-serviceable components.

Warning: Risk of explosion if battery is replaced by an incorrect type. Dispose of used batteries according to the instructions.



IL Y A RISQUE D'EXPLOSION SI LA BATTERIE EST REMPLACÉE PAR UNE BATTERIE DE TYPE INCORRECT. METTRE AU REBUT LES BATTERIES USAGÉES CONFORMEMENT AUX INSTRUCTIONS



Warning: Hot Surface Do Not Touch.

The following information is applicable only to ztC Edge 110i systems:

- These devices are open-type devices that are to be installed in an enclosure suitable for the environment and where the internal compartment is only accessible by the use of tool.
- SUITABLE FOR USE IN CLASS I, DIVISION 2, GROUPS A, B, C AND D HAZARDOUS LOCATIONS, OR NONHAZARDOUS LOCATIONS ONLY.



Warning: EXPLOSION HAZARD - DO NOT DISCONNECT EQUIPMENT WHILE THE CIRCUIT IS LIVE OR UNLESS THE AREA IS KNOWN TO BE FREE OF IGNITABLE CONCENTRATIONS.

System Requirements Overview


A ztC Edge system can support multiple virtual machines (VMs) and a remote management computer (that is, a general-purpose PC) that can run the ztC Edge Console.

ztC Edge [System Hardware](#) specifications and requirements are summarized below, for each type of physical machine (PM). See [Space Recommendations](#) for recommendations for placement of PMs, and see [System Specifications](#) for additional system specifications.


For information on guest operating systems, see [Tested Guest Operating Systems](#).

System Hardware

Feature	ztC Edge 200i PM	ztC Edge 250i PM
RAM (physical memory)	32 GB	64 GB

Feature	ztC Edge 200i PM	ztC Edge 250i PM
Disk space	1 terabyte (TB) solid-state drive (SSD)	2 TB SSD
Network ports	<p>Each PM has four 1-Gb Ethernet ports.</p> <p>On a system configured for two nodes, use:</p> <ul style="list-style-type: none"> • A1 (yellow label), for A-link 1 • A2 (blue label) for priv0 <p>On a system configured for two nodes or for one node, use:</p> <ul style="list-style-type: none"> • P1 for a combined business network and management network • P2 for an optional business network 	<p>Each PM has eight network ports: six 1-Gb ports (P1 through P6) in the main chassis and two 10-Gb ports (A1 and A2) in the expansion unit.</p> <p>On a system configured for two nodes, use:</p> <ul style="list-style-type: none"> • A1 (yellow label), for A-link 1 • A2 (blue label) for priv0 <p>On a system configured for two nodes or for one node, use:</p> <ul style="list-style-type: none"> • P1 for a combined business network and management network. • P2 through P6 for optional business networks.
	<div>  <p>Note: P1 is sometimes referred to as network0 or ibiz0; P2 is sometimes referred to as network1 or ibiz1; P3 is sometimes referred to as network3 or ibiz3; and so on.</p> </div>	

Feature	ztC Edge 100i PM	ztC Edge 110i PM
RAM (physical memory)	32 GB	32 GB or 64 GB

Feature	ztC Edge 100i PM	ztC Edge 110i PM
Disk space	512 GB solid-state drive (SSD), of which approximately 475 GB is available for VMs.	2 terabytes (TB) SSD, of which approximately 1.9 TB is available for VMs.
Network ports	<p>Each PM has four 1-Gb Ethernet ports.</p> <p>On a system configured for two nodes, use:</p> <ul style="list-style-type: none"> Blue (•) for a combined A-link and priv0 private network Yellow (••) for a second, dedicated A-link network <p>On a system configured for two nodes or for one node, use:</p> <ul style="list-style-type: none"> P1 for a combined business network and management network P2 for an optional business network 	<p>Each PM has eight network ports: six 1-Gb ports (P1 through P6) at the front and two 10-Gb ports (A1 and A2) at the back.</p> <p>On a system configured for two nodes, use:</p> <ul style="list-style-type: none"> A1 (yellow label), for A-link 1 A2 (blue label) for priv0 <p>On a system configured for two nodes or for one node, use:</p> <ul style="list-style-type: none"> P1 for a combined business network and management network. P2 through P6 for optional business networks.
	<div>  <p>Note: P1 is sometimes referred to as network0 or ibiz0; P2 is sometimes referred to as network1 or ibiz1; P3 is sometimes referred to as network3 or ibiz3; and so on.</p> </div>	

The system also supports Intel[®] Active Management Technology (AMT) lights-out support, which you can access over the **P1** port of each PM.

ALSR configurations have different network requirements. For information, see [Meeting Network Requirements](#).

See [Network Architecture, A-Link and Private Networks](#), and [Business and Management Networks](#) for more information.

IP Addresses

Each ztC Edge system must have a static IPv4 IP address assigned for use by the management software. Obtain IP addresses for DNS primary and secondary servers, and gateway and subnet mask information for your management network, from your IT network administrator. See [Obtaining System IP Information](#) for more information.

Ports

ztC Edge systems use port 443 in the local firewall for HTTPS communications, port 22 for ssh, and 5900-5999 for each active VNC associated with each VM. Firewalls must allow traffic through the appropriate ports. Firewalls must permit VMs to contact quorum service computers using UDP port 4557. For additional information on TCP and UDP ports, access the Knowledge Base to search for the article *TCP and UDP ports used by ztC Edge* ([KB0014311](#)). See [Accessing Knowledge Base Articles](#).

Related Topics

[Important Physical Machine and Virtual Machine Considerations](#)

[Virtual Machine Recommendations and Limits](#)

[Planning Virtual Machine Resources](#)

[Configuring IP Settings](#)

Space Recommendations

To ensure that the installation site for a ztC Edge system provides a properly equipped, cooled, and sized environment, consider the following space recommendations for your site.

Space recommendations for nodes located on a table follow:

- At least 2 in. (5.08 cm) of space on the left and right sides of a node
- At least 3 in. (7.62 cm) of space on the top of a node
- At least 5 in. (12.7 cm) of space on the front and rear of a node
- At least 2 in. (5.08 cm) of space between nodes

Space recommendations for DIN rail-mounted nodes follow:

- At least 2 in. (5.08 cm) of space on the left and right sides of a node
- At least 5 in. (12.7 cm) of space on the top and bottom of a node
- At least 2 in. (5.08 cm) of space between nodes

Additional space recommendations follow:

- A node can be installed either horizontally (on a flat surface) or vertically (on a wall). If a node is installed vertically:
 - For a ztC Edge 100i or 110i node, the surface with the Stratus logo should be facing up.
 - For a ztC Edge 200i or 250i node, the surface with the ports should be facing down.
- To prevent damaging the system's cables, the bend radius for all cables should be at least 2 in. (5.08 cm).
- Avoid installing any kind of heat-generating source below the node.
- Avoid exceeding the operational environmental limits of the node.
- Each node should have at least 100 LFM (0.51 m/s) of airflow over the heatsink for optimal heat transfer.

In addition to the preceding recommendations, evaluate your site's specific installation needs. If you need further guidance, contact your authorized Stratus service representative.

System Specifications

For specifications of ztC Edge systems, see the following:

- [System Specifications: ztC Edge 250i Systems](#)
- [System Specifications: ztC Edge 200i Systems](#)
- [System Specifications: ztC Edge 110i Systems](#)
- [System Specifications: ztC Edge 100i Systems](#)

System Specifications: ztC Edge 250i Systems

The following table provides system specifications.

Component	Description
-----------	-------------

CPU	
CPU	Intel Xeon W-1290TE, 1.8 GHz, 20 MB cache, 10 HT cores, 35W
System Memory	2 x 260-pin unbuffered DDR4-2666 MHz ECC, SO-DIMM socket, 64 GB total
I/O	
Display	1 x HDMI 1 x VGA port
Ethernet	6 x 10/100/1000 Ethernet ports 2 x 10 Gb Ethernet ports
USB Ports	2 x USB 3.2, Gen 2 (10 Gbps) 4 x USB 3.2, Gen 1 (5 Gbps)
Inactive Ports	Audio ports Serial ports (DB9)
Storage	1 NVMe SSD, 2 TB
Indicators	1 x green LED (power switch) as indicator for PWR status 1 x yellow LED as indicator for SYS status
System	
Power Supply	Optional AC power module, 100 to 240 VAC, 50/60 Hz, 2.5A
Input power	9 to 36 VDC
Wattage and BTU	Idle: 47 W, 160 BTU/hr Maximum: 84 W, 287 BTU/hr
Environmental	

Operating Temperature	-20°C to 60°C (-4°F to 140°F)
Storage Temperature	-40°C to 85°C (-40°F to 185°F)
Humidity	95% @ 40°C (non-condensing)
Shock	IEC 60068-2-27 (with SSD: 20G @ wall mount, half sine, 11 ms duration)
Vibration Endurance	IEC 60068-2-64 (with SSD: 3Grms STD, random, 5 - 500 Hz, 1 hr/axis)
<i>Physical Dimensions</i>	
Weight	4.6 kg (10.2 lb)
Height	192 mm (7.55 in.)
Width	127 mm (5.00 in.)
Depth	230 mm (9.05 in.)

System Specifications: ztC Edge 200i Systems

The following table provides system specifications.

Component	Description
<i>CPU</i>	
CPU	Intel Xeon W-1250TE, 2.4 GHz, 12 MB cache, 6 HT cores, 35W
System Memory	2 x 260-pin unbuffered DDR4-2666 MHz ECC, SO-DIMM socket, 32 GB total
<i>I/O</i>	
Display	1 x HDMI 1 x VGA port

Ethernet	6 x 10/100/1000 Ethernet ports
USB Ports	2 x USB 3.2, Gen 2 (10 Gbps) 4 x USB 3.2, Gen 1 (5 Gbps)
Inactive Ports	Audio ports Serial ports (DB9)
Storage	1 NVMe SSD, 1 TB
Indicators	1 x green LED (power switch) as indicator for PWR status 1 x yellow LED as indicator for SYS status
System	
Power Supply	Optional AC power module, 100 to 240 VAC, 50/60 Hz, 2.5A
Input power	9 to 36 VDC
Wattage and BTU	Idle: 32 W, 109 BTU/hr Maximum: 75 W, 256 BTU/hr
Environmental	
Operating Temperature	-20°C to 60°C (-4°F to 140°F)
Storage Temperature	-40°C to 85°C (-40°F to 185°F)
Humidity	95% @ 40°C (non-condensing)
Shock	IEC 60068-2-27 (with SSD: 20G @ wall mount, half sine, 11 ms duration)
Vibration Endurance	IEC 60068-2-64 (with SSD: 3Grms STD, random, 5 - 500 Hz, 1 hr/axis)
Physical Dimensions	
Weight	3.3 kg (7.2 lb)

Height	192 mm (7.55 in.)
Width	77 mm (3.07 in.)
Depth	230 mm (9.05 in.)

System Specifications: ztC Edge 110i Systems

The following table provides system specifications.

Component	Description
<i>CPU</i>	
CPU	Intel Core i7-8700T processor, 35W
System Memory	2 x 260-pin unbuffered DDR4-2400 MHz SO-DIMM socket, 32 GB or 64 GB total
<i>I/O</i>	
Display	1 x HDMI 1 x DVI port
Ethernet	6 x 10/100/1000 Ethernet ports 2 x 10 Gb Ethernet ports
USB Ports	2 x USB 3.2, Gen 2 (10 Gbps) (previously referred to as USB 3.1, Gen 2) 2 x USB 3.2, Gen 1 (5 Gbps) (previously referred to as USB 3.1, Gen 1)
Storage	1 SATA SSD, 2 TB
Indicators	1 x green LED as indicator for PWR status 1 x green LED as indicator for SYS status 1 x green LED as indicator for SSD active
Switch	1 x Power switch

	1 x Reset switch
System	
Power Supply	24VDC input Optional AC power module, 100 to 240VAC, 50/60 Hz, 5A ¹
Wattage and BTU	62 W, 213 BTU/hr
Environmental	
Operating Temperature	-20°C to 55°C (-4°F to 131°F)
Storage Temperature	-40°C to 80°C (-40°F to 176°F)
Humidity	10% to 95% (non-condensation)
Shock	IEC 60068-2-27 (with SSD: 25G @ wall mount, half sine, 11 ms duration)
Vibration Endurance	IEC 60068-2-64 (with SSD: 3Grms STD, random, 5 - 500 Hz, 1 hr/axis)
Physical Dimensions	
Weight	5.2 kg (11.46 lb) without package 6.2 kg (13.67 lb) with package
Height	86.9 mm (3.42 in.)
Width	280 mm (11.02 in.)
Depth	210 mm (8.26 in.)

System Specifications: ztC Edge 100i Systems

The following table provides system specifications.

¹The DIN wall-mount for the AC adapter is not available for India deliveries.

Component	Description
<i>CPU</i>	
CPU	Intel Core i7-6700TE processor, 35W
System Memory	2 x 260-pin unbuffered DDR4-2400 MHz SO-DIMM socket, 32 GB total
<i>I/O</i>	
Display	1 x HDMI 1 x DVI port
Ethernet	4 x 10/100/1000 Ethernet ports
USB Ports	2 x USB 2.0 6 x USB 3.2, Gen 1 (5 Gbps) (previously referred to as USB 3.1, Gen 1)
Storage	1 SATA SSD, 512 GB
Indicators	1 x green LED as indicator for PWR status 1 x green LED as indicator for SYS status 1 x green LED as indicator for SSD active
Switch	1 x Power switch 1 x Reset switch
<i>System</i>	
Power Supply	9-36VDC input Optional AC power module, 100 to 240VAC, 50/60 Hz, 5A
Wattage and BTU	41 W, 140 BTU/hr
<i>Environmental</i>	

Operating Temperature	-40°C to 60°C (-40°F to 140°F)
Storage Temperature	-40°C to 80°C (-40°F to 176°F)
Humidity	10% to 95% (non-condensation)
Shock	IEC 60068-2-27 (with SSD: 50G @ wall mount, half sine, 11 ms duration)
Vibration Endurance	IEC 60068-2-64 (with SSD: 3Grms STD, random, 5 - 500 Hz, 1 hr/axis)
Physical Dimensions	
Weight	4.8 kg (10.58 lb) without package 5.6 kg (12.34 lb) with package
Height	75 mm (2.95 in.)
Width	280 mm (11.02 in.)
Depth	190 mm (7.48 in.)

DIN-Rail and Wall-Mount Bracket Assembly

For information about attaching mount kits to ztC Edge systems, see the following:

- [DIN-Rail and Wall-Mount Bracket Assembly: ztC Edge 250i Systems](#)
- [DIN-Rail and Wall-Mount Bracket Assembly: ztC Edge 200i Systems](#)
- [DIN-Rail and Wall-Mount Bracket Assembly: ztC Edge 110i Systems](#)
- [DIN-Rail and Wall-Mount Bracket Assembly: ztC Edge 100i Systems](#)


DIN-Rail and Wall-Mount Bracket Assembly: ztC Edge 250i Systems



Note: When installing the DIN-rail or wall-mount kit on a ztC Edge 250i node, make sure that the surface with the ports faces down.

To attach the DIN-rail mount kit:

- Use the four flat-head M4 x 4mm screws located in the accessory box to attach the DIN-rail mount plate to the node.
- Use the six flat-head M3 x 4.5mm screws located in the accessory box to attach the two DIN-rail mount brackets to the DIN-rail mount plate.




To attach the wall/table mount kit, use the four flat-head M4 x 4mm screws located in the accessory box to attach the wall/table mount brackets to the node.




Note: If you install the screws in drywall, use hollow wall anchors to ensure that the unit does not pull away from the wall due to prolonged strain on the cable and power connector. Use a maximum screw diameter of 0.166 in. (4.2 mm) with a minimum head diameter of 0.216 in. (5.5 mm).

When using the wall/table mount kit, you can mount the node flat against a surface; however, ensure that you install the mount brackets to leave enough space between the vent holes and the surface to allow for heat dissipation.



Alternatively, you can mount the node in a tower orientation to allow for maximum heat dissipation or space requirements.



The mount kit also includes rubber feet that you can install to place the node on a table in the flat or tower orientation.


DIN-Rail and Wall-Mount Bracket Assembly: ztC Edge 200i Systems



Note: When installing the DIN-rail or wall-mount kit on a ztC Edge 200i node, make sure that the surface with the ports faces down.

To attach the DIN-rail mount kit:


- Use the four flat-head M4 x 4mm screws located in the accessory box to attach the DIN-rail mount plate to the node.
- Use the six flat-head M3 x 4.5mm screws located in the accessory box to attach the two DIN-rail mount brackets to the DIN-rail mount plate.



To attach the wall/table mount kit, use the four flat-head M4 x 4mm screws located in the accessory box to attach the wall/table mount brackets to the node.



Note: If you install the screws in drywall, use hollow wall anchors to ensure that the unit does not pull away from the wall due to prolonged strain on the cable and power connector. Use a maximum screw diameter of 0.166 in. (4.2 mm) with a minimum head diameter of 0.216 in. (5.5 mm).




The mount kit also includes rubber feet that you can install to place the node on a table.

DIN-Rail and Wall-Mount Bracket Assembly: ztC Edge 110i Systems




Note: When installing the DIN-rail or wall-mount kit on a ztC Edge 110i node, make sure that the surface with the Stratus logo faces up.

To attach the DIN-rail mount kit, use the six flat-head M3 x 6 mm screws located in the accessory box.



To attach the wall-mount kit, remove the six (three per side) round-head M3 x 12 mm screws located on the bottom of the node. Reuse these six screws to install the wall-mount kit.



Note: If you install the screws in drywall, use hollow wall anchors to ensure that the unit does not pull away from the wall due to prolonged strain on the cable and power connector. Use a maximum screw diameter of 0.166 in. (4.2 mm) with a minimum head diameter of 0.216 in. (5.5 mm).

DIN-Rail and Wall-Mount Bracket Assembly: ztC Edge 100i Systems




Note: When installing the DIN-rail or wall-mount kit on a ztC Edge 100i node, make sure that the surface with the Stratus logo faces up.

To attach the DIN-rail mount kit:


- Remove the four (two per side) flat-head M3 x 6mm screws located at the bottom of the node.
- Use the four round-head M3 x 6mm screws located in the accessory box to attach the DIN-rail mount plate to the node.

- Use the six flat-head M3 x 6mm screws located in the accessory box to attach the two DIN-rail mount brackets to the DIN-rail mount plate.



To attach the wall-mount kit:

- Remove the four (two per side) flat-head M3 x 6mm screws located at the bottom of the node.
- Use the four round-head M3 x 6mm screws located in the accessory box to attach the wall-mount brackets to the node.



Note: If you mount the unit on drywall or similar material, use hollow wall anchors compatible with the material to ensure that the unit does not pull away from the wall due to prolonged strain on the cables. Use screws with a minimum diameter of 0.138 in. (3.5 mm), minimum length of 1.5 in. (38.1 mm), and minimum head diameter of 0.216 in. (5.5 mm). Ensure that the screws are compatible with the selected hollow wall anchor.

Product Compliance

Compliance information for ztC Edge systems is provided at the following website:

https://stratadoc.stratus.com/compliance_info/Compliance_Information_for_Stratus_Products.htm

General Network Requirements and Configurations



Note: ALSR networks have some additional and different network requirements and recommendations. See [Creating an ALSR Configuration](#) in addition to the information below.

Before you deploy a ztC Edge system, make sure your network meets the following requirement:

- ztC Edge systems utilize full IPv4 and IPv6 protocol access, including IPv6 multicast. Any obstruction of this traffic may prevent a successful deployment or compromise the availability of a running ztC Edge system.

In addition, see the following topics for the requirements specific to each network type:

- [A-Link and Private Network Requirements](#)
- [Business and Management Network Requirements](#)

Business and Management Network Requirements

Business and management networks, which single-node systems and dual-node systems use, have the following requirements:

- The networks use IPv6 link-local addressing.
- The networks support an MTU value of up to 9000.
- The networks do not support bonding or VLAN trunking.
- Virtual machines (VMs) can use IPv4, IPv6, and other Ethernet protocols.
- All business networks can be used for IPv6 host access if your site has SLAAC or DHCPv6 enabled.
- To reach the ztC Edge Console, use ibiz0, which is the IPv4 address that migrates to the primary management physical machine (PM). Each PM of a dual-node system also has its own ibiz0 IPv4 address on the management network.
- Each PM requires at least one business network (specifically, the management network).

To ensure that Ethernet traffic flows unobstructed to and from VMs from either PM of a dual-node system:

- The switch ports connected to business networks must not filter ARP packets, including gratuitous ARP packets. A ztC Edge system sends gratuitous ARP packets on behalf of guest VMs in order to prompt Ethernet switches to update their port-forwarding tables to direct VM traffic to the appropriate physical Ethernet port on the appropriate PM.
- The switch ports connected to business networks must allow layer2 multicasts (address: 01:E0:09:05:00:02) with ethertype: 0x8807.
- If you configure RHEL or CentOS guests to have multiple NICs on same subnet, you may experience guest network connectivity issues due to asymmetric routing. To avoid this problem, modify the `/etc/sysctl.conf` file on the guest Virtual Machine (VM) to contain the following lines, save the file, and reboot the VM.
 - `net.ipv4.conf.default.rp_filter = 2`
 - `net.ipv4.conf.all.rp_filter = 2`
- Do not issue the `ifdown` command from a PM's host OS to temporarily bring down a VM's business network connection (ibizx). Doing so will disconnect the physical interface from its bridge and cause the VM to become unreachable over the network. Instead, use the `ifconfig down` command.
- The switches connected to business networks must not enable any MAC address security features that would disable the movement of a MAC address from one business link to the matching business link on the other PM.
- For optimal failover response, configure any switches connected to your system to have MAC aging timeout values of less than one second.

If these requirements are not met, or if the switch does not properly update its forwarding table when a VM is migrated from one ztC Edge PM to the other PM of a dual-node system, the VM may experience a blackout in which network traffic is not properly directed to and from the VM.

Related Topics

[Network Architecture](#)

[Business and Management Networks](#)

A-Link and Private Network Requirements

A-Link and private networks, which are available only to dual-node systems, have the following requirements:

- The networks use IPv6 link-local addressing.
- All A-Link and private networks on one PM of a ztC Edge system must be in the same L2 broadcast domain as its matching links on the other physical machine (PM), without any protocol filtering.
- Ethernet packets sent between two PMs of a system must not be obstructed or rate-limited. Ensure that they are not routed or switched by any L3 network infrastructure.
- The speed of A-Link networks should be equal to or greater than the speed of business or management networks.
- Network traffic for storage replication between PMs is sent over A-Link networks.
- Private networks have no network hosts connected other than the ztC Edge end-points.

Related Topics

[A-Link and Private Networks](#)

ztC Edge Console Requirements

The ztC Edge Console provides browser-based remote management of the ztC Edge system, its physical machines (PMs), and virtual machines (VMs).

- Your computer must be able to access the subnet containing the ztC Edge management network (which is enabled on the network port labeled **P1**).
- Use a supported browser. See [Compatible Internet Browsers](#).

For more information, see [Using the ztC Edge Console](#).

Compatible Internet Browsers

A browser is used to connect to the ztC Edge Console. Use only browsers that are compatible with ztC Edge systems. Using an incompatible browser can result in some rendering problems and the omission of some wizards.

The following browsers are compatible with ztC Edge systems.

Compatible Browsers	Release
Microsoft Internet Explorer™	11.0.648 or greater
Microsoft Edge	42.17134 or greater
Mozilla® Firefox®	65.0 or greater
Google® Chrome™	73.0 or greater

Power Requirements and Considerations

To ensure maximum availability, Stratus strongly recommends that ztC Edge's fault-tolerant (FT) software run on physical machines (PMs), or nodes, that are powered by redundant power supplies. In addition, each PM power supply should connect to a separate power source.

See [Connecting Power](#) for illustrations of some sample power-connection configurations.

Deployment

When you deploy the system for the first time:



Note: If you have already deployed and configured a system, and you need to prepare it for deployment at a new site, see [Redeploying a ztC Edge System](#).

1. Review the network cabling information. If necessary, make changes in your network. See [Connecting Ethernet Cables](#).
2. Deploy the system. See [Deploying the System](#).

When the deployment is complete, see [Post-Deployment Tasks](#).

Related Topics

[Upgrading Stratus Redundant Linux Software](#)

Connecting Power


To connect power, connect a single-node ztC Edge system to a single power supply, or configure a dual-node ztC Edge system with redundant power supplies connected to separate sources. You can optionally

use site DC power or uninterruptible power supplies (UPS), as described below.


After connecting power, return to [Deploying the System](#).

Connecting ztC Edge 200i and 250i Systems to Site DC Power (Optional)

If you install a ztC Edge 200i or 250i system in an environment that provides DC power, you need to supply a power source at 9 to 36 VDC and a power cord with the correct wiring for each node. The following illustration shows the pin assignments for the DC input power connector on each 200i or 250i node.



If you are connecting a node to a site DC power supply with user-supplied materials, fasten four separate wires (two positive (+) and two negative (-) wires) from the DC power supply to the power connector terminals. The wires must be a minimum of 18 AWG with a maximum length of 5 ft (1.5m). If the wire length is more than 5 ft (1.5m), increase the wire gauge for a maximum voltage drop of 1 V at 6.5 A. For best results, also terminate each wire with a ferrule sized and crimped as specified by the ferrule manufacturer. The following illustration shows the recommended signal ground, AC power adapter, and optional site DC power connections.



For additional system specifications, see [System Specifications](#).


Connecting a ztC Edge System to UPS Power (Optional)

The following illustrations show how to connect one or two optional UPS units to a dual-node ztC Edge system. For an illustration of how to connect a single-node system to a UPS, see the node0 connections under **Dual UPS**.




Note: Stratus recommends that you use two UPS units connected to separate and independent power sources. With two power sources, the system continues to receive power in the event that one power source fails.

Single UPS:



Dual UPS:



Related Topics

[Power Requirements and Considerations](#)

Deploying the System

This topic describes how to deploy a ztC Edge system. It supplements information in the [deployment guide](#) for your system. (For a system with one node, if your system is already running and you need to add a second node, see [Adding a Node to a Single-Node System](#).)



Prerequisite: The following procedure describes how to deploy a factory-fresh node installed with Release 2.3 or higher. If you need to deploy an existing node from a decommissioned system or a node installed with an earlier software release, you must perform a factory reset on the node before deploying it. If necessary, contact your Stratus service representative for assistance.

To deploy a system

1. Connect the keyboard and monitor to the node, connect the P1 port to your existing LAN, and then connect power to the node (Step 1 of the [deployment guide](#) for your system).
2. The node powers on automatically; otherwise, press the power button (Step 2 of the [deployment guide](#) for your system). The node might beep while booting, which is normal.
3. In the **ztC Edge Deployment Wizard**, press **Enter** to begin deploying the system and follow the on-screen instructions (Step 3 of the [deployment guide](#) for your system).
4. A window appears asking you to select a keyboard map. Use the **Tab**, arrow, or **Esc** key to select one of the following:
 - **Germany - map = DE**
 - **Japan - map = JP106**
 - **USA - map = US** (the default)

Use the **Tab** key to navigate to **OK**, and then press **Enter**.



Note: You can select or change the keyboard map after the initial deployment. For information, see [Mapping Your Keyboard](#).

5. A message on the screen instructs you to select the method to configure the network address of this node. Use the **Tab**, arrow, or **Esc** key to select one of the following:
 - **Automatic configuration via DHCP** (the default)—Select this method to configure P1 as a dynamic IP configuration.
 - **Manual configuration (Static Address)**—Select this method to provide IP addresses for P1. A dialog box appears for you to type these values, which you obtain from your network administrator (you may have written these addresses in the **User-supplied Components** section of the [deployment guide](#) for your system):
 - IP address for this node
 - Subnet mask for this node
 - Default gateway (optional)

If you enter invalid information, the dialog box redisplay until you enter valid information.

Use the **Tab** key to navigate to **OK** (or **Back**), and then press **Enter**.

6. A confirmation dialog box appears. Use the arrow keys or the **Tab** key to navigate to **Save** (the default), to save the displayed values (or to navigate to **Back**, to return to the previous window). Then, press **Enter**.

If you saved the values, a blue screen appears for several seconds.

7. The screen continues to display various status messages for up to 5 minutes.
8. The screen displays a message to connect to an IP address in a web browser (Step 4 of the [deployment guide](#) for your system). Note the IP address because you will use it to log on to the ztC Edge Console.

The monitor connected to the node displays no additional prompts. If you configured P1 as a dynamic IP configuration (selecting **Automatic configuration via DHCP** above for the node's network address), record its IP address as described in [Recording the Management IP Address](#).



Note: If you configured incorrect network settings (for example, you mistyped an IP address), you can correct the problem by pressing the **[1]** key to start over.

To complete the deployment, see [Logging On to the ztC Edge Console for the First Time](#).

Deployment Guides

[ztC Edge 100i/110i Systems: Deploying a Single-Node System](#) (R014Z)


[ztC Edge 200i/250i Systems: Deploying a Single-Node System](#) (R017Z)

Connecting Ethernet Cables

When deploying a ztC Edge system, you need to connect Ethernet cables. The following illustration shows the Ethernet cable connections for the network configuration of a system configured for two nodes. (The keyboard and console can connect to either node0 or node1. The illustration shows the connection to node0.) On a system configured for one node, follow the instructions (below) to connect Ethernet cables to **P1** for network0 (ibiz0) and, optionally, to **P2** for network1 (ibiz1).



Note: Ethernet ports **P1** and **P2** and ports **A1** and **A2** are on the front or back of the node, depending on the node model. In addition, a node may have more ports than just **P1** and **P2**, depending on the node model.



When you deploy the system (see [Deploying the System](#)), you connect:

- The blue cable for **priv0** from embedded port **A2** on node0 to the same embedded port on node1.
- The yellow cable for A-Link1 from embedded port **A1** on node0 to the same embedded port on node1.

For network0 (ibiz0), you connect an Ethernet cable from **P1** on each node to a network that is accessible from the remote management computer. For the optional network1 (ibiz1), you can connect an Ethernet cable from **P2** on each node to the additional network.

Make any changes in your network (if necessary) in preparation for these connections. Then, perform the next step in [Deploying the System](#).

Related Topics

[Deployment](#)

[A-Link and Private Network Requirements](#)

[Business and Management Network Requirements](#)

[ztC Edge Console Requirements](#)

Mapping Your Keyboard

You can configure your keyboard for a different layout after deployment.

Supported keyboard layouts include:

Layout	Language
de	German
de-latin1	German (latin1)
de-latin1-nodeadkey	German (latin1 without dead keys)
dvorak	Dvorak
jp106	Japanese
sg	Swiss German
sg-latin1	Swiss German (latin1)
uk	United Kingdom
us	U.S. English
us-acentos	U.S. International

To configure your keyboard layout after deployment:

1. Log in to the first PM as `root`.
2. From the command line, issue the `localectl` command to configure the correct keyboard layout.
The following example configures the German keyboard layout:

```
# localectl set-keymap de
```

3. Repeat the preceding steps on the second PM, if it exists.

Related Topics

[Post-Deployment Tasks](#)

Recording the Management IP Address

Your network administrator may require the management IP address for each physical machine (PM) in order to configure the system IP address. Perform this procedure if the management network was configured to have a dynamic IP address. (Your network administrator already has this information if the management network has a static IP address.)

1. When the PM completes its installation and reboots, a screen similar to the following appears:

```
ztC Edge

IPv4 address 10.84.52.117

IPv6 address 3d00:feed:face:1083:225:64ff:fe8d:1b6e

IPv6 address fe80: :225:64ff:fe8d:1b6e
```

2. Record the IPv4 address shown on the screen.
3. Give this IP address to your network administrator.

Return to [Deploying the System](#) to continue deployment.

Related Topics

[Business and Management Network Requirements](#)

Post-Deployment Tasks

After completing system deployment, you must complete several post-deployment tasks, including:

- [Obtaining System IP Information](#)
- [Logging On to the ztC Edge Console for the First Time](#)
- [Registering the System and Acquiring a Permanent License](#)
- Configuring Required System Preferences:
 - [Configuring Date and Time](#)
 - [Configuring Remote Support Settings](#)
 - [Configuring Quorum Servers](#)
 - [Specifying Owner Information](#)

- [Configuring Active Directory](#)
- [Managing Local User Accounts](#)



Note: You must specify an email address for each user account, including **admin**, to enable the forgot password feature. If a user account does not include an email address, and the user clicks the **Forgot Password?** link on the console login page, the system sends an email to **user@example.com**. [Managing Local User Accounts](#) describes how to add users as well as how to edit user accounts, including how to add email addresses.

- [Resolving Outstanding Alerts on the Dashboard](#)
- [Connecting a Second Business Network](#)

In some situations, you may need to perform the following additional tasks:

- [Redeploying a ztC Edge System](#)
- [Adding a Node to a Single-Node System](#)

Obtaining System IP Information

After you deploy the system, you need the node0 IP address to log on to the ztC Edge Console for the first time (see [Logging On to the ztC Edge Console for the First Time](#)). To complete the initial logon procedure, you also need system IP information, which the network administrator should provide. Give the network administrator the node0 and node1 (if it exists) IP addresses (see [Recording the Management IP Address](#)), which helps the network administrator determine system IP information. The system IP address must be a static IP address. Do not use a dynamic IP address.

Related Topics

[Deployment](#)

[Post-Deployment Tasks](#)

Logging On to the ztC Edge Console for the First Time

When deploying the system, log on to the ztC Edge Console to accept the end-user license agreement (EULA) and to provide network information. You can also register the system and acquire a permanent license now, though you can do so later. When a system is first installed, it has a temporary license that expires within 30 days.

To log on to the ztC Edge Console for the first time

1. From a networked PC or laptop, type the IP address of node0 (primary) into a browser address bar (Step 5 of the [deployment guide](#) for your system).



Note: If a security message appears, proceed to the web site. You can add a security exception later, to allow the site to load without the message (see [Configuring Secure Connections](#)).

The log-on page of the ztC Edge Console appears.

2. Enter **admin** for the **Username** and **admin** for the **Password** (or other credentials, if provided), and then click **LOGIN**.

The Stratus ztC Edge END USER LICENSE AGREEMENT (EULA) appears.

3. Read the EULA and then, if appropriate, click **Accept** to accept it. If you do not accept the EULA, deployment terminates.

The **INITIAL CONFIGURATION** page appears under **Config**.

4. Under **NOTIFICATIONS**, the box for **Enable Support Notifications** is checked, by default. If you do not want the ztC Edge system to send health and status notifications to your authorized Stratus service representative, uncheck the box. You can change this setting later (see [Configuring Remote Support Settings](#)).
5. Under **SYSTEM IP**, for **Static System IP**, enter the static system IP address that you obtained from your network administrator (in the [deployment guide](#) for your system, see the **User-supplied Components** section). (The system IP address is sometimes referred to as the cluster IP address.)
6. Also under **SYSTEM IP**, select **DHCP** (the default) or **Static**. For **DHCP**, you do not need to provide additional information.

If you select **Static**, the node0 static IP address that you entered during deployment appears.

Provide the following values (in the [deployment guide](#) for your system, see the **User-supplied Components** section):

- Primary and secondary DNS
- NetMask
- Gateway address for node0

After you have entered the network information, click **Continue**. After a short delay, the **LICENSE INFORMATION** window appears.

7. You can register the system and install a permanent license now (Step 6 of the [deployment guide](#) for your system) or later. See [Registering the System and Acquiring a Permanent License](#).
8. When registration is complete, click **Finish**. The **ACCOUNT SECURITY** window appears.
9. For **New Password** in the **ACCOUNT SECURITY** window, type a new password for the user **admin**. Type the password again in **Confirm Password**. The password must conform to the password policy of the system (for information, see [Password Policy](#)).

Notes:



- You must change the password for **admin** now, for security. You can change it again later, and you should change the default user login name for the **admin** account. You make these changes on the **Users & Groups** page (see [Configuring Users and Groups](#)).
- For additional security, also change the password for **root** in the host operating system of each PM as soon as possible after deployment (see [Accessing the Host Operating System](#)).

10. Click **Finish**.

The ztC Edge Console appears and the initial logon is complete. Bookmark or otherwise make note of the system IP address for use when logging in to the console in the future.

Perform additional tasks in [Post-Deployment Tasks](#), if necessary.

Related Topics

[Deployment](#)

[ztC Edge Console](#)

[Using the ztC Edge Console](#)

Deployment Guides

[ztC Edge 100i/110i Systems: Deploying a Single-Node System](#) (R014Z)

[ztC Edge 200i/250i Systems: Deploying a Single-Node System](#) (R017Z)

Adding a Node Guides

[ztC Edge 100i/110i Systems: Adding a Node](#) (R015Z)

[ztC Edge 200i/250i Systems: Adding a Node](#) (R018Z)

Registering the System and Acquiring a Permanent License

You must register a system, which includes acquiring a permanent license. When a system is first deployed, it has a temporary license that expires within 30 days. (A temporary license is displayed as **UNREGISTERED_TRIAL** for **Asset ID** in the masthead.) You can register the system when you log on to the ztC Edge Console for the first time, or you can register it later. You can do so on a system with or without Internet access.

On a system that does not have Internet access, you need to move a file between the location of the console (which does not have Internet access) and a location with Internet access. Two methods are as follows, though other methods are possible:

- A USB flash drive—You move a USB flash drive between a management PC (which can connect to the system) and a computer with Internet access.
- A mobile device such as a laptop or smart phone—You move a mobile device between a location where you can log in to the ztC Edge Console and a location with Internet access.



Prerequisite: Before you register the system, read [To complete the registration portal steps to ensure that you have all required information.](#)

To complete the registration portal steps

Step 1: General Information—Enter the following information:

- **First Name and Last Name**
- **Company Email**—Provide the email address of the company that is the final deployment site. Do not provide a personal email address.

You also need to review and accept the **Service Terms**.

Step 2: Location Info—Enter the following information:

- **End User Company Name**—Provide the full name of the company where the system will be deployed.
- **Deployment Shipping Address**—Provide the complete address for replacement part shipments. Use the address of the company that is the final deployment site. Do not provide a PO box. Fields are:
 - **Address 1 and Address 2**
 - **City, State, Postal Code, and Country**
 - **Special Instructions** (for example, "always deliver to loading dock 2")

Step 3: Contact Details—Enter the following information:

- **Primary Technical Contact and Secondary Technical Contact**—Provide the names of the technical contacts who will be communicating with your authorized Stratus service representative.
- **Service Renewal Contact**—Provide the name of the person who is responsible for handling annual service agreement renewals.

For each contact, enter **First Name**, **Last Name**, **Email Address**, **Desk Phone**, and **Mobile (optional)**. You can add more contacts later using the **Stratus Customer Service Portal** at <https://service.stratus.com>.

After you click **Next** at the bottom of the page, Stratus verifies the information.

If there is a problem with the information, a **Problem Encountered** pane appears, which describes the problem. Click **Back** to fix the problem, if possible. If a problem still exists, click **Next** to continue, allowing you to download a file that enables you to complete registration. To help resolve the problem and ensure that your account is set up properly, your authorized Stratus service representative will contact you.

An **Information Verification** page appears, allowing you to review the information. Click **Back** to change any information. Click **Next** to submit the information and complete registration.

Step 4: License Key—For a system with Internet access, monitor the **Product License** page of the ztC Edge Console to confirm that the license automatically updates to a permanent license. For a system without Internet access, click **Download License** to download the license key file, which you will install on the ztC Edge system. Make note of the location where you download the file.

To register a system and acquire a permanent license

On a system with Internet access

1. If you are registering the system when logging on to the console for the first time, start with the next step. If you are registering the system after deployment, perform these steps:
 - a. In the ztC Edge Console, click **Preferences** in the left-hand navigation panel.
 - b. On the **Preferences** page, click **Product License**.
2. For **Online License Registration and Activation**, click **Register Online** to open a new browser tab with the Stratus registration web portal. Then, complete the [registration web portal steps](#).

At **Step 4**, monitor the **Product License** page of the ztC Edge Console to confirm that the license automatically updates to a permanent license. If needed, click **Check License Now**. When the **Status** changes to **License is activated and does not expire**, registration is complete. If the license does not update successfully within 5 minutes, click **Download License** in the registration web portal to download the license key file, and continue with the next step.

3. On the **Product License** page of the ztC Edge Console, expand **Offline License Check and Manual License Installation**.
4. Under **Install an Activated License Key to the System**, click **Choose File** and navigate to the location where you saved the file.
5. Select the file, click **Open**, and then click **Upload** to upload the file to the system. Confirm that the license updates to a permanent license. When the **Status** changes to **License is activated and does not expire**, registration is complete.

On a system without Internet access

If a system does not have Internet access, you need to move a file between the location of the ztC Edge Console (which does not have Internet access) and a location with Internet access. The procedure below describes one method, though other methods are possible.

On a computer or mobile device with access to the ztC Edge Console

1. If using a management PC, insert a USB flash drive into a USB port.
If using a mobile device, ensure that it has access to the ztC Edge Console.
2. If you are registering the system when logging on to the console for the first time, continue with the next step. If you are registering the system after deployment, perform these steps:
 - a. Log on to the ztC Edge Console.
 - b. Click **Preferences** in the left-hand navigation panel.
 - c. On the **Preferences** page, click **Product License**.
3. For Step 1, **Offline License Registration via URL File** (beneath the **Offline License Registration and Manual License Installation** bar), click **Download URL File** and save the **register_site_file.html** file to the USB flash drive or mobile device. If using a USB flash drive, remove it.
4. Go to a location with Internet access.

In a location with Internet access

1. If using a USB flash drive, insert it into a USB port of the computer with Internet access.
2. Navigate to the file you saved, and click the file name. A browser opens the file and is redirected to the Stratus registration web portal. Complete the [registration web portal steps](#).
At **Step 4**, download the permanent license key file and save it to the USB flash drive or mobile device. If using a USB flash drive, remove it.
3. Return to the location with access to the console.

On a computer or mobile device with access to the ztC Edge Console

1. If using a USB flash drive, insert it into a USB port on the management PC.
If using a mobile device, ensure that it has access to the ztC Edge Console.
2. In the console, click **Preferences** in the left-hand navigation panel.
3. On the **Preferences** page, click **Product License**.
4. For Step 2, **Install an Activated License Key to the System** (beneath the **Offline License Registration and Manual License Installation** bar), click **Choose file** and navigate to the location where you saved license key file.
5. Select the file, click **Open**, and then click **Upload** to upload the file to the system.

If you are logging on to the console for the first time, return to the final step in [Logging On to the ztC Edge Console for the First Time](#) after you have uploaded the license.

Related Topics

[Logging On to the ztC Edge Console for the First Time](#)

[Managing the Product License](#)

Redeploying a ztC Edge System

Redeploy a ztC Edge system if you already deployed and configured the system, but you need to reset its network settings to prepare it for deployment on a different network or subnet, possibly at a new location.

You typically redeploy a new ztC Edge system if you need to prepare it with settings and virtual machines (VMs) for an end user, but then you need to reset the network settings so the end user can deploy the system at their site for the first time (in a similar manner to using the Windows System Preparation Tool (*Sysprep*) to prepare a Windows system for its first end-user deployment, or Out-Of-Box Experience (OOBE)).

After configuring the system for the end user, you initiate a redeployment in the ztC Edge Console. The system subsequently clears the system and node network settings, shuts down any VMs that are running, and powers down the system. The system retains its non-network system settings and the VMs that you configured, but it is now prepared for deployment as described in the [deployment guide](#) for your system.

Notes:

When you redeploy a ztC Edge system, note the following restrictions and workarounds:

- Disable any NFS/CIFS shares before redeploying a system.

Active NFS/CIFS shares interfere with the redeployment feature. Disable the shares until you finish configuring the network settings on the new network.

- System reboot needed when setting new static system IP address.



A system loses access to the secondary node if you redeploy and shut down the system, start it up in a new location, and then configure a new static system IP address. To regain access to the secondary node, reboot the system by opening the **System** page and clicking **Reboot**. Rebooting the system refreshes the gateway settings on the secondary node and allows it to connect to the system.

- If you already moved a system to a new network, but you forgot to redeploy it first, see [KB0014252](#) for instructions on redeploying the system.
- If you need to redeploy an individual, used node as the first node in a new system, or as the secondary node in a different system, see [KB0014332](#) for instructions.

To redeploy a ztC Edge system

1. Prepare the system for the end user. Configure the ztC Edge system settings and create VMs as needed. (When you redeploy the system, only the network settings will be cleared.)
2. When you are finished preparing the system, open the **Preferences** page in the ztC Edge Console, click **IP Configuration**, and then click **Redeploy**.
3. The system clears the system and node network settings, shuts down any VMs that are running, and powers down the system.
4. The system is ready for deployment by the end user. To deploy the system, see the [deployment guide](#) for your system. (If needed, see [Deploying the System](#) for additional details.)

Related Topics

[Deployment](#)

[ztC Edge Console](#)

[Using the ztC Edge Console](#)

Deployment Guides

[ztC Edge 100i/110i Systems: Deploying a Single-Node System \(R014Z\)](#)

[ztC Edge 200i/250i Systems: Deploying a Single-Node System \(R017Z\)](#)

Adding a Node to a Single-Node System

This topic describes how to add a second node to a system to create a redundant system. It supplements information in the [adding a node guide](#) for your system. (If you need to initially deploy a system, see [Deployment](#).)

Prerequisites: To complete this procedure, you need:



- A second, factory-fresh ztC Edge node that is installed with Stratus Redundant Linux Release 2.3.0.0 or higher and matches the model of the first/running node. If you need to use a spare node that is imaged with any release prior to Release 2.3.0.0, you must exchange it for a factory-imaged Release 2.3.x.x node to support pairing with any Release 2.3.x.x primary node. Contact your authorized Stratus service representative for assistance.
- A static IP address for the second node, if you had configured the first node with a static IP address. (You can check the current network configuration on the **Preferences** page of the ztC Edge Console, under **IP Configuration**.)

To add a node

1. Confirm that the first node is running and healthy with a flashing SYS LED. On a PC or laptop with network connectivity to the first node, connect to the ztC Edge Console and confirm that the **Dashboard** page displays green check marks with no outstanding issues. Resolve any issues before adding the second node.



Note: Consider delaying the following steps until a planned maintenance period, because VM performance slows until you restart the VMs in step 6.

2. Connect the P1 port of the second node to your existing LAN, and connect the blue and yellow network cables from the first node to the second node (A2 and A1 ports). Connect the power cable to the second node and verify that the node powers on. For additional information on the network configuration, see [Connecting Ethernet Cables](#).
3. In the ztC Edge Console connected to the first node, open **Preferences**, click **Availability**, and click the + (plus sign) to add a second node. Complete the add node wizard to pair the nodes and make the system redundant. In summary:
 - a. On the **Preparation** tab, click **Continue** to search for the second node that you connected.
 - b. On the **Discovery** tab, when the wizard displays information about the newly discovered second node:
 - If the node is a compatible match for pairing, click **Continue** to begin the pairing process.
 - If the node is not a compatible match for pairing, click **Cancel**, correct any issues reported by the wizard, and restart the wizard.
 - c. On the **Pairing** tab, wait for the system to complete the pairing process.
 - d. On the **Finish** page, confirm that the nodes were successfully paired in a redundant configuration.
4. Pairing may take up to 30 minutes to complete, after which the SYS LED on the second node flashes to indicate healthy status, and the add node wizard confirms successful pairing with green check marks on each tab. Click **Close** to close the wizard and display the **Availability** page, which now indicates that the **Redundant Configuration** is **Enabled** and displays the redundant configuration.
5. In the ztC Edge Console, on the **Preferences** page, click **IP Configuration** to verify the network settings. If needed, enter a static IP address for the second node (**node1**) and click **Save**.



Note: Before pairing the nodes, you must accept the new support terms described on the **Confirming pairing and support levels** pop up. Click **Continue** to accept the terms and begin pairing.

6. Any existing VMs may synchronize for hours, after which you must restart the VMs to enable redundancy and clear warnings. For systems that support fault-tolerant (FT) operation, consider updating the Protection Level (HA/FT) setting for the VMs while they are down, as described in [Changing the Protection Level for a Virtual Machine \(HA or FT\)](#). When the system is synchronized and the VMs are running, the **Dashboard** displays green check marks with no outstanding issues.
7. If you have not already done so, register the system to obtain a permanent product license as described in [Registering the System and Acquiring a Permanent License](#).

If the system is already registered and has Internet access, it automatically updates the product license with the serial number of the second node. If the system has no Internet access, or displays an alert to perform a license check, update the license as described in [Managing the Product License](#).



Note: You will be unable to perform system software upgrades until the product license is updated.

Adding a Node Guides

[ztC Edge 100i/110i Systems: Adding a Node](#) (R015Z)

[ztC Edge 200i/250i Systems: Adding a Node](#) (R018Z)

Connecting a Second Business Network

When you deploy a ztC Edge system for the first time, you connect a network cable from the P1 port of each node to your existing network to create a shared business/management network called network0 (sometimes referred to as ibiz0).

If you want to add a second, dedicated business network (network1, sometimes referred to as ibiz1) after deployment, you can connect a network cable from the P2 port of each node to your existing network.

Adding a second business network may help to improve load balancing on a system with two or more VMs because you can assign the virtual machines (VMs) to separate business networks. Reducing the load on network0 can also help to improve performance because network0 carries management traffic as well as business traffic.

To connect a second business network

1. Connect a network cable from the **P2** port of each node to your existing network.
2. In the ztC Edge Console, go to the **Networks** page.
 - a. The new **network1** connection should appear within a minute or so.
 - b. Verify that the new **network1** connection displays a green check.
3. Use the **Reprovision Virtual Machine** wizard to enable **network1** (and possibly disable **network0**) for each VM, as needed. For more information, see [Reprovisioning Virtual Machine Resources](#).

Related Topics

[Connecting Ethernet Cables](#)

[A-Link and Private Network Requirements](#)

[Business and Management Network Requirements](#)

[General Network Requirements and Configurations](#)

3

Chapter 3: Using the ztC Edge Console

The ztC Edge Console is a browser-based interface that provides management and monitoring of an ztC Edge system from a remote management computer. For an overview of the console, see the [ztC Edge Console](#).

For information on pages within the ztC Edge Console, see the following topics:

- [Dashboard Page](#)
- [System Page](#)
- [Preferences Page](#)
- [Alerts History Page](#)
- [Audit Logs Page](#)
- [Support Logs Page](#)
- [Physical Machines Page](#)
- [Virtual Machines Page](#)
- [Volumes Page](#)
- [Networks Page](#)
- [Virtual CDs Page](#)
- [Upgrade Kits Page](#)

ztC Edge Console

The ztC Edge Console is a browser-based interface that provides management and monitoring of an ztC Edge system from a remote management computer. You can perform many administrative operations from the console because it provides access to the system as a whole as well as to physical machines (PMs), virtual machines (VMs), and other resources.

For information on the requirements of the remote management computer that runs the ztC Edge Console, see [ztC Edge Console Requirements](#).

Using the ztC Edge Console, you can perform a variety of administrative functions:

- Read system alerts from the Dashboard. See the [Dashboard Page](#).
- View VM, CPU, memory, and storage statistics, and reboot or shutdown the system from the System page. See the [System Page](#).
- Set preferences for the system, notifications (e-Alerts and SNMP configuration), and remote support (notification and access); and access administrative tools that enable you to create a secure connection. System preferences include owner information and configuration values for IP address, quorum services, date and time, etc. See the [Preferences Page](#).
- View alerts and audit logs. See the [Alerts History Page](#), the [Audit Logs Page](#), and the [Support Logs Page](#).
- Monitor, manage, and maintain resources:
 - PM status, storage (including disks), network, VMs, and USB devices: see the [Physical Machines Page](#).
 - VM status and management tasks such as creating, importing/restoring, managing, and maintaining VMs: see the [Virtual Machines Page](#).
 - Volumes, including their state, name, data synchronization status, size, state, and other information: see the [Volumes Page](#).
 - Networks, including state, link condition, name, internal name, type (for example, A-Link), VMs, speed, MAC address, and network bandwidth: see the [Networks Page](#).
 - Virtual CDs, including their state, name, size, and whether or not the VCD can be removed: see the [Virtual CDs Page](#).
- Monitor and manage upgrade kits. See the [Upgrade Kits Page](#).

You can also edit your user information (see [Editing Your User Information](#)) and configure users and groups (see [Configuring Users and Groups](#)).

Related Topics

[Logging On to the ztC Edge Console for the First Time](#)

[Logging On to the ztC Edge Console](#)

[Using the ztC Edge Console](#)

Logging On to the ztC Edge Console

Log on to the ztC Edge Console to manage the ztC Edge system. Using the console, you can manage the system, including its physical machines (PMs), virtual machines (VMs), storage, and networks. You can also view alerts and logs, and perform other administrative tasks.

Notes:



1. A login session times out after one hour, if unused.
2. The system has a limit of 10 login sessions.
3. Passwords must conform to the [Password Policy](#) of the system.
4. You can configure a login banner to provide customized content to the ztC Edge Console login page. See [Configuring the Login Banner](#).

To log on to the ztC Edge Console

1. Type the ztC Edge system's IP address or name that is a fully qualified domain name (FQDN) into a browser address bar:

`http://IP_address`

OR

`http://FQDN_name`

IP_address is the ztC Edge system's static IP address, supplied during deployment.

FQDN_name is the FQDN corresponding to that IP address.

2. When the logon page appears, enter your **Username** and **Password**.

If you have forgotten your password, click **Forgot Password?** and the **Reset Password** page appears. Enter the requested information to reset your password.



Note: Resetting a password requires that you have an email account on the system, with an email address, as configured in your local user account (see [Managing Local User Accounts](#)). If you are unable to receive email, you must contact your system administrator, who will request a password reset for you. (The system administrator needs to ask the administrator of the host OS to change the password. The host OS administrator changes the password by using commands on the primary node.)

To reset your password



Note: To receive email when resetting your password, the Mail Server must be configured. See [Configuring the Mail Server](#).

- a. When the **Reset Password** page appears, enter your **Username** and click **Continue**. An email is sent to the email address listed with your local user account. The email contains a link to a reset password page.
- b. In your email account, open the email with the reset-password link, and click the link. The **Reset Password** page re-appears.
- c. For **New Password** and **Confirm Password**, type your new password. The new password must conform to the [Password Policy](#) of the system.
Click **Continue**.
- d. A page appears, with a message that the reset was successful and that you can log in to the system with your new password. Click **Finish**.

3. Click **LOGIN**.

Password Policy

The password policy of the system requires that your password meet these conditions:

- Its minimum length is 8 characters.
- It must contain both upper- and lower-case characters.
- It cannot be the username.



Note: The interval between login attempts is 500 ms, so, after a login attempt, you must wait at least a half second to log in again.

Related Topics

[Logging On to the ztC Edge Console for the First Time](#)

[ztC Edge Console](#)

[Using the ztC Edge Console](#)

Editing Your User Information

Edit your user information (that is, your user profile) by changing your user name, email address, real name, or password.

To edit your user information

1. Click your user name in the upper right-hand corner of the console.

The **Edit User** dialog box opens.

2. Enter or modify values for the following:

- **User Name**
- **Email Address**
- **Real Name**
- **Password**



Note: Passwords must confirm to the [Password Policy](#) of the system.

- **Confirm Password**

3. Click **Save**. (Or click **Cancel** to cancel the changes.)


Related Topics

[ztC Edge Console](#)

[Using the ztC Edge Console](#)

Dashboard Page

The **Dashboard** page displays a summary of outstanding alerts on the ztC Edge system. To open this page, click **Dashboard** in the left-hand navigation panel.

To display additional information about outstanding alerts, click an alert symbol (for example, ) in the ztC Edge system diagram or click an entry in the list of alerts below the system diagram. Alert lists may appear

in tabs such as **All**, **System**, or **Ignored**, which may appear below the system diagram, depending on the alerts. The alert information includes:

- The component associated with the issue (for example, the ztC Edge system, physical machine (PM), or virtual machine (VM)).
- A description of the activity or task that requires attention.
- The reason the issue should be resolved, if available.

Resolve active alerts as soon as possible (see [Resolving Outstanding Alerts on the Dashboard](#)).

Understanding the ztC Edge System Diagram

The system diagram on the **Dashboard** page displays a graphical representation of system status. A star symbol indicates the primary PM. Alert symbols, if present, represent informational or critical alerts that require attention. Click an alert symbol to display information about the alert.

Related Topics

[Physical Machines Page](#)

[System Page](#)

[Virtual Machines Page](#)

Resolving Outstanding Alerts on the Dashboard

After completing system deployment, resolve any outstanding alerts that appear on the Dashboard page.

To resolve outstanding alerts

On the ztC Edge Console Dashboard page, view any alerts listed in the lower portion of the page. Your options are as follows:

- Resolve the alert.

For instance, if you see the message **Support Notification service should be enabled to ensure the best possible support from Stratus**, then enable support notification service.

- Click **Ignore** (beneath the **Action** column) to ignore the alert and remove it from the list. Minor alerts can be ignored rather than resolved. Clicking **Ignore** hides the alert.

To restore the ignored alert to the list, click **Ignored**, above the alerts list, and then **Restore**, under the **Action** column.

Related Topics

[Dashboard Page](#)

System Page

The **System** page displays information about the ztC Edge system, and enables you to reboot or shut down the system. The page also displays [statistics](#) and resource allocations for the ztC Edge system. To open this page, click **System** in the left-hand navigation panel.

You can use the **System** page for administrative tasks including:

- [Rebooting the System](#)
- [Shutting Down the System](#)

To power on the system (at the physical console of the PMs), see [Powering On the System](#).

You perform many other administrative tasks on the ztC Edge system using the ztC Edge Console. For information, see the [ztC Edge Console](#).

Viewing statistics

The **System** page contains these sections, which display information and statistics of system usage as well as of PMs and VMs:

- **system name**—Circle graphs indicate the system's CPU allocation, memory allocation, disk (R/W), and network utilization.
- **Node0** and **Node1** (if it exists)—Circle graphs indicate each node's CPU utilization, memory utilization, disk utilization, and network utilization. For disk utilization and network utilization, you can select the logical disk or the network whose statistics you want to display.

Related Topics

[Using the ztC Edge Console](#)

Powering On the System

Power on the ztC Edge system at the physical console of each physical machine (PM), or node. Doing so performs an orderly startup by first booting the system software and then starting the virtual machines (VMs) on the system. (To power off a system, see [Shutting Down the System](#).)



Caution: If you are powering on the system for the first time to deploy it, follow the instructions in the deployment guide for your system. (If needed, see [Deploying the System](#) for additional details.)



Note: If a PM loses power because you disconnect the power cord or AC mains power is lost, each PM in a dual-node system, and the one PM in a single-node system, is set to power on automatically as soon as power is restored. The system software and VMs restart automatically.

To power on a ztC Edge system

1. Ensure that all the required network cables are connected. In a dual-node system, check that the network cables are connected to both PMs.
2. Press the power button on the front panel of the PM(s) in the system.
3. Ensure that the **PWR** LED or power button on the front panel of the PM(s) is lit.

Related Topics

[ztC Edge Console](#)

[System Page](#)

[Using the ztC Edge Console](#)

Rebooting the System

Reboot the ztC Edge system using the ztC Edge Console to safely restart both PMs without affecting VMs. On a single-node system, reboot the system only during a planned maintenance period, since the Virtual Machines are shut down and restarted during the reboot.



Caution: Rebooting the ztC Edge system by any method other than following (for example, rebooting from the PMs individually) may result in data loss.



Note: You can reboot a system configured with two PMs only if both PMs are running, healthy, and not in maintenance mode. You can reboot a system configured with one PM only if the PM is running, healthy, and not in maintenance mode.



Prerequisite: On a system configured with two PMs, confirm that both PMs are running before rebooting. On a single-node system, confirm that the one PM is running before rebooting.

To reboot the ztC Edge system

1. Select **System** in the left-hand navigation panel.
2. Click the **Reboot** button. A message appears, asking you to confirm the reboot. Click **Yes** to continue.

Rebooting can take up to 15 minutes. You can observe the process in the **Dashboard** and the masthead of the ztC Edge Console. The system's PMs sequentially enter and then exit maintenance mode (for information on maintenance mode, see [Maintenance Mode](#)).

3. Verify that the PMs restart and that all VMs continue running as expected.

After you initiate a reboot, a message in the masthead shows the status of the reboot. If necessary, you can cancel the reboot by clicking **Cancel Reboot** in the masthead.



Caution: If you cancel a reboot, the system is left in its current state and you need to manually restore it to a healthy state.

Related Topics

[ztC Edge Console](#)

[System Page](#)

[Using the ztC Edge Console](#)

Shutting Down the System

Use the ztC Edge Console to shut down the ztC Edge system. Doing so performs an orderly shutdown by first shutting down the virtual machines (VMs) and then the physical machines (PMs). Use only this method to shutdown the ztC Edge system. Before shutting down, make sure both PMs of a system configured with two nodes are running, or the one PM of a system configured with one node is running.

Cautions:



1. Shutting down the ztC Edge system takes the VMs offline, so shutdown the system only during a planned maintenance period.
2. Shutting down the ztC Edge system by any other method (for example, removing power from both PMs individually) may result in data loss.



Note: When you shut down the system, standby power remains on for lights-out management unless you disconnect the power cord or the AC mains power is switched off.

To shut down the ztC Edge system

1. On systems configured with two nodes, confirm that both PMs are running so that the disks can synchronize between nodes.
2. Select **System** in the left-hand navigation panel.
3. Click the **Shutdown** button. A warning appears: *It will shut down the entire system and stop one or more VMs!* Click **Yes** to shutdown or **No** to cancel the shutdown. After clicking **Yes**, a second warning appears, asking you to confirm the shutdown. Click **Yes** (again) to shutdown or **No** to cancel the shutdown.

You can observe some of the shutdown process in the **Dashboard** and the masthead of the ztC Edge Console as the system's PMs sequentially enter maintenance mode (for information on maintenance mode, see [Maintenance Mode](#)). When the system shuts down completely, though, the ztC Edge Console is unavailable and the masthead displays **Lost Communication**.

After the system shuts down, you lose the connection to the console. If the ztC Edge system cannot shutdown completely, a VM may not be shutting down properly. Do one of the following to shut down the VM:

- Use the VM console or a remote desktop application to log on to the VM. Use operating system commands to shut down the VM.
- Log on to the ztC Edge Console. Click **Virtual Machines** in the left-hand navigation panel, select the VM, and then click **Power Off**.

Related Topics

[Managing the Operation of a Virtual Machine](#)

[ztC Edge Console](#)

[System Page](#)

[Using the ztC Edge Console](#)

Preferences Page

The **Preferences** page enables you to configure ztC Edge system settings. To open this page, click **Preferences** in the left-hand navigation panel.

The following table lists and describes the preferences.

Preference	Description
System	
Owner Information	Allows you to specify and then view the name and contact information for an ztC Edge system administrator. This information is also provided in response to Simple Network Management Protocol (SNMP) requests. See Specifying Owner Information .
Product License	Allows you to view and manage the ztC Edge product license. See Managing the Product License .
Software Updates	Allows you to check the current version of the system software and whether or not a new version is available. If a new version is available, you can download it and read the Release Notes. You can also specify that alerts be sent when an update is available and that an available update be downloaded automatically. See Managing Software Updates .
IP Configuration	Allows you to view and specify the Internet Protocol (IP) address and network settings for the system; and to redeploy a system. See Configuring IP Settings .
Availability	Allows you to view the redundant configuration of your system, and optionally deploy a second node to improve availability. See Configuring Availability

Preference	Description
	Settings .
Quorum Servers	Allows you to view existing and new Quorum servers. Quorum servers provide data integrity assurances and automatic restart capabilities for specific failures in the ztC Edge environment. See Quorum Servers and Configuring Quorum Servers .
Date & Time	Allows you to view the system time, specify values for Network Time Protocol (NTP) (recommended), or to manually set the time and date on the system. See Configuring Date and Time .
Mail Server	Allows you to configure the mail server to enable the ztC Edge system to send email when, for example, someone needs to reset a password. See Configuring the Mail Server .
Administrative Tools	
Users & Groups	Allows you to add, modify, or remove user accounts on the ztC Edge system; to enable Active Directory (and then grant to it), and to select a user and view the time when the user's password was last updated. An administrator can also use the page to force a selected user to change the user's password on the next login. See Configuring Users and Groups .
Secure Connection	Allows you to enable only HTTPS connections to the system. See Configuring Secure Connections .
VM Device Configuration	Allows you to disable or enable insertion of virtual CDs (VCDs) in all VMs or attachment of USB devices to all VMs. See Configuring VM Devices .
IPtables Security	Allows you to manage IP packet filtering using the administrative tool IPtables. See Managing IPtables .
Login Banner Notice	Allows you to configure a login banner. See Configuring the Login Banner .
ztC Advisor	Allows you to enable ztC Advisor to allow administrators to remotely monitor

Preference	Description
	the system's health in the ztC Advisor dashboard. See Enabling ztC Advisor .
Save Preferences	Allows you to save Preferences -page settings to a file on a local computer or in the Stratus Cloud [®] service. See Saving and Restoring System Preferences .
Restore Preferences	Allows you to restore Preferences -page settings from a backup file. See Saving and Restoring System Preferences .
Notification	
e-Alerts	Allows you to enable email alerts (e-Alerts) for system administrators. See Configuring e-Alerts .
SNMP Configuration	Allows you to enable Simple Network Management Protocol (SNMP) requests and traps for remote system monitoring. See Configuring SNMP Settings .
OPC Configuration	Allows you to configure Open Platform Communication (OPC) settings to enable OPC server functionality, which allows you to monitor the ztC Edge system alongside other industrial equipment. See Configuring OPC Settings .
Remote Support	
Support Configuration	Allows you to configure remote access and notifications. Remote access enables your authorized Stratus service representative to log on to the system remotely for troubleshooting. When enabled, the ztC Edge system can send notifications to your authorized Stratus service representative about problems with the system. See Configuring Remote Support Settings .
Proxy Configuration	Allows you to configure proxy settings for the ztC Edge system if your organization requires a proxy server to access the Internet and you have a service agreement with Stratus or another authorized ztC Edge service representative. The Stratus Redundant Linux software uses proxy server information for support notification messaging and remote support access features. See Configuring Internet Proxy Settings .

Related Topics

[ztC Edge Console](#)

[Using the ztC Edge Console](#)

Specifying Owner Information

Specify the name and contact information for an administrator or owner of the ztC Edge system to make this information available for support purposes.

This contact information is available in the ztC Edge Console and provided in response to Simple Network Management Protocol (SNMP) requests.

To specify system owner information

1. Click **Preferences** in the left-hand pane.
2. On the **Preferences** page, click **Owner Information**.
3. Supply information in the **Full Name**, **Phone Number**, **Email**, and **Site Address** fields.
4. Click **Save**.

Related Topics

[Preferences Page](#)

[ztC Edge Console](#)

Managing the Product License

Manage the product license for the system by:

- Acquiring a permanent license during or after deployment.
- [Checking the status of an existing license, which updates it, if necessary.](#)
- Viewing current license information such as status and expiration date.

When a system is first installed, it has a temporary license that expires within 30 days. (A temporary license is displayed as **UNREGISTERED_TRIAL** for **Asset ID** in the masthead.) You must register the system, which includes acquiring a permanent license. You can register the system immediately after the initial deployment or later. For information on registering the system, see [Registering the System and Acquiring a Permanent License](#).

Once a system has a permanent license, it checks with the license server for updates every 24 hours, if the system has an Internet connection. If a system does not have Internet access, you can still update the license and check its status. To do so, you need to move a file between the location of the ztC Edge Console (which does not have Internet access) and a location with Internet access. Two methods are as follows, though other methods are possible:

- A USB flash drive—You move a USB flash drive between a management PC (which can connect to the system) and a computer with Internet access.
- A mobile device such as a laptop or smart phone—You move a mobile device between a location where you can log in to the ztC Edge Console and a location with Internet access.

Choose the menu below (click drop-down, if applicable) for the procedure that is appropriate for your needs.

To check the status of a license

If the system has Internet access, use the following procedure. This procedure also automatically updates the license, if necessary. If the system does not have Internet access, use the [On a system without Internet access](#) procedure. If you need to update a license manually, see [To update a new license manually](#).

1. In the ztC Edge Console, click **asset_ID** (of **Asset ID: asset_ID**) in the masthead.

Alternatively, on a registered system, click **Preferences** in the left-hand navigation panel of the console, and then:

- a. On the **Preferences** page, click **Product License**.
- b. For **Online License Check**, click **Check License Now**.

2. The console displays the status of the license (date format varies, based on location):

STATUS	License is activated and does not expire.
LAST CHECK	<i>day, month dd, 20yy, time</i>
SERVICE EXPIRATION	<i>day, month dd, 20yy, time</i>
ASSET ID	<i>asset_ID</i>
PRODUCT UUID	<i>xxxxxxxx-xxxx-xxxx-xxxx-xxxxxxxxxxxx</i>
FT Enabled	<i>Yes_or_No</i>

ALSR Allowed	<i>Yes_or_No</i>
Guest Monitoring Allowed	<i>Yes_or_No</i>
Save/Restore Sys Preferences Allowed	<i>Yes_or_No</i>
Save/Restore Sys Preferences Expire	<i>day, month dd, 20yy, time_or_ Never Licensed</i>

To update a new license manually for a registered system

On a registered system with an Internet connection, the license is updated automatically. You can also, if necessary, update a license manually.

On a system with Internet access

1. In the console, click **Preferences** in the left-hand navigation panel.
2. On the **Preferences** page, click **Product License**.
3. Click the **Offline License Check and Manual License Installation** bar to display its options, if they are not already displayed.
4. Under **Offline License Check via URL File**, click **Download URL File** and save the file.
5. Click the file name. A web browser opens and the Stratus license server checks the status of the license file. If necessary, a new license .key file is automatically downloaded.
6. Then, click **Upload**.

On a system without Internet access

Use the procedure below to check a license and, if necessary, acquire a new license manually on a registered system that does not have Internet access. You need to move a file between the location of the ztC Edge Console (which does not have Internet access) and a location with Internet access. The procedure below describes one method, though other methods are possible.

On a computer or mobile device with access to the ztC Edge Console

1. If using a management PC, insert a USB flash drive into a USB port.
If using a mobile device, ensure that it has access to the ztC Edge Console.
2. Log on to the ztC Edge Console.
3. Click **Preferences** in the left-hand navigation panel.
4. On the **Preferences** page, click **Product License**.

5. Click the **Offline License Check and Manual License Installation** bar to display its options, if they are not already displayed.
6. Under **Offline License Check via URL File**, click **Download URL File** and save the file to your mobile device or USB flash drive. If using a USB flash drive, remove it. Go to a location with Internet access.

In a location with Internet access

1. If using a USB flash drive, insert it into a USB port of the computer with Internet access.
2. Navigate to the file you saved, and click the file name.
3. A web browser opens and the Stratus license server checks the status of the license file. If necessary, a new license .key file is automatically downloaded. If using a USB flash drive, copy the new license .key file to it, and then remove the USB flash drive.
4. Return to the location with access to the console.

On a computer or mobile device with access to the ztC Edge Console

1. If using a USB flash drive, insert it into a USB port on the management PC.
If using a mobile device, ensure that it has access to the ztC Edge Console.
2. In the console, click **Preferences** in the left-hand navigation panel.
3. On the **Preferences** page, click **Product License**.
4. Click the **Offline License Check and Manual License Installation** bar to display its options, if they are not already displayed.
5. For **Install an Activated License Key to the System**, click **Choose File** and navigate to the location where you saved the file.
6. Select the file, click **Open**, and then click **Upload** to upload the file to the system.

Related Topics

[ztC Edge Console](#)

[Preferences Page](#)

[Using the ztC Edge Console](#)

Managing Software Updates

You can manage software updates by checking the current version number of the system software and by checking if a software update is available. You can also, optionally, enable the following:

- A message to be sent to the **Alert History** page when a system software update is available.
- An email alert (e-Alert) to be sent to a system administrator when a system software update is available.
- The system to download (though not install) the update automatically.

If you configure the system to automatically check for updates, the system checks once per day, around midnight local time. When an update is available, the system downloads it to a staging area on the system, shortly after checking for the updated software. If the download to the staging area succeeds and if configured to do so, the system sends a message to the **Alert History** page and/or an e-alert stating that the software is ready for installation. If the download fails, the update is removed.



Prerequisite: If you want system administrators to receive an e-Alert when an update is available, you must configure the mail server and e-Alerts, if these are not already configured. See [Configuring the Mail Server](#) and [Configuring e-Alerts](#).

To manage software updates

1. Click **Preferences** in the left-hand navigation panel, to open the **Preferences** page.
2. On the **Preferences** page, click **Software Updates** (under **System**).
3. **Available System Software Updates** appears with the following information:
 - The version number of the current system software.
 - The version number of a new version of system software, if available.

If a new version of the system software is available, click one or both of the following links, as appropriate for your needs:

- **Download Software**—Click this link to download the available version.
 - **View Release Notes**—Click this link to view the Release Notes as well as the entire user guide for the available version.
4. **Manage System Software Updates** appears with the following options:

- **Alert me when a System Software Update is available**—Select this option if you want a message that an update is available sent to the **Alert History** page. If you want an email sent to system administrators, informing them when an update is available, you must configure e-Alerts.
- **Automatically download System Software Updates when they become available.**
(Downloaded to the system only, NOT installed)—Select this option if you want the system to download a new system software update automatically when it is available. After the software is downloaded, it is available as an upgrade kit on the **Upgrade Kits** page and you can install the software. For additional information, see the [Upgrade Kits Page](#) and [Upgrading Stratus Redundant Linux Software Using an Upgrade Kit](#).

5. Click **Save**.

Related Topics

[Alerts History Page](#)

Configuring IP Settings

Configure Internet Protocol (IP) settings for the ztC Edge system to set or modify the IP address of the system and nodes as well as values for applicable settings such as network mask, gateway address, and Domain Name System (DNS) server. (You also modify network settings when redeploying a system using the **Redeploy** button, as described in [Redeploying a ztC Edge System](#).)

During deployment and post-deployment, you configure IP addresses for the system. For a system configured with two nodes, you configure three IP addresses: one for the system and one for each node (node0 and node1). For a system configured with one node, you configure two IP addresses: one for the system and one for the node (node0). You can change the IP addresses and other IP settings after deployment using the appropriate procedure below. You must specify a static IPv4 address for the ztC Edge system.

Warnings:

1. Do not change the IP configuration settings, especially on systems with running VMs, without the advice and knowledge of your network administrator. Doing so could make the system and all its VMs inaccessible.
2. If you change the **Static System IP** address, any MAC addresses automatically assigned to the VMs will change when the VMs reboot, because the Stratus Redundant Linux software generates MAC addresses for the VMs based on the system IP address. To prevent changes to the MAC address for a VM (for example, to support software applications that are licensed on a MAC-address basis), set a persistent MAC address as described in [Assigning a Specific MAC Address to a Virtual Machine](#).
3. You must use the ztC Edge Console to change IP addresses. Do not use Linux tools.

Notes:

1. The procedure you use to configure IP settings depends on whether the ztC Edge system stays on the same subnet or moves to a new subnet. If you need to move a ztC Edge system to a new subnet, *redeploy* the system to clear its network settings before moving it, as described in [Redeploying a ztC Edge System](#).
2. Changing IP settings for a new subnet typically includes changing the node's physical network connections (for example, disconnecting and then re-attaching network cables if moving the PMs). Before you disconnect cables from nodes, you must shut down the nodes. For this, you have the option of using the **Save and Shutdown** button in the **IP Configuration** section of the **Preferences** page.
3. In a system configured with one node, the **IP Configuration** page displays settings for only one node.

To change the system and/or node IP settings with the system on same subnet

The ztC Edge system and all virtual machines (VMs) continue to run throughout this procedure; however, the ztC Edge Console briefly loses its connection to the system if you change the system IP address. You can access the ztC Edge Console at the new system IP address within 1-2 minutes. (You can change node IP addresses on each node, individually, but the console connection is not lost.)

1. Click **Preferences** in the left-hand navigation panel, to open the **Preference** page.
2. Click **IP Configuration**.
3. In the **Static System IP** box, type the static system IP address that you obtained from your network administrator.
4. Click the **Static** button and type valid, unique values for **Primary DNS** and **Secondary DNS**.
5. Verify that the displayed **NetMask** value is correct.
6. For **Node0** and **Node1** (if it exists), enter appropriate values for **IP Address** and **Gateway IP**.
7. Click **Save** to save the values (or click **Reset** to restore previous values).

If you have changed the system IP address, the **System IP has been updated** message box appears. After a brief delay, the browser redirects automatically to the new system IP address.

Related Topics

[Deployment](#)

[Obtaining System IP Information](#)

[Logging On to the ztC Edge Console for the First Time](#)

[Preferences Page](#)

[ztC Edge Console](#)

[Using the ztC Edge Console](#)

Configuring Availability Settings

Use the **Availability** page to view the redundant configuration of your system, and optionally deploy a second node to improve availability.

The **Availability** page displays the current **Redundant Configuration** of your system:

- **Enabled** – Both nodes are online; the system is redundant. If one of the nodes fails or is taken offline, the virtual machines (VMs) will automatically fail over to the healthy node. (For an overview of the levels of availability and failover on ztC Edge systems, see [Modes of Operation](#).)
- **Disabled** – Only one node is configured; the system is not redundant. If the node fails or is taken offline, the VMs will be unavailable. To make the system redundant and improve availability, add a second node.

The **Availability** page also displays information about each node in your system. If only one node is present, you can click the + (plus sign) to add a second node for redundancy. For more information, see the adding a node guide for your system (or [Adding a Node to a Single-Node System](#)).

Adding a Node Guides

[ztC Edge 100i/110i Systems: Adding a Node](#) (R015Z)

[ztC Edge 200i/250i Systems: Adding a Node](#) (R018Z)

Related Topics

[Preferences Page](#)

[ztC Edge Console](#)

[Using the ztC Edge Console](#)

Configuring Quorum Servers

When you log on to the ztC Edge system for the first time, configure quorum servers.

Prerequisites:



1. You must have a system configured with two nodes in order to configure a quorum server.
2. Before you configure quorum servers, read [Quorum Servers](#) and [Creating an ALSR Configuration](#) (which discusses quorum servers).

Notes:



1. For a VM to recognize quorum server configuration changes, you must reboot the VM by shutting it down and then restarting it. See [Shutting Down a Virtual Machine](#) and [Starting a Virtual Machine](#).
2. Windows Updates on a quorum server can interrupt the server's operation, which affects fault-recovery behavior. On quorum servers, you should schedule Windows Updates during a maintenance period or disable Windows Updates.

To configure quorum servers

1. Click **Preferences** in the left-hand navigation panel, to open the **Preferences** page.
2. Click **Quorum Servers**.

3. Click **Add Quorum Server**.
4. In the **Add Preferred Quorum Server** dialog box, enter the following values (if a preferred quorum server already exists, the **Add Alternate Quorum Server** dialog box appears):
 - **DNS or IP Address**—Type the fully-qualified **DNS** host name or **IP address** for the preferred quorum server.
 - **Port** (the default value is 4557)—Type the port number if it is different from the default.

Click **Save** to save the values.

5. Repeat steps 4 and 5 to configure a second, alternate quorum server. Stratus recommends configuring two quorum servers.
6. To enable quorum service, select the **Enabled** check box and click **Save**.

To remove a quorum server



Caution: If you remove the preferred quorum server, the alternate quorum server becomes the preferred quorum server. If no alternate quorum server exists, removing the preferred quorum server automatically disables quorum service.

1. Navigate to the **Preferences** page of the ztC Edge Console.
2. Click **Quorum Servers**.
3. Locate the entry for the quorum server you want to remove.
4. In the right-most column, click **Remove**.



Note: If a VM is using the quorum server that you are removing, you must reboot the VM so that it no longer recognizes the quorum server, which allows the removal process to finish.

Related Topics

[ztC Edge Console](#)

[Preferences Page](#)

[Using the ztC Edge Console](#)

Configuring Date and Time

When you log on to the ztC Edge system for the first time, configure the date and time to enable the Network Time Protocol (NTP) service. Using the NTP service automatically sets the system clock and ensures that it does not drift from the actual time.



Caution: When you change the date and time settings, the primary physical machine (PMs) may reboot and the secondary PM (if it exists) may shutdown if system time has drifted from actual time. All virtual machines (VMs) are stopped and business processing is interrupted until the reboot is complete.



Note: The clock swaps between time zones whenever VMs migrate or restart. To ensure that the time zone in VMs does not change:

- Set the time zone in all VMs to correspond to the time zone configured for the ztC Edge system.
- Configure all VMs to use the same NTP servers as those configured for the ztC Edge system.

To configure date and time settings

1. Click **Preferences** in the left-hand navigation panel, to open the **Preferences** page.
2. On the **Preferences** page, click **Date & Time**.
3. In the **Date & Time** display, the default setting for **Configure Time Zone** is **America, New York**. Select a time zone appropriate for your location, if necessary.
4. Select one of the following for **Configure Date and Time**:
 - **Automatically (recommended)** enables NTP service. Type NTP server addresses in the text area, one per line. Specifying multiple NTP servers provides redundancy.
 - **Manually** allows you to manually enter settings.



Note: If you configure time manually, the ztC Edge system's time may drift from actual time.

5. Click **Save** (or click **Reset** to restore the previously-saved values).

If the system requires a reboot because of time drift, a message appears in the ztC Edge Console masthead telling you that the system will reboot. In this case, the primary physical machine (PM) reboots and the secondary PM (if it exists) shuts down. While the primary PM reboots, you lose your connection to the ztC Edge Console. When the reboot is complete, the PM re-establishes a connection to the console and you receive an alert telling you to restart the secondary PM.

Related Topics

[ztC Edge Console](#)

[Preferences Page](#)

[Using the ztC Edge Console](#)

Configuring the Mail Server

Configure the mail server to enable the ztC Edge system to send email when, for example, someone needs to reset a password.

To configure the mail server



Note: If you change any Mail Server settings, you *must* re-enter the mail-server password if authentication is enabled.

1. Click **Preferences** in the left-hand navigation panel, to open the **Preference** page.
2. Under **System**, click **Mail Server**.
3. Click the **Enable Mail Server** box. Boxes for specifying or selecting the following settings appear:
 - **SMTP Server** (required)—Enter the name of the Simple Mail Transfer Protocol (SMTP) server that your company uses to send email.
 - **Port Number** (optional)—Enter the port number to use when sending e-Alerts. If no port number is specified, the default SMTP port 25 will be used. (For additional information on all ports, including the SMTP port, access the Knowledge Base to search for the article *TCP and UDP ports used by ztC Edge* (KB0014311). See [Accessing Knowledge Base Articles](#).)
 - **Sender's Email Address**—Enable e-Alert delivery by specifying a valid sender's email address in either of the following cases:
 - You have not specified a DNS server on the ztC Edge system **and** your SMTP server is not configured to accept domain literals (From addresses in the form

noreply@IP_address).

- You want the e-Alert to provide a different sender's email address (for example, noreply@company.com).

Any email address that the SMTP server accepts is sufficient.

- **Encrypted Connection**—Select a value from the pull-down menu for the encryption protocol that the SMTP server requires:
 - **None** for no encryption. By default, port number 25 is used.
 - **TLS** for the Transport Layer Security (TLS) protocol. For TLS, Stratus recommends that you specify 587 for **Port Number**, though 25 is used by default.
 - **SSL** for the Secure Sockets Layer (SSL) protocol. For SSL, Stratus recommends that you specify 465 for **Port Number**, though 25 is used by default.
- **Enable Authentication**—Click this box if the SMTP server requires authentication to send email. Then, type the **Username** and **Password** for the SMTP account.



Note: If authentication is enabled (because the **Enable Authentication** box is already checked or because you have just checked it) and you change any Mail Server settings, you *must* re-enter the mail-server password.

4. Click **Save** (or click **Reset** to restore the previously-saved values).

Related Topics

[ztC Edge Console](#)

[Preferences Page](#)

[Using the ztC Edge Console](#)

Configuring Users and Groups

Use the **Users & Groups** page to add, modify, or remove user accounts on the ztC Edge system, or to grant access for Active Directory users. You can select a user and view the time when the user's password was last updated. An administrator can also use the page to force a selected user to change the user's password on the next login.

To open this page, click **Preferences** in the left-hand navigation panel and then on the **Preferences** page, select **Users & Groups** under **Administrative Tools**.

To manage local user accounts

To add a new user, click **Add** in the lower pane. To modify an existing user, click the name of a user account and click **Edit** or **Remove**.

To view the time when a user last changed the user's password, look at the **Last Password Update Time** column for a selected user. To force a user to change the user's password on the next login, an administrator selects the user and then clicks **Expire Password**.

For more information, see [Managing Local User Accounts](#).

To manage domain user accounts

For information about enabling the Active Directory service on your ztC Edge system, see [Configuring Active Directory](#). To grant or remove access for domain users to manage the ztC Edge system, see [Managing Domain User Accounts](#).



Note: If you are logged on as administrator to a system that has Active Directory users or groups configured, the **Grant Access** button will appear in the upper-right corner of the **Users & Groups** page. Clicking the **Grant Access** button launches the Grant Access wizard. The [Managing Domain User Accounts](#) topic discusses using the Grant Access wizard.

To sort and locate user accounts

If you have a large number of accounts, you can click a column heading to sort the accounts by parameter. You can sort accounts by **Type**, **Username**, **Real Name**, **Email** address, or **Role**.

Related Topics

[Managing Domain User Accounts](#)

[Managing Local User Accounts](#)

[Configuring Active Directory](#)

[Security Hardening](#)

Managing Local User Accounts

You add, edit, or remove users, specify passwords, and assign user roles to local-user accounts on the **User & Groups** page in the ztC Edge Console. You can also select a user and view the time when the user's password was last updated, and an administrator can force a selected user to change the user's

password on the next login. You can assign a user who is not an administrator the task (or privilege) *Join a computer to the domain*. (To grant or deny access for established user accounts in an Active Directory domain, see [Managing Domain User Accounts](#).)

Local user accounts reside on the ztC Edge system itself, as opposed to a central domain server. You can find local accounts on the **Users & Groups** page by looking for entries labeled **Local User** in the **Type** column.

User roles are:

- **Administrator**: full system administrator privileges
- **Platform Manager**: system administrator privileges except for adding, removing, and modifying users
- **VM Manager**: ability to manage VMs (see [Managing Virtual Machines](#) for detailed information)
- **Read-only**: ability to view but not to change system configuration or to install system software

For the procedures below, begin by opening the **Users & Groups** page: click **Preferences** in the left-hand navigation panel to open the **Preferences** page, and then, under Administrative Tools, select **Users & Groups**.

To add a user account

1. In the lower pane, click **Add**.
2. In the **Role** drop-down window, select **Administrator**, **Platform Manager**, **VM Manager**, or **Read-only**.
3. Provide values for the **User Name**, **Password** (and **Confirm Password**), **Email Address**, and **Real Name** fields. User names may be from 1 to 64 characters long, and must include no white space. Passwords must conform to the [Password Policy](#) of the system.
4. Click **Save**.

To edit a user account

1. Select the account you want to edit.
2. In the lower pane, click **Edit**.
3. Change the user's information, as necessary. For example, to change a user's role, in the **Role** drop-down window, select **Administrator**, **Platform Manager**, **VM Manager**, or **Read-only**.

4. Click **Save**.

To force a user to change the user's password

1. Select the user whose password you want to expire.
2. Click **Expire Password**.
3. Click **Yes** in the Confirm dialog box.

To assign "Join a computer to the domain" to a non-administrator

1. Add a user who is not an administrator to the AD server, and delegate to the user the task (or privilege) **Join a computer to the domain**. For details, see the documentation for the AD server.
2. On the ztC Edge system, edit the `/etc/resolv.conf` file to add the IP address of the AD domain controller. The following line is an example:

```
nameserver 123.456.28.910
```
3. In the ztC Edge Console, enable AD if it is not already enabled. See [Configuring Active Directory](#).

To remove a user account

1. Select the account to remove.
2. Click **Remove** in the lower pane.
3. Click **Yes** in the Confirm dialog box.

Notes:

1. You cannot delete the default **admin** account, although you should change its name and password by editing the account.
2. You must specify an email address for each user account, including **admin**, to enable the forgot password feature. If a user account does not include an email address, and the user clicks the **Forgot Password?** link on the console login page, the system sends an email to **user@example.com**.

Related Topics

[Configuring Active Directory](#)

[Managing Domain User Accounts](#)

[Configuring Users and Groups](#)

Managing Domain User Accounts

You can grant Active Directory (AD) domain user accounts access to the ztC Edge Console. Domain user accounts are managed on a central AD domain server, as opposed to the local ztC Edge system.

After granting access to domain accounts, you can use the Grant Access wizard (on the Users & Groups page) to view, manage, and sort the AD accounts that have access to the system.



Prerequisites: You must add the ztC Edge system to an Active Directory domain before you can manage domain accounts. (See [Configuring Active Directory](#).) If Active Directory is not configured, or if the user who is logged onto the interface does not have administrator privileges, the Grant Access button is grayed out on the Users & Groups page.

For the procedures below, open the **ztC Edge - Grant Access Wizard**:

1. In the left-hand navigation panel, click **Preferences** to open the **Preferences** page.
2. Under Administrative Tools, select **Users & Groups**.
3. Click **Grant Access**.

To grant access to a domain user account

1. In the **ztC Edge - Grant Access Wizard**, specify the search range in the **Search for** menu.
2. Type the name or group for which to search. Partial names and text are allowed.
3. Click **Search**.
4. Click the green plus sign (+) next to the users or groups you want to add as ztC Edge Console Global Users or Groups of the system.
5. Use the drop-down menus in the Role column to assign a role to the user or group to which you have just granted access. You can assign the following roles:
 - **Administrator** –Enables performance of the full range of system administration activities.

- **Platform Admin**—Enables Administrator privileges, except for managing user accounts.
- **VM Manager**—Enables ability to manage VMs (see [Managing Virtual Machines](#) for detailed information)
- **Read Only**—Enables read access but no management functions.

6. Click **Finish**. The new domain users are displayed in the Grant Access wizard.

To remove access for a domain user account

1. In the **ztC Edge - Grant Access Wizard**, click the check box next to users or groups you want to remove.
2. Click **Deny Access**, then click **Finish**.

Related Topic

[Configuring Active Directory](#)

Configuring Active Directory

Configure Active Directory for the ztC Edge system to authorize existing users or groups from an Active Directory domain to log on to the ztC Edge Console with their Active Directory credentials.

*After you add the ztC Edge system to an Active Directory domain, you can assign administrative privileges to domain users using the **Grant Access** wizard, which you start from the **Users & Groups** page (see [Configuring Users and Groups](#)).*

To add the ztC Edge system to an Active Directory domain

1. Click **Preferences** in the left-hand navigation panel, to open the **Preferences** page.
2. Click **Users & Groups**.
3. Click the **Enable Active Directory** button in the lower pane.
4. Next to **Active Directory Domain**, type the name of the domain to use.
5. Click one of the following to prevent or allow automatic assignment of the "Everyone" role:
 - **Prevent all AD users from being automatically assigned the "Everyone" role** (the default).
 - **Allow all AD users to authenticate and be authorized for "Everyone" role access.**
6. Click **Add System to Active Directory**.

7. Type the **Username** and **Password** of an Active Directory Administrator in order to add this ztC Edge system to the domain.
8. Click **Add**.
9. Assign administrative privileges to domain users on the **Users & Groups** page, as described in [Managing Domain User Accounts](#).

To remove an ztC Edge system from an Active Directory domain

1. In the ztC Edge Console, click **Preferences** in the left panel, to open the **Preferences** page.
2. Click **Users & Groups**.
3. Click **Remove System from Active Directory** in the lower pane.
4. Type a **Username** and **Password** that provides you with administrative privileges within the domain.
5. Click **Remove**.

To disable domain authentication

1. In the ztC Edge Console, click **Preferences** in the left panel, to open the **Preferences** page.
2. Click **Users & Groups**.
3. Click **Disable Active Directory** in the lower pane.



Note: Disabling Active Directory prevents the use of domain authentication for authorizing administrators of the ztC Edge system; however, it does not remove the system from the domain. To restore the use of domain authentication, click **Enable Active Directory**. You do not need to retype the name of the controller or restore domain users on the **Users & Groups** page.

Related Topics

[Configuring Users and Groups](#)

[Managing Domain User Accounts](#)

[Managing Local User Accounts](#)

[Preferences Page](#)

[ztC Edge Console](#)

[Security Hardening](#)

Configuring Secure Connections

For security, the ztC Edge system allows only HTTPS connections, by default. If you want to allow HTTP connections, you can configure secure connections.

Note:



When you activate or deactivate the check box next to **Enable HTTPS Only / Disable HTTP** in the procedure below and click **Save**, the system automatically logs you out of the ztC Edge Console and you must log in again,

When HTTPS connections are enabled, you can use a script to install a custom certificate into the CA bundle on the host machine. See [To install a custom certificate into the CA bundle](#).

To enable HTTP and HTTPS connections

1. Click **Preferences** in the left-hand navigation panel, to open the **Preferences** page.
2. Under **Administrative Tools**, click **Secure Connection**.
3. Deactivate the check box next to **Enable HTTPS Only / Disable HTTP**.
4. Click **Save**.

The system automatically logs you out of the ztC Edge Console and redirects the browser to the HTTPS login page. To access the HTTP login page, you manually replace **https** with **http** in the browser's address bar, and then you can log in.

If the system allows HTTP and HTTPS connections and you want to allow only HTTPS connections, you need to activate the check box.

To enable only HTTPS connections

1. Click **Preferences** in the left-hand navigation panel, to open the **Preferences** page.
2. Under **Administrative Tools**, click **Secure Connection**.
3. Activate the check box next to **Enable HTTPS Only / Disable HTTP**.
4. Click **Save**.

The system automatically logs you out of the ztC Edge Console, redirects the browser to the HTTPS login page, and you must log in again.

To install a custom certificate into the CA bundle

To install a custom certificate into the CA bundle of the ztC Edge system, use the [certificate_installer](#) script. Using this script, you can install a custom SSL certificate, recover a previously used or build-in certificate, and display information about a certificate currently in use or previously used, as follows:

- Install a custom certificate on the host machine (non HTTPS-only mode):

- i. Copy a certificate to the `/tmp` folder of the host machine.
- ii. Issue the following command:

```
certificate_installer install -c /tmp/server.crt -k  
/tmp/server.key
```

- Install a custom certificate on the host machine (HTTPS-only mode):

- i. Copy a certificate to the `/tmp` folder of the host machine.
- ii. Issue the following command:

```
certificate_installer install -c /tmp/server.crt -k  
/tmp/server.key -f
```

- Recover the custom certificate to the previously used one:

```
certificate_installer recover -p
```

- Recover the custom certificate to the built-in one:

```
certificate_installer recover -b
```

- List information about the currently used certificate:

```
certificate_installer list -c
```

- List information about the previously used certificate:

```
certificate_installer list -p
```

For more information about installing a custom certificate, access the Knowledge Base to search for the article *Adding Certificates to ca-bundle.crt in ztC Edge* ([KB0014653](#)). See [Accessing Knowledge Base Articles](#).

The `certificate_installer` script

Usage

```
certificate_installer [command command_options] [script_options]
```

Commands and Options

<code>install <i>command_options</i></code>	<p>Installs the custom certificate. Command options are:</p> <ul style="list-style-type: none">• <code>-c, --cert=<i>certificate_path</i></code>: The path where the certificate is saved.• <code>-k, --key=<i>private_key_path</i></code>: The path where the key is saved.• <code>-f, --[no-]force</code>: Force replacing the SSL certificate in use.
<code>recover <i>command_options</i></code>	<p>Recovers the custom certificate. Command options are:</p> <ul style="list-style-type: none">• <code>-b, --[no-]built-in</code> (the default): Recover to the built-in certificate.• <code>-p, --[no-]previous</code>: Recover to the previously used certificate
<code>list <i>command_options</i></code>	<p>Lists the custom certificate(s). Command options are:</p> <ul style="list-style-type: none">• <code>-a, --[no-]all</code> (default): List all SSL certificates on host machine.• <code>-c, --[no-]current</code>: List the currently used certificate.• <code>-p, --[no-]previous</code>: List the previously used certificate.• <code>-L, --location=<i>location</i></code>: Show information of a certificate at a specified location.

Script Options

<code>-v, --[no_]verbose</code>	In verbose mode, the script displays all information.
<code>-l, --log=log_file</code>	Prints logs to the file <i>log_file</i> instead of to STDOUT.

Related Topics

[ztC Edge Console](#)

[Preferences Page](#)

[Using the ztC Edge Console](#)

[Security Hardening](#)

Configuring VM Devices

Configure VM devices to disable or enable insertion of virtual CDs (VCDs) in all VMs or attachment of USB devices to all VMs. By default, these VM devices can be inserted and attached. Use **VM Device Configuration** on the **Preferences** page to change the configuration.

When VM devices are enabled (the default) for insertion or attachment, you can insert VCDs in all VMs or attach a USB device to VMs. When VM devices are disabled for insertion or attachment, you cannot insert or attach these devices.

To disable insertion or attachment of VM devices

1. Click **Preferences** in the left-hand navigation panel, to open the **Preferences** page.
2. On the **Preferences** page, click **VM Device Configuration** beneath **Administrative Tools**.
3. Activate the check box for one or both of the following:
 - **Disable insertion of CDs on all VMs**—Activate the check box to disable inserting CDs in VMs.
 - **Disable attachment of USB devices to all VMs**—Activate the check box to disable attaching USB devices to VMs.
4. Click **Save**.

To enable insertion or attachment of VM devices

1. Click **Preferences** in the left-hand navigation panel, to open the **Preferences** page.
2. On the **Preferences** page, click **VM Device Configuration** beneath **Administrative Tools**.
3. Deactivate the check box for one or both of the following:
 - **Disable insertion of CDs on all VMs**—Deactivate the check box to enable inserting CDs in VMs.
 - **Disable attachment of USB devices to all VMs**—Deactivate the check box to enable attaching USB devices to VMs.
4. Click **Save**.

Related Topics

[Inserting a Virtual CD](#)

[Attaching a USB Device to a Virtual Machine](#)

[Preferences Page](#)

[Using the ztC Edge Console](#)

Managing IPtables

The administration tool for managing IP packet filtering for the Linux operating system is known as *iptables*. With ztC Edge systems, the task of working with iptables has been simplified and streamlined. Using the **IPtables Security** page, you can set up, maintain, and inspect the various filter table chains and their underlying rules. You have access to the three main chains (**INPUT**, **OUTPUT**, and **FORWARD**) for applying the packet-filtering rules you need. With ztC Edge systems, the rules are applied to the host operating system on each physical machine (PM), to both IPv4 and IPv6 packets, and the rules remain persistent after rebooting.

When you insert a rule, you specify a chain (**INPUT**, **OUTPUT**, or **FORWARD**) and a **Rule ID**. When processing inbound packets, the kernel applies the rules associated with the **INPUT** chain, and when processing outbound packets, the kernel applies the rules associated with the **OUTPUT** chain. The kernel applies the rules associated with the **FORWARD** chain when processing received inbound packets that must be routed to another host. Rules are applied in order of the **Rule ID**. (A **Rule ID** is similar to a row ID, where, for example, **Rule ID** 1 equals row 1.) Instead of creating rules, however, you can load default settings for the rules.

The **IPtables Security** page displays a separate table for each of the three chains and their associated rules. The rules, if they exist for a particular chain, are sorted by **Rule ID**. Columns display the network name, type of network, protocol, and other information. If necessary, use the scroll-bar on the right side of the page to view all of the rules and the scroll-bar at the bottom to view all of the columns. For more information on iptables functionality, see the Linux manual (man) pages for iptables.

You can, optionally, enable the rules to apply to the guest operating systems, in addition to the host. By default, rules apply only to the host operating system, but not to guest operating systems. When you enable rules to also apply to guests, all existing rules, imported rules, and additional newly inserted rules also apply to all guest operating systems (that is, for rules based on the same business network that has been allocated to the guest).

Notes:

1. For information on the ports that ztC Edge software uses, see [System Requirements Overview](#).
2. For additional information on ztC Edge TCP and UDP ports, access the Knowledge Base to search for the article *TCP and UDP ports used by ztC Edge* ([KB0014311](#)). See [Accessing Knowledge Base Articles](#).

To manage IPtables, first, enable IPtables security, if you have not already done so.

To enable IPtables security

1. Click **Preferences** in the left-hand navigation panel, to open the **Preference** page.
2. On the **Preferences** page, click **IPtables Security**.
3. Activate the checkbox next to **Enable IPtables Security**.

The **Enable IPtables Security** window becomes gray for a few minutes. When the window is active again, **Enable IPtables Security** is selected

Rules are applied only to the host, by default. You can, though, apply rules to guests as well as the host.

To apply rules to guests as well as the host

1. Click **Preferences** in the left-hand navigation panel, to open the **Preference** page.
2. On the **Preferences** page, click **IPtables Security**.
Ensure that **Enable IPtables Security** is selected.
3. **Apply to Host** is selected, by default:

Select **Apply to Host and Guests** to apply rules to both the host operating system and guest operating systems. The **Enable Port Management** window becomes gray for a few minutes.

When **Apply to Host and Guests** is selected, all existing rules, imported rules, and additional newly inserted rules will also apply to all guest operating systems (that is, for rules based on the same business network that has been allocated to the guest).

Continue, as appropriate, by inserting a new rule, removing a rule, loading default settings, importing rules, or exporting rules.

To insert a new rule

1. Click **Preferences** in the left-hand navigation panel, to open the **Preference** page.
2. On the **Preferences** page, click **IPtables Security**.

Ensure that **Enable IPtables Security** is selected.

3. Click the **Insert New Rule** button to open the **Insert New Rule** pop-up window.
4. In the **Insert New Rule** pop-up window, set values for the following:
 - **Chain**—Select **INPUT**, **OUTPUT**, or **FORWARD** from the drop-down list.
 - **Rule ID**—Enter a number that establishes the order for processing the rule. Enter a value, starting with 1 and up to a maximum value that is the total number of rules within the chain. Each **Rule ID** value must be unique.

If you enter a number that is already assigned to a rule, the existing rule is incremented by 1 (as are subsequent rules, if any) and the number you enter is assigned to the new rule. So, if, for example, **Rule ID 1** already exists and you enter **1** for the new rule, the existing **Rule ID 1** becomes **Rule ID 2**, the existing **Rule ID 2** (if it exists) becomes **Rule ID 3**, and so on.
 - **Shared Network**—Select a network from the drop-down list of all available shared networks.
 - **Protocol**—Select **udp**, **tcp**, or **all**.

Selecting **all** causes the **Grouping** and **Port Number** fields to become inactive (gray) because setting a range of port numbers is unnecessary.
 - **Target**—Select **drop**, **accept**, or **reject** for the action you want to apply to the packet that matches the rule's specifications.

- **Port Number (starting)**—For the first port of the range, enter a number 0 to 65535 that is less than or equal to **Port Number (ending)**.
- **Port Number (ending)**—For the last port of the range, enter a number 0 to 65535 that is greater than or equal to **Port Number (starting)**.
- **IP Address (starting)**—For the first IPv4 address of the range, enter an address 0.0.0.0 through 255.255.255.255 that is less than or equal to **IP Address (ending)**.
- **IP Address (ending)**—For the last IPv4 address of the range, enter an address 0.0.0.0 through 255.255.255.255 that is greater than or equal to **IP Address (starting)**.
- **IPv6 Address (starting)**—For the first IPv6 address of the range, enter an address 0000:0000:0000:0000:0000:0000:0000:0000 through ffff:ffff:ffff:ffff:ffff:ffff:ffff:ffff that is less than or equal to **IPv6 Address (ending)**.
- **IPv6 Address (ending)**—For the last IPv6 address of the range, enter an address 0000:0000:0000:0000:0000:0000:0000:0000 through ffff:ffff:ffff:ffff:ffff:ffff:ffff:ffff that is greater than or equal to **IPv6 Address (starting)**.

Click **Insert** to insert the new rule.

5. Newly inserted rules apply only to the host, by default. If you want the rules to apply to the host and guests, see [To apply rules to guests as well as the host](#).
6. Click **Save** at the bottom of the page, or click **Reset** to cancel any unsaved changes, which restores rules to those of the last saved session.

After the new rule is saved, the **IPtables Security** page displays it in the appropriate chain.

To remove a rule

1. Click **Preferences** in the left-hand navigation panel, to open the **Preference** page.
2. On the **Preferences** page, click **IPtables Security**.

Ensure that **Enable IPtables Security** is selected.

(**Apply to Host** and **Apply to Host and Guests** have no effect on removing rules.)
3. Select the rule that you want to remove.
4. Click **Remove** (in the right-most column), for the rule you selected.
5. Click **Save** at the bottom of the page, or click **Reset** to cancel any unsaved changes, which restores rules to those of the last saved session.

After the rule is removed, it disappears from the **IPtables Security** page .

To load default settings



Caution: Loading default settings will override current settings. .

1. Click **Preferences** in the left-hand navigation panel, to open the **Preference** page.
2. On the **Preferences** page, click **IPtables Security**.

Ensure that **Enable IPtables Security** is selected.

3. Click **Load Default Settings** at the bottom of the page.

A warning appears: *Current settings will be overridden by the initial settings!* Click **OK** if you want to load the default settings, or click **Cancel** to cancel the loading of default settings. If you click **OK**, the **Enable Port Management** window becomes gray for a few minutes and the *Loading default settings....* message appears.

4. The default rules apply only to the host, by default. If you want the rules to apply to the host and guests, see [To apply rules to guests as well as the host](#).

To import or export rules

1. Click **Preferences** in the left-hand navigation panel, to open the **Preference** page.
2. On the **Preferences** page, click **IPtables Security**.

Ensure that **Enable IPtables Security** is selected.

3. Click **Import** or **Export** at the bottom of the page.

- **Import**—The **Import/Restore IPtables Security Rules Wizard** appears. Browse to and select the XML file that you want to import. All rules associated with a shared network's type within the imported XML file will be generated for each existing shared network on the system with the same type.

After you have selected an XML file, the following message appears:

***Append** will reserve current rule set. Select **Overwrite** if you want to clear out all current rules.*

Click the appropriate button:

- **Append**—The selected XML file is appended to the existing XML file, preserving existing rules.

- **Overwrite**—The selected XML file overwrites the existing XML file, eliminating the existing rules.
 - **Export**—A file explorer window appears. Browse to a location on your local system where you want to save the file of exported rules. All rules in the table are exported to an XML file that is then downloaded to the location you select.
4. Imported rules apply only to the host, by default. If you want the rules to apply to the host and guests, see [To apply rules to guests as well as the host](#).
 5. If you imported a file, click **Save** (or click **Reset** to restore the previously saved values).

Related Topics

[Preferences Page](#)

[ztC Edge Console](#)

[Security Hardening](#)

Configuring the Login Banner

You can configure a login banner to provide customized content to the ztC Edge Console login page. For example, you can add a message.

To configure the login banner

1. Click **Preferences** in the left-hand navigation panel, to open the **Preference** page.
2. Under **Administrative Tools**, click **Login Banner Notice**.
3. Activate the **Enable Login Banner Notice** box. A box appears.

In the box, enter the information that you want to appear on the console login page. You can, for example, type the company name or provide a message.

4. Click **Save** (or click **Reset** to restore the previously-saved values).

Related Topics

[ztC Edge Console](#)

[Preferences Page](#)

[Using the ztC Edge Console](#)

Enabling ztC Advisor



Note: ztC Advisor was discontinued in December 2023. If you have not already done so, disable ztC Advisor on the **ztC Advisor** preference page by clearing the check box next to **Enable ztC Advisor** and clicking **Save**.

Enable ztC Advisor for a ztC Edge system to allow administrators to remotely monitor the system's health in the ztC Advisor dashboard.

ztC Advisor is a secure web-based portal that provides centralized visibility of your entire fleet of ztC Edge systems. Through an intuitive, user-friendly dashboard, you can assess at a glance, the health, resource usage, and software version of each system. For more information about registering for and using ztC Advisor, see the following web page: <https://www.stratus.com/solutions/ztc-advisor>.



Prerequisite: The ztC Edge system must be registered with Stratus and have an Internet connection to be monitored in ztC Advisor. You can enable ztC Advisor at any time, but system health information appears in the dashboard only when the system is registered with Stratus and connected to the Internet.

After enabling ztC Advisor as described in the following procedure, you can log on to the ztC Advisor dashboard and view the status of your system at the following web page: <https://ztcadvisor.stratus.com>.

To enable ztC Advisor for a ztC Edge system

1. Click **Preferences** in the left-hand navigation panel to open the **Preferences** page.
2. Under **Administrative Tools**, click **ztC Advisor**.
3. Activate the check box next to **Enable ztC Advisor**.
4. Optionally type an **Alias Name** for the system.

By default, the dashboard lists each system by its Asset ID; however, you can also assign an alias to the system to provide a more descriptive name and make it easier to locate in filters and searches.

The alias name can be up to 64 characters in length and include any combination of letters, numbers, and special characters.

5. Click **Save** to save the settings and enable monitoring.

After you save the changes, the system appears in the ztC Advisor dashboard within a few minutes.

Related Topics

[ztC Edge Console](#)

[Preferences Page](#)

[Using the ztC Edge Console](#)

Saving and Restoring System Preferences

On a ztC Edge system with the appropriate license, a user who has full system administrator privileges can save the settings of the ztC Edge Console **Preferences** page by creating a restore file (sometimes referred to as a backup file). You can save this file to a destination folder on a local computer or to a folder in your Stratus Cloud account. You can then select this saved file to restore **Preferences** settings to the same node, a replacement node, or to one or more other nodes, if needed at a later time. This feature enables you to quickly set up one or more systems. For example, if you are already logged in to your Stratus Cloud account where your system has a restore file, you can restore the node's system preferences with one click.

Notes:



- You can save a maximum of 50 files in your Stratus Cloud account, per ztC Edge system.
- To save a file in a Stratus Cloud account or to restore a file from it, the system must have Internet access, and you must log in to a Stratus Cloud account with valid credentials.
- Saving the system preferences of a single-node system is particularly important because a single-node system does not provide redundancy.

The system must have the appropriate license to save and restore **Preferences** settings. When a system is initially installed, this feature is disabled. The **Save System Preferences** and the **Restore System Preferences** windows of the **Preferences** page display a message explaining that you need to activate the license for saving and restoring **Preferences** settings. You must activate the license in order to use this feature.

To activate the license

Prerequisites: You need the following information to activate the license:



- **First Name and Last Name**
- **Company Email**—Provide the email address of the company that owns the system receiving the license. Do not provide a personal email address.
- **Company Name**—Provide the name of the company that owns the system receiving the license.
- **Company Phone Number**—Provide the phone number of the company that owns the system receiving the license. Do not provide a personal phone number.
- **Asset ID**—Provide the ASSET ID from the masthead of the ztC Edge Console.

If your system has Internet access, proceed with Step 1, below. If your system does not have Internet access, you need to move the license file between a location with Internet access and the location of the ztC Edge Console (which does not have Internet access). The procedure below describes a method using a USB flash drive, though other methods are possible. If you are using a USB flash drive, obtain it before beginning this procedure and insert it into a USB port in the remote management PC that is running the ztC Edge Console.

1. In the left-hand navigation panel, click **Preferences** to open the **Preferences** page.
2. Under **Administrative Tools**, click **Save System Preferences** or **Restore System Preferences**.
3. The window displays a message, explaining that you need to activate a separate license for saving and restoring **Preferences**.
4. Read the message. If your system has Internet access, click the link to open the licensing web page.



Note: If you also need to register the system and acquire a permanent license for the system, see [Registering the System and Acquiring a Permanent License](#).

If your system does not have Internet access, perform the procedure below to open the licensing web page.

On a system without Internet access

- a. Click the link to open the licensing web page, and copy the URL for the licensing web page using whatever method the browser allows.
 - b. Paste the URL in a text file and save the text file to the USB flash drive.
 - c. Remove the USB flash drive and go to a computer with Internet access.
 - d. Insert the USB flash drive into a USB port of the computer.
 - e. Navigate to the text file, open it, and copy the URL for the licensing web page.
 - f. Open a browser, paste the URL in the browser address bar, and go to the web page.
5. Enter the information on the web page and click **Submit**.
 6. Click the **Download License** button when it appears. If the system has Internet access, proceed with the next step.

If the system does not have Internet access, save the downloaded license file to the USB flash drive and remove the flash drive. Return to the remote management computer running the console and insert the USB flash drive.

7. Upload the license to the system by first clicking **Product License** on the **Preferences** page. Then, perform one of the following procedures, as appropriate for your system:
 - To upload the license automatically on a system with Internet access, first click **Product License** on the **Preferences** page, and then click **Check License Now** for **Online License Check**. The newly downloaded license will be automatically applied to the system.
 - To upload the license manually on a system with or without Internet access:
 - a. Click **Product License** on the **Preferences** page.
 - b. Click the **Offline License Check and Manual License Installation** bar to display its options, if they are not already displayed.
 - c. For **Install an Activated License Key to the System**, click **Choose File** and navigate to the location where you saved the license file.
 - d. Select the file, click **Open**, and then click **Upload** to upload the file to the system.

The system now has the appropriate license to save and restore **Preferences** settings.

The following preferences settings are included, by default, in the saved file:

Owner Information	VM Device Configuration
Software Updates	IPtables Security
IP Configuration	Login Banner Notice
Quorum Servers (dual-node systems, only)	ztC Advisor
Date & Time	e-Alerts
Mail Server	SNMP Configuration
Users & Groups	OPC Configuration
Secure Connection	Support Configuration
	Proxy Configuration

To save system preferences

1. In the left-hand navigation panel, click **Preferences** to open the **Preferences** page.
2. Under **Administrative Tools**, click **Save System Preferences**.
3. Under **Save System Preferences**, select one of the following:
 - **Save system preferences to a file on this computer**
 - **Save system preferences to a file in the cloud**—With this selection, the following message appears when the remote management computer (which is running the ztC Edge Console) is connected to the Internet:

Log on to the Stratus Customer Service Portal to authenticate your account.

Enter the username and password of your Stratus Customer Service account. If the remote management computer is not connected to the Internet, the login fields do not appear; instead, a message indicates that Internet connectivity is unavailable and you cannot save the file.

After you log in to a Stratus Cloud account, the account displays the name of the user logged in and the number of files currently stored in the account. You can save a maximum of 50 files, per each system. If 50 files are saved, you cannot save another file. You cannot delete files, so you must contact your Stratus service representative about deleting files.

The account login session is open as long as your console session is active; you are automatically logged out when you close the console session or the session times out due to inactivity.

4. Enter information, as necessary, in the following fields:

- **File Name**—This field displays a default file name in the format **ztC_Asset_ID_preferences_yyyy-mm-dd-hh-mm.zip**. You can modify the default name, if necessary, after you save the file. Characters allowed in the file name are letters, numbers, hyphens, and underscore (_).
- **Description**—Enter a description (optional).
- **Keywords**—The keyword *system_ID* appears, by default. You can change the default keyword and add additional keywords, for a total of three keywords.

5. Click one of the following buttons:

- **Save**—The file is saved with the default file name, or you can modify the file name, if necessary.

If you are saving the file to a local computer, use the default location or navigate to a different location. (The default location is set in the browser.)

If you are saving the file in a Stratus Cloud account, and the username and password are validated successfully, the file is created and saved in the user's account, in a folder with the name **Asset_ID**.

- **Clear**—Clears the **Description** and **Tags** fields. Additionally, if you are saving the file in a Stratus Cloud account, the file name is reset to the default name, and the username and password are cleared.

The message *System preferences saved.* appears when the save succeeds.

After you saved the settings of system preferences and you want to restore the settings to the same system or another system, you should first prepare by becoming familiar with Cautions, Prerequisites, and Notes regarding the restore operation.

To prepare for restoring system preferences

Before you restore a saved system preferences file, you should be aware of the Caution, Prerequisites, and Notes below.

Caution: If the restored system preferences change any of the following settings, the system's connection to the ztC Edge Console is lost:



- IP Configuration
- Secure Connections (if you are logged in with HTTP enabled, and the restore file disables HTTP)
- Date & Time

When the connection is lost, the restore operation continues to run in the background, though you are not able to see its progress or status. If you lose the connection, log in again. (For information about setting the IP configuration, see [Configuring IP Settings](#). For information about setting secure connections, see [Configuring Secure Connections](#). For information about setting the date and time, see [Configuring Date and Time](#).)

Prerequisites:



- Active Directory (AD) settings: If restored preferences enable AD, you must provide AD credentials when logging in. For information about enabling AD, see [Configuring Active Directory](#).
- The **Quorum Servers** setting:
 - The **Enabled** status is restored.
 - No VMs should be using the existing quorum server; all VMs in use should be powered off, before restoring preferences. If any VMs are using the quorum server during the restore operation, the restore of **Quorum Servers** will fail.
 - This setting is not restored to a single-node system.

For information about enabling quorum servers, see [Configuring Quorum Servers](#).

Notes: Before you restore system preferences, consider the following information:

- The system that you restore preferences to and the system whose saved preferences file you are using must be the same in the following ways:
 - The same hardware model—The system that you restore preferences to must be the same hardware model as the system whose saved preferences file is being restored.
 - The same dual-node or single-node configuration—You can restore to a dual-node system only preferences that were saved on a dual-node system. You can restore to a single-node system only preferences that were saved on a single-node system.
- If you restore system preferences on a system running an earlier or later release than the original backup, you can restore only the preferences that are supported in the earlier release.
- **IPtables Security**—To restore IPtables settings, you must select either **Append** (to append the restore-file settings to the existing rule set) or **Overwrite** (to overwrite the existing rule set with the restore-file settings). (For information about IPtables, see [Managing IPtables](#).)
- **IP Configuration**—When selected, all network configuration data is restored. (For information, see [Configuring IP Settings](#).)
- **Date & Time**—Only the setting **Automatically** is restored immediately. When restoring the setting **Manually** as well as settings with a different time zone and multiple NTP servers, the physical machines are powered off, and the restored date and time settings take effect after the system is rebooted. (For information, see [Configuring Date and Time](#).)
- For **Users & Groups**, consider the following:
 - You must provide AD credentials to restore the **Users & Groups** setting.
 - If a user account exists on the current system and in the restore file, the current system considers the user account to be edited.
 - If a user account exists in the restore file but not on the current system, the current system considers the user account to be added.





- The current system skips an AD entry in the restore file in the following circumstances:
 - If an AD entry in the restore file is missing in AD configured for the current system at the time of the restore.
 - If the AD entry in the restore file has a mismatch in user type with the AD entry configured for the current system at the time of the restore.

(For information about **Users & Groups**, see [Configuring Users and Groups](#).)

After you are familiar with Cautions, Prerequisites, and Notes regarding the restore operation, you can restore system preferences.

To restore system preferences

1. In the left-hand navigation panel, click **Preferences** to open the **Preferences** page.
2. Under **Administrative Tools**, click **Restore System Preferences**.
3. Under **Restore System Preferences**, select one of the following:
 - **Restore system preferences from a file saved on this computer:**
 - a. Click **Choose file** to display a list of files in the default save directory, including saved zip files. If necessary, navigate to a different directory.
 - b. Scroll to select the file with the **Preferences** settings that you want to restore, and click the file name. The following table appears:

Restoring system preferences from:

File Name	ztC_Asset_ID_preferences_YYYY-MM-DD-HH-MM-SS.zip
Software Version	version_number
Description	description
Keywords	keywords

If the restored **Preferences** include Users & Groups, the following information also appears:

Active Directory Credentials	You need Active Directory credentials to restore Users & Groups settings.
-------------------------------------	--

To restore settings in the selected file, click **Next**.

- **Restore system preferences from a file saved in the cloud**—With this selection, *Log on to the Stratus Customer Portal to authenticate your account* appears with **Username** and **Password** boxes (if you are not already logged in to your account) when the remote management computer is connected to the Internet. If the remote management computer is not connected to the Internet, a message appears indicating that Internet connectivity is unavailable. (After you log in to your Stratus Cloud account, the session is open as long as your console session is active; you are automatically logged out when you close the console session or the session times out due to inactivity.)

Enter the username and password for your Stratus Customer Service account, and click **LOGIN**.

When the connection succeeds, the following table appears, listing one or more files, up to the total number of files saved:

Select an Asset ID <i>Search IDs</i>	Select a file from which to restore system preferences	
Asset ID	File Name	Created
<i>asset_ID</i>	<i>filename</i>	<i>time</i>

The **Asset ID** column displays a list of the *asset_ID* folders. The **File Name** column lists the files within the *asset_ID* folder with the time when the file was saved, as displayed in the **Time** column. In addition, the table [Restoring system preferences from:](#) appears.

Under **Asset ID**, the ID of the current system is listed first and its restore file (if it exists) is listed first under **File Name**. In this case, click the top filename to restore **Preferences** settings to the current system.

To search for a file, enter its *filename* in the *Search IDs* box.

To select a file, click the desired *asset_ID*, and then click the desired *filename*. Click **Next** to restore **Preferences** settings from the selected file.

4. The **Select the system preferences to restore** window appears with a list of preferences.

The following preferences settings are restored, by default:

Owner Information	ztC Advisor
Software Updates	e-Alerts
Quorum Servers (dual-node systems, only)	SNMP Configuration
Mail Server	OPC Configuration
VM Device Configuration	Support Configuration
Login Banner Notice	Proxy Configuration

Note:

The following preferences are not selected by default because the preference causes either a pop-up message to appear or the system to restart:



- **Date & Time**—If the settings change, the system reboots.
- **Users & Groups**—If Active Directory (AD) is enabled, a window appears for AD credentials.
- **Secure Connection**—If you are logged in with HTTP and the restore file disables HTTP, the connection to the system is lost and you must log in again.
- **IPtables Security**—A window appears asking if you want to either overwrite the current set of rules or append the restored rules to the current set of rules.
- **IP Configuration**—If the IP configuration changes, the connection to the system is lost and you must log in again.

Deselect the checkbox of any preference that you do not want to restore. Select any additional preferences, if not already selected.

5. Click **Restore** for the system to restore the selected preferences, or click **Back** to return to the previous window. Once you click **Restore**, you cannot cancel the procedure. The restore operation takes about a minute to complete. During the restore operation, you cannot navigate to other screens in the ztC Edge Console window. You must wait for the restore operation to complete before you display another console window.

The **Restore Status** column lists the restore status as **In Progress**, **Completed**, **Partially completed**, or **Failed**. When the restore operation is complete, the following message appears:

Complete! The Preferences shown above have been successfully restored.

6. Click **Done**. The initial **Restore System Preferences** screen reappears.

Related Topics

[ztC Edge Console](#)

[Preferences Page](#)

[Using the ztC Edge Console](#)

Configuring e-Alerts

Configure email alerts (e-Alerts) to enable the ztC Edge system to send email to system administrators whenever the system detects an event requiring administrator attention.



Prerequisite: In order for e-Alerts to function properly, you must configure the mail server. See [Configuring the Mail Server](#).

To enable e-Alerts

1. Click **Preferences** in the left-hand navigation panel, to open the **Preference** page.
2. Under **Notification**, click **e-Alerts**.
3. Click the **Enable e-Alerts** box. Boxes for specifying or selecting the following settings appear:
 - **e-Alerts Language**—Select a language from the pull-down menu.
 - **List of Recipients** (required)—Enter email addresses for all e-Alert recipients.
4. Click **Save** (or click **Reset** to restore the previously-saved values).



Note: When you enable or update the e-Alert configuration, generate a test alert to confirm that you receive the alerts.

To generate a test alert

Click **Generate Test Alert**. The Stratus Redundant Linux software generates a test alert and sends a sample email with the subject "Test Alert" to all email recipients; SNMP sends traps to recipients of SNMP traps, if configured (see [Configuring SNMP Settings](#)); and Support Configuration sends a notification to your authorized Stratus service representative, if configured (see [Configuring Remote Support Settings](#)). Watch the Alerts History log (see the [Alerts History Page](#)) for delivery status.

You can also test e-Alerts by putting the secondary physical machine into maintenance mode (see [Maintenance Mode](#)), and then removing it from maintenance mode. Verify that you receive e-Alerts for both maintenance mode events.

Related Topics

[ztC Edge Console](#)

[Preferences Page](#)

[Using the ztC Edge Console](#)

Configuring SNMP Settings

Configure Simple Network Management Protocol (SNMP) settings for the ztC Edge system to allow SNMP management applications to remotely monitor your systems. (SNMP information pertains only to systems and not individual PMs.) You can enable SNMP requests and SNMP traps:

- **SNMP request**—A request sent to the system to retrieve the values of objects listed in the Management Information Bases (MIBs) supported by the Stratus Redundant Linux software. These MIBs include a system-specific MIB that is a collection of objects describing the ztC Edge system. You can download a copy of the MIB file from the **Drivers and Tools** section of the **Downloads** page at <https://www.stratus.com/services-support/downloads/?tab=ztcedge>.
- **SNMP trap**—A message initiated by one of the nodes in the ztC Edge system after an event such as an alert that is then sent to an identified list of recipients, typically a network management station (NMS).

Follow the appropriate procedure to enable SNMP requests or traps.

To enable SNMP requests

To enable SNMP requests, perform one of the following actions:

- Enable SNMP requests from the **Preferences** page:
 - Add an SNMPv3 user who can enable SNMPv3 requests and who has read-only access to the full MIB in the ztC Edge system.
 - Configure access control for SNMPv1 and SNMPv2 requests, where you allow no users (**Restricted**) or any user using the default public community (**Unrestricted**) to send requests.
- Customize SNMP request functionality by editing `snmpd.conf` files. You can customize access control for SNMPv1 requests and SNMPv2 requests. You can also customize the list of users for SNMPv3 requests. For information, see [To customize SNMP request functionality](#) (below).


To enable SNMP requests from the Preferences Page

1. Click **Preferences** in the left-hand navigation panel, to open the **Preference** page.
2. Under **Notification**, click **SNMP Configuration**.
3. Activate the check box next to **Enable SNMP Requests**.
4. The **List of Users for SNMP Requests (Version 3)** appears.

If a username appears below the **List of Users for SNMP Requests (Version 3)**, the user's security level is displayed and a read-only display of the `snmpd.conf` file also appears. The user has read-only access to the full MIB. Note that the system supports only one **SNMP Requests (Version 3)** user.

If a username does not appear, you can add an SNMPv3 user.

To add an SNMPv3 user

- a. Click the  **Add** button, which opens the **Add a User** wizard.
- b. Enter values for the following:

Username—The name of a user who has access to the SNMPv3 agent. The name must be unique.

Security Level—The user's security level. Valid values are:

- **No Authentication and No Privacy**: No security is applied to messages; messages are not authenticated or encrypted.
- **Authentication and No Privacy**: Messages are authenticated, but not encrypted. You must enter values for **Authentication Type** and **Authentication Password**.
- **Authentication and Privacy**: Messages are authenticated and encrypted. You must enter values for **Authentication Type**, **Authentication Password**, **Encryption Type**, and **Encryption Password**.

When the security level includes authentication or privacy, the following fields appear:

Authentication Type—The user's type of authentication. Valid values are:

- **MD5**: Configure the message digest algorithm (MD5) as the user's authentication type.

- **SHA:** Configure the secure hash algorithm (SHA) as the user's authentication type.

Authentication Password—The user's required password, which is used to generate the secret authentication key. The password must be a minimum of eight characters.

Encryption Type—The user's type of encryption. Valid values are:

- **AES:** Configure the Advanced Encryption Standard (AES) as the user's encryption type.
- **DES:** Configure the data encryption standard (DES) as the user's encryption type.

Encryption Password—The user's required password, which is used to generate the secret encryption key. The password must be a minimum of eight characters.

- c. Click **Save** to save the changes.

5. Select an access option:

Restricted (the default)—Allows no users to send SNMPv1 requests and SNMPv2 requests.

Unrestricted—Allows any user using the default public community to send SNMPv1 requests and SNMPv2 requests.

Customized (available when `snmpd.conf` has been manually edited by a user; see [To customize SNMP request functionality](#), below)—Allows customized access.

6. Click **Save**. (Or click **Reset** to restore the previously-saved values.)

To customize SNMP request functionality by editing `snmpd.conf` files

Customize SNMP request functionality by editing `snmpd.conf` files.

Customize access control for SNMPv1 requests and SNMPv2 requests by editing the `/etc/snmp/snmpd.conf` file:

1. Log in to the host.
2. Manually edit the standard `/etc/snmp/snmpd.conf` file on both nodes.
3. Save the file.

4. Restart the `snmpd` process on each node by entering the command **`systemctl restart snmpd`**.

Customize the list of users for SNMPv3 requests by editing the `/etc/snmp/snmpd.conf` and `/var/lib/net-snmp/snmpd.conf` files.

1. Log into the host.
2. Manually edit the standard `/etc/snmp/snmpd.conf` file on both nodes.
3. Manually edit the standard `/var/lib/net-snmp/snmpd.conf` file on both nodes.
4. Save the file.
5. Restart the `snmpd` process on each node by entering the command **`systemctl restart snmpd`**.

To enable SNMP traps


Notes:



1. When you add a recipient for **SNMP Traps (Version 3)**, you need to confirm that the engine ID of the trap user on the recipient server is `0x80001370017F000001`.
2. When you enable or modify the SNMP trap settings, generate a test alert to confirm that traps are received.

1. Click **Preferences** in the left-hand navigation panel, to open the **Preference** page.
2. Under **Notification**, click **SNMP Configuration**.
3. Activate the check box next to **Enable SNMP Traps**.
4. Type the name of the SNMP **Community**, or keep the default (**public**).
5. Below the **List of Recipients of SNMP Traps (Version 3)** is a list of the trap users, and the IP address of the recipient server where the trap user exists. The ztC Edge system sends SNMPv3 traps to the trap user on the recipient server. Add a recipient, if necessary.

To add a recipient

- a. Click the  **Add** button, which opens the **Add a Recipient** wizard.
- b. Enter values for the following:

Recipient Address—The host name or the IPv4 address of the recipient server.

Username—The name of a trap user on the recipient server. The name must be unique for the recipient.

Security Level—The user's security level. Valid values are:

- **No Authentication and No Privacy:** No security is applied to messages; messages are not authenticated or encrypted.
- **Authentication and No Privacy:** Messages are authenticated, but not encrypted. You must enter values for **Authentication Type** and **Authentication Password**.
- **Authentication and Privacy:** Messages are authenticated and encrypted. You must enter values for **Authentication Type**, **Authentication Password**, **Encryption Type**, and **Encryption Password**.

When the security level includes authentication or privacy, the following fields appear:

Authentication Type—The user's type of authentication. Valid values are:

- **MD5:** Configure the message digest algorithm (MD5) as the user's authentication type.
- **SHA:** Configure the secure hash algorithm (SHA) as the user's authentication type.

Authentication Password—The user's required password, which is used to generate the secret authentication key. The password must be a minimum of eight characters.

Encryption Type—The user's type of encryption. Valid values are:

- **AES:** Configure the Advanced Encryption Standard (AES) as the user's encryption type.
- **DES:** Configure the data encryption standard (DES) as the user's encryption type.

Encryption Password—The user's required password, which is used to generate the secret encryption key. The password must be a minimum of eight characters.

- c. Click **Save** to save the changes.
6. Click **Save**. (Or click **Reset** to restore the previously saved values.)
7. Configure your organization's firewall to allow SNMP operations, which enables SNMP management systems to receive alerts from and send traps to the ztC Edge system. To do so, configure your organization's firewall to open the SNMP port:

Message Type: SNMP

Protocol: SNMP

Port: 161 (Get/Walk) 162 (Traps)

8. Generate a test alert by clicking **Generate Test Alert**.

The Stratus Redundant Linux software generates a test alert and SNMP sends traps to recipients of SNMP traps; e-Alerts send a sample email with the subject "Test Alert" to all email recipients of e-Alerts, if configured (see [Configuring e-Alerts](#)); and Support Configuration sends a notification to your authorized Stratus service representative, if configured (see [Configuring Remote Support Settings](#)). Watch the Alerts History log (see the [Alerts History Page](#)) for delivery status.

Related Topics

[SNMP](#)

[ztC Edge Console](#)

[Preferences Page](#)

[Using the ztC Edge Console](#)

[Security Hardening](#)

Configuring OPC Settings

Configure Open Platform Communication (OPC) settings to enable OPC server functionality, which publishes ztC Edge system performance data for an OPC client to receive and display. This allows you to monitor the ztC Edge system alongside other industrial equipment.

In order to use OPC functionality, you must install OPC client software (of your choice) on a separate computer and then configure the OPC client (see [To install and configure an OPC client](#)). The OPC client must be configured to receive data from the port on the ztC Edge system that you configure for OPC. The default port is 4840, though you can specify another port number.

To configure OPC settings

1. Click **Preferences** in the left-hand navigation panel, to open the **Preference** page.
2. Under **Notification**, click **OPC Configuration**.
3. Activate the check box next to **Enable OPC Server**.
4. The default port number is **4840**. If necessary, specify another number.
5. Activate either or both of the following check boxes, as appropriate for your system:

Allow anonymous OPC client connections—OPC clients do not need to provide a username and password when connecting to the OPC server on the ztC Edge system. (When the check box is not activated, OPC clients must provide a username and password.)

Allow OPC client connections using usernames and passwords configured from Users & Groups—OPC clients can connect to the OPC server on the ztC Edge system with the same username and password used to log in to the ztC Edge Console. (When the check box is not activated, OPC clients cannot log in to the OPC server using local-user account usernames and passwords, as specified on the **User & Groups** page. See [Managing Local User Accounts](#).)

6. Click **Save**. (Or click **Reset** to restore the previously-saved values.)

To install and configure an OPC client

You must install OPC client software and configure an OPC client on a separate computer. You can choose OPC client software from the many versions that exist in the marketplace. The procedure below describes how to install and configure an OPC client using UaExpert[®] software from Unified Automation.

Installing and configuring an OPC client using UaExpert software



Note: In addition to reading the procedure below, follow instructions with the UaExpert software.

1. Download and install the Windows version of the UaExpert software. See <https://www.unified-automation.com/products/development-tools/uaexpert.html>.
2. If starting UaExpert software for the first time, follow the instructions with the software for an initial start-up.
3. Run the UaExpert software.

The **Unified Automation UaExpert - The OPC Unified Architecture Client - NewProject** main window opens.

4. In the menu bar, click **Server** and select **Add**. The **Add Server** dialog box appears.
5. Click the **Advanced** tab.
6. In the **Endpoint Url** box, enter the URL of the endpoint, which is the ztC Edge system's cluster IP address (for example, **opc.tcp://tcp_cluster_ip_address:4840/**).
7. For **Security Settings**, select **None** for both **Security Policy** and **Message Security Mode**.
8. For **Authentication Settings**, Select one of the following, as required for your configuration:

Anonymous—Select if you activated the check box for allowing anonymous OPC client connections.

Username and Password—Enter values if you activated the check box for allowing OPC client connections using usernames and passwords. The username and password you enter must be identical to the username and password that you add for a read-only user on the ztC Edge system for OPC access. See [Managing Local User Accounts](#) for information on adding a user to the ztC Edge system.

9. Click **OK** to close the **Add Server** dialog box.

The main window reappears. In the left panel, the name of the server appears in the **Project** box, under **Servers**.

10. Select the new server and then click the connect button, which appears in the tools bar to the right of the minus sign icon.

When the client connects successfully to the server, the **Address Spaces** box of the main window displays the end point of the server.

In the **Address Spaces** box, you can click the top level to expand and explore the available data values. In the **Attributes** box, the **Value** column displays the current value of the selected item.

Related Topics

[Displaying OPC Output](#)

[ztC Edge Console](#)

[Preferences Page](#)

[Using the ztC Edge Console](#)

Displaying OPC Output

After you have enabled OPC server functionality on the ztC Edge system, an OPC client (on a computer that is not the ztC Edge system) can publish the system's performance data. The data is divided into address spaces, where each address space is divided into sub-objects that contain several data items. The OPC server functionality on the ztC Edge system passes values for the data items to the OPC client, which then displays the data.

This topic describes how to display ztC Edge system information using an OPC client created with UaExpert[®] software from Unified Automation.

To display OPC output

1. On the computer where you have created an OPC client, open the client.
2. In the (left) **Project** panel, click **Project**, **Servers**, and then **ztC OPC Server**.

In the left panel beneath **Project** is **Address Space**. After you select **ztC OPC Server**, the **Address Space** panel displays the **Root** hierarchy.

3. In the **Address Space** panel, click **Objects** below **Root**. Beneath **Objects**, you can select **Server** and **ztC**.

■ Server

For information about the node that is currently running the OPC server, view the **BuildInfo** sub-object: click **Server** and then **ServerStatus**.

The **BuildInfo** sub-object displays values for the following data items:

Data Items	Description
ProductUrl	Displays http://www.stratus.com/ .
ManufacturerName	Displays Stratus Technologies Ireland, Ltd.
ProductName	Displays the product name of the hardware (ztC Edge).
SoftwareVersion	Displays the version number of the Stratus Redundant Linux software.

Data Items	Description
BuildNumber	Displays the Stratus Redundant Linux software build number.
BuildDate	Displays the date of the Stratus Redundant Linux software build.

For additional information on the **Server** object, see *Part 5: Information Model* of the *OPC Unified Architecture Specification*, which is available at opcfoundation.org.

- **ztC**—The ztC object divides the address space into the following sub-objects, with the data items listed in the each table:

Applications

The applications data items provide information about the health of applications.

Data Items	Description
AlertedApplicationsCount	Lists the number of applications in <code>AlertedApplicationsList</code> . Data type: <code>UInt32</code> .
AlertedApplicationsList	Lists the applications currently monitored that have any status that is not normal or is unavailable (<i>Not Running</i> , <i>Not Responding</i> , <i>Unavailable</i> , and <i>Not Found</i>). This list includes applications with a VM that is stopped. The list does not include monitors that are not activated (that is, application monitors listed in the Applications panel of the Monitor tab without the Enabled box activated). Data type: dynamic array of string.

Data Items	Description
AllApplicationsHealthy	<p>Indicates whether or not a monitored application has a warning: <i>true</i> indicates no warnings; <i>false</i> indicates that one or more monitored applications has a warning.</p> <p>Data type: Boolean.</p>
ApplicationMonitoringEnabled	<p>Indicates whether application monitoring is licensed and turned on: <i>true</i> indicates that it is turned on; <i>false</i> indicates that it is not turned on.</p> <p>Data type: Boolean.</p>
ApplicationsCount	<p>Indicates the number of applications currently monitored . Its value should equal the number of applications in ApplicationsList.</p> <p>Data type: UInt32.</p>
ApplicationsList	<p>Lists the applications currently monitored. It is a one-dimensional array that increases or decreases as monitored applications are added or removed. The list does not include monitors that are not activated (that is, application monitors listed in the Applications panel of the Monitor tab without the Enabled box activated). Names listed include the VM name as a prefix to the application name (for example, vm1/testapp.exe).</p> <p>Data type: dynamic array of string.</p>

Physical Machines

The data items for physical machines provide information about whether or not individual nodes in a system are healthy.

Data Items	Description
AllPhysicalMachinesHealthy	<p>Indicates whether both nodes are healthy: <i>true</i> indicates both nodes are present, running green-checked, and neither is in maintenance mode; <i>false</i> indicates that one node (or both nodes) is not present, is not running green-checked, and/or is in maintenance mode.</p> <p>Data type: Boolean.</p>
Node0 and Node1	<p>NodenHostState: the host state. Valid values include <i>exiled</i>, <i>failed</i>, <i>firmware</i>, <i>imaging</i>, <i>lost</i>, <i>nfc</i>, <i>off</i>, <i>proto</i>, <i>running</i>, <i>starting</i>, <i>stopping</i>, <i>unlicensed</i>, and <i>unreachable</i>.</p>
	<p>NodenIPAddress: the node IP address.</p>
	<p>NodenMaintenanceMode: the host maintenance mode. Valid values include <i>evacuating</i>, <i>maintenance</i>, and <i>normal</i>.</p>
	<p>NodenExists: indicates whether or not the node is known to the system, where <i>true</i> indicates the node successfully joined the system; <i>false</i> indicates that a second node was not added to the system, or that a second node was added and was later removed. If the value is <i>false</i>, ignore all other <i>noden</i> information.</p>

Data Items	Description
	<p>NodenVirtualMachineList: lists the virtual machines (VMs) running on this node.</p>
	<p>NodenCombinedState: indicates a combination of NodenMaintenanceMode, NodenExists, and NodenHostState, as follows:</p> <ul style="list-style-type: none"> ◦ NodenCombinedState is <i>missing</i> when NodenExists is <i>false</i>. ◦ NodenCombinedState is either <i>evacuating</i> or <i>maintenance</i> when NodenExists is <i>true</i>, NodenHostState is <i>running</i>, and NodenMaintenanceMode is <i>evacuating</i> or <i>maintenance</i>. ◦ When NodenCombinedState is any other value, it indicates the value of NodenHostState, with the range of NodenHostState values listed above.
PhysicalMachinesList	<p>Lists nodes that are present.</p> <p>Data type: dynamic array of string.</p>
PhysicalMachinesWarningCount	<p>Lists the number of physical machines that are not green-checked.</p> <p>Data type: UInt32.</p>
PhysicalMachinesWarningList	<p>Lists physical machines that are reporting problems. The list typically includes both</p>

Data Items	Description
	<p>nodes; for example, when the secondary is in maintenance mode, the primary is marked unsafe to pull.</p> <p>Data type: dynamic array of string.</p>
PrimaryPhysicalMachine	<p>Displays the name of the current primary node.</p> <p>Data type: string.</p>

Virtual Machines

The data items for virtual machines provide information about the status of VMs running on the system.

Data Items	Description
AllVirtualMachinesHealthy	<p>Indicates whether any VM has a warning or failure status: <i>true</i> indicates all VMs are green-checked; <i>false</i> indicates that one or more VMs is not running green-checked.</p> <p>Data type: Boolean.</p>
FTVirtualMachinesList	<p>Displays the names of FT VMs present on the system.</p> <p>Data type: dynamic array of string.</p>
GetPhysicalMachine	<p>Indicates which physical machine is running the specified VM.</p> <p>Data type: function that takes one string and returns one string (the input argument of the function is a string that is a VM name, and the output is a string (node0 or node1) indicating</p>

Data Items	Description
	the physical machine that is currently running the VM named in the input argument).
HAVirtualMachinesList	Displays the names of HA VMs present on the system. Data type: dynamic array of string.
RunningVirtualMachinesCount	Lists the number of VMs in RunningVirtualMachinesList. Data type: UInt32.
RunningVirtualMachinesList	Lists the names of VMs marked as <i>running</i> . Data type: dynamic array of string.
StoppedVirtualMachinesCount	Lists the number of VMs in StoppedVirtualMachinesList. Data type: UInt32.
StoppedVirtualMachinesList	Lists the names of VMs marked as <i>stopped</i> (ignores transition states such as <i>booting</i>). Data type: dynamic array of string.
VirtualMachinesCount	Lists the number of VMs present on the system. Data type: UInt32.
VirtualMachinesList	Lists the names of VMs present on the system. Data type: dynamic array of string.

System

The data items for the system provide high-level status information as well as information about access methods for the overall system.

Data Items	Description
ManagementConnectionGood	Indicates whether the OPC server can retrieve information from the ztC Edge system: <i>true</i> indicates that the server can retrieve information from the system; <i>false</i> indicates that the server cannot retrieve information. Data type: Boolean.
ManagementIP	Indicates the system IP address of the ztC Edge system. Data type: string.
ManagementURL	Indicates the HTTP URL of the ztC Edge Console. Data type: string.
OutstandingSeverity	Corresponds to the overall system status icon on the login page. Data type: string.
SecureManagementURL	Indicates the HTTPS URL for the ztC Edge Console. Data type: string.

Related Topics

[Configuring OPC Settings](#)

Configuring Remote Support Settings

When you log on to the ztC Edge system for the first time, configure support configuration settings that enable the ztC Edge system to send support notifications (alerts) to your authorized Stratus service representative when an event requires attention.

To configure support configuration settings



Note: When you enable or modify settings for **Enable Remote Support Access** or **Enable Notifications**, generate a test alert to confirm that your authorized Stratus service representative can receive system health messages from your system.

1. Click **Preferences** in the left-hand navigation panel, to open the **Preferences** page.
2. Under **Remote Support**, click **Support Configuration**.
3. Modify the settings, as appropriate for your system:
 - **Enable Remote Support Access** allows your authorized Stratus service representative to remotely connect to the ztC Edge system for troubleshooting purposes. Note that you can enable and then disable this setting, as needed.
 - **Enable Notifications** allows the ztC Edge system to send health and status notifications to your authorized Stratus service representative.
 - **Enable Support Notifications** sends an alert for any event that requires attention. It also sends a periodic "heartbeat" call-home message to your authorized Stratus service representative.
 - **Enable Periodic Reporting** sends a daily summary of system information to help improve product and service quality.
4. Click **Save** (or click **Reset** to restore the previously saved values).
5. Configure your organization's firewall to allow support messages.

To configure your firewall to allow support messages

Use the following information to configure your organization's firewall to allow communication with your authorized Stratus service representative:

Message Type: Call-Home and Licensing

Protocol: TCP

Port: 443

Stratus support server address: *.stratus.com

Message Type: Support Diagnostics

Protocol: TCP

Port: 443

Stratus support server address: *.stratus.com

Message Type: Dial-In

Protocol: TCP

Port: 443, Default proxy port: 3128 (You can change the default proxy port number.)

Stratus support server address: *.ecacsupport.com

Message Type: e-Alert

Protocol: SMTP

Port: 25

(For additional information on TCP and UDP ports, access the Knowledge Base to search for the article *TCP and UDP ports used by ztC Edge* ([KB0014311](#)). See [Accessing Knowledge Base Articles](#).)

To enable SNMP management systems to receive alerts and send traps to the ztC Edge system, configure the firewall for the following:

Message Type: SNMP

Protocol: SNMP

Port: 161 (Get/Walk) 162 (Traps)

6. Generate a test alert.

To generate a test alert

Click **Generate Test Alert**. The Stratus Redundant Linux software generates a test alert and Support Configuration sends a notification to your authorized Stratus service representative; e-Alerts send a sample email with the subject "Test Alert" to all email recipients of e-Alerts, if configured (see [Configuring e-Alerts](#)); and SNMP sends traps to recipients of SNMP traps, if configured (see [Configuring SNMP Settings](#)). Watch the Alerts History log (see the [Alerts History Page](#)) for delivery status. A subsequent alert will be generated if the support notification fails.

Related Topics

[ztC Edge Console](#)

[Preferences Page](#)

[Using the ztC Edge Console](#)

Configuring Internet Proxy Settings

Configure proxy settings for the ztC Edge system if your organization requires a proxy server to access the Internet and you have a service agreement with Stratus or another authorized ztC Edge service representative.

A proxy server provides a secure bridge between the ztC Edge system and the Internet. Stratus Redundant Linux software uses proxy server information for only outbound HTTP traffic related to support notification messaging and remote support access features.

To configure Internet proxy settings

1. Click **Preferences** in the left-hand navigation panel, to open the **Preferences** page.
2. Under **Remote Support**, click **Proxy Configuration**.
3. To enable proxy service, click the **Enable Proxy** box.
4. In the **Proxy Server** box, type the fully-qualified proxy server host name or IP address.
5. In the **Port Number** box, type the port number if it is different from the default number (3128).
6. If the proxy server requires authentication, click the **Enable Authentication** box and type the **Username** and **Password**.

If you do not type a password, the previous password continues to be required. If the previous password was empty and you do not enter a new password, the password remains empty.

7. Click **Save** (or click **Reset** to restore the previously-saved values).

Related Topics

[ztC Edge Console](#)

[Preferences Page](#)

[Using the ztC Edge Console](#)

Alerts History Page

The **Alerts History** page displays messages about events on the ztC Edge system.

To open the **Alerts History** page, click **Alert History** in the left-hand navigation panel of the ztC Edge Console. (To view a log of user activity on the ztC Edge system, see the [Audit Logs Page](#).)

Note: Support notification alerts, e-Alerts, and SNMP traps are generated only when you enable them in the ztC Edge Console console. For information see:



- [Configuring Remote Support Settings](#)
- [Configuring e-Alerts](#)
- [Configuring SNMP Settings](#)

To view alert information, scroll through the alerts, which are, by default, listed in reverse chronological order. Click an alert to display the time the alert occurred as well as information about the problem and resolution (if available), and whether **Support Notifications**, an **e-Alert**, or an **SNMP Trap** was sent for this alert. (You can also display alert information using `snmptable`; see [Obtaining System Information with snmptable](#).)

To remove an alert, select it and click **Remove**.

To remove all of the alerts, click **Purge All**.

Related Topics

[ztC Edge Console](#)

[Using the ztC Edge Console](#)

Audit Logs Page

The **Audit Logs** page displays a log of user activity in the ztC Edge Console. To open this page, click **Audit Logs** in the left-hand navigation panel. (To display information about events on the ztC Edge system, see the [Alerts History Page](#).)

To view log information, scroll through the log entries, which are, by default, listed in reverse chronological order. The information includes:

- **Time**—The date and time of the action.
- **Username**—The name of the user that initiated the action.

- **Originating Host**—The IP address of the host on which the ztC Edge Console was running.
- **Action**—The action performed in the ztC Edge Console.

You can also display information about audit logs using `snmptable` (see [Obtaining System Information with snmptable](#)).

Related Topics

[ztC Edge Console](#)

[Using the ztC Edge Console](#)

[Security Hardening](#)

Support Logs Page

The **Support Logs** page enables you to generate diagnostic files, which include the ztC Edge system's log files and configuration information at a particular moment in time. This information enables your authorized Stratus service representative to resolve an issue with the system.

For additional information, see:

- [Creating a Diagnostic File](#)
- [Deleting a Diagnostic File](#)
- [Uploading a Diagnostic File to Customer Support](#)

Related Topics

[ztC Edge Console](#)

[Using the ztC Edge Console](#)

[Preferences Page](#)

Creating a Diagnostic File

Diagnostic files provide the ztC Edge system's log files and configuration information at a particular moment in time. You create a diagnostic file to help your authorized Stratus service representative resolve issues with the system.



Note: Stratus Redundant Linux software allocates a fixed amount of storage space for diagnostic files. If sufficient space is not available when you create a diagnostic file, the system will delete previously created files.

To create diagnostic files

1. Click **Support Logs** in the left-hand navigation panel, to open the **Support Logs** page.
2. Click **Generate Diagnostic File**.
3. Upload the file to your authorized Stratus service representative, as described in [Uploading a Diagnostic File to Customer Support](#).

Related Topics

[ztC Edge Console](#)

[Preferences Page](#)

[Using the ztC Edge Console](#)

Uploading a Diagnostic File to Customer Support

Upload a diagnostic file to the Stratus ztC Edge Customer Support web site to help resolve an issue with the system. (To create a diagnostic file, see [Creating a Diagnostic File](#).)

To upload a diagnostic file to Customer Support

1. Click **Support Logs** in the left-hand navigation panel, to open the **Support Logs** page.
2. Do one of the following:
 - If the ztC Edge system has Internet connectivity, upload the diagnostic file directly to the Stratus ztC Edge Customer Support web site by clicking **Upload**. If the upload succeeds, a message appears, confirming that the diagnostic file was uploaded successfully.
 - If the ztC Edge system does not have Internet connectivity or if the **Upload** fails, you can manually upload the diagnostic file to the **Stratus Diagnostic Upload** web page. First, click **Download** on the ztC Edge Console to download the diagnostic file as a .zip file to your local computer. Transfer the diagnostic zip file to a computer with Internet connectivity . Open a web browser, and in its address bar, enter <http://diags.stratus.com/DiagUpload.html>. On the **Stratus Diagnostic Upload** page, click **Choose File**, select the zip file on the computer, and click **Submit**.

If you need help with this procedure, call ztC Edge Customer Support at the phone number listed on the **ztC Edge Support** page at <https://www.stratus.com/services-support/customer-support/?tab=ztcedge>.

After you are certain that you no longer need the file (for example, Customer Support confirms that the file uploaded correctly), you can optionally delete it from the ztC Edge system, as described in [Deleting a Diagnostic File](#).

Related Topics

[ztC Edge Console](#)

[Preferences Page](#)

[Using the ztC Edge Console](#)

Deleting a Diagnostic File

Delete a diagnostic file from the ztC Edge system after you have uploaded it to your authorized Stratus service representative.

To delete a diagnostic file

1. Click **Support Logs** in the left-hand navigation panel, to open the **Support Logs** page.
2. Select the diagnostic file and click **Delete**.

Related Topics

[ztC Edge Console](#)

[Preferences Page](#)

[Using the ztC Edge Console](#)

Physical Machines Page

The **Physical Machines** page enables you to manage the physical machines (PMs) in the ztC Edge system. (PMs are also referred to as nodes.) To open this page, click **Physical Machines** in the left-hand navigation panel.

State, **Activity**, **Name**, **Model**, and **# of VMs** columns appear immediately under the **PHYSICAL MACHINES** heading and masthead. To manage a specific PM, click **node0 (primary)** or **node1** (if it exists) under **Name**. To interpret PM states and activities, see [Physical Machine States and Activities](#). To display information about a node, you can use the `snmptable` command; see [Obtaining System Information with snmptable](#).

The bottom pane displays action buttons for and details about the selected node:

- **Action buttons:** Various action buttons appear, with inactive buttons grayed out, depending upon the state of the selected node. To perform most maintenance tasks, click **Work On**, which places a node into maintenance mode (for information, see [Maintenance Mode](#)). To learn about additional PM actions available in maintenance mode, see [Physical Machine Actions](#) or the help topic for the task you want to complete.
- **Detailed information:** To view detailed information or statistics about the selected node, click one of the following tabs:
 - **Summary** (in the initial display), which displays information about the node, such as (if applicable) the manufacturer, the model, serial number, overall state, activity, and configuration (memory and logical disks) for the selected node.
 - **Description**, which displays a window where you can enter information about the node.
 - **Storage**, which displays the state, logical ID, size, and size used of storage. It also displays the remaining life of SSD drives.
 - **Network**, which displays the state, name, speed, and MAC address of networks.
 - **Sensors**, which displays information about the name, state, and current value of sensors, including voltage and the temperature of the CPU and system (node).
 - **Virtual Machines**, which displays the state, activity, and name of virtual machines.
 - **USB Devices**, which lists any USB devices inserted in the node.
 - **Monitor**, which provides information about the system (for example, CPU usage and memory utilization). For information, see [Monitoring the ztC Edge System](#).

Related Topics

[ztC Edge Console](#)





[Using the ztC Edge Console](#)




Physical Machine Actions

When you select a physical machine (PM), some or all of the following action buttons appear, with inactive buttons grayed out, depending on the PM's state and activity.



Caution: Use the **Physical Machines** page of the ztC Edge Console when you perform maintenance on a PM. Avoid using controls on the computer, because the ztC Edge Console protects the ztC Edge system from most actions that are potentially disruptive.

Commands	Description
 Identify	Flashes the SYS LED on the node selected beneath Name . See Identifying a Physical Machine .
 Work On	Enters a PM into maintenance mode. VMs running on this PM migrate to the other PM, if it exists and is in service. (Otherwise, you are asked to re-confirm the request and then shut down VMs.) When VMs are migrated or shut down, the PM displays running (in Maintenance) . See Maintenance Mode .
The following actions are available on some systems after clicking the Work On button, when the PM has entered maintenance mode.	
 Finalize	Removes a PM from the state running (in Maintenance) . See Maintenance Mode .
 Shutdown	Shuts down a PM. The PM transitions to off (in Maintenance) . See Shutting Down a Physical Machine .

Commands	Description
 Reboot	Reboots the PM. The PM transitions to preparing for reboot (in Maintenance) . See Rebooting a Physical Machine .
 Remove	Causes the Stratus Redundant Linux software to delete the PM from the ztC Edge system's database, so that you can replace the PM or one of its components. See Replacing Physical Machines (Manual) .
The following action may be available when a PM has failed or when the Stratus Redundant Linux software has removed a PM from service and powered it off, due to an excessive failure rate.	
 Recover	Recovers a failed PM. In some cases, the ztC Edge Console displays the state of a failed PM as Unreachable (Syncing/Evacuating...) . See Recovering a Failed Physical Machine (Manual) .

Related Topics





[ztC Edge Console](#)













[Using the ztC Edge Console](#)

[Physical Machines Page](#)

Physical Machine States and Activities

The following states and activities apply to physical machines (PMs). Only certain actions are enabled during each state and activity.

State	Activity	Available Commands	Description
	 Running	Work On	PM is running normally.
	 Evacuating	Finalize	Virtual machines are migrating from this PM to its partner.

State	Activity	Available Commands	Description
	 Running	Work On	PM is predicted to fail.
	 Running	Work On	PM failed.
	 Powered Off	Work On	ztC Edge has powered off the PM because of an excessive failure rate.
	 Booting	Finalize	PM is booting.
	 Rebooting	Finalize	PM is rebooting.
	 Running	Finalize Shutdown Reboot Recover Replace	PM is running in Maintenance Mode. See Maintenance Mode .

Related Topics

[ztC Edge Console](#)

[Using the ztC Edge Console](#)

[Physical Machines Page](#)

Virtual Machines Page

Use the **Virtual Machines** page to manage the virtual machines (VMs) running on your ztC Edge system.

To open this page, click **Virtual Machines** in the left-hand navigation panel of the ztC Edge Console.

To manage a specific VM, click the name of a VM in the top pane of the **Virtual Machines** page. The bottom pane displays controls and information for managing the VM.

To interpret VM status as displayed on the **Virtual Machines** page, see [Virtual Machine States and Activities](#). To learn more about the controls on this page, see [Virtual Machine Actions](#) or the help topic for a specific task.

You can use the **Virtual Machines** page for administrative tasks including:

- Viewing information about a VM, including its name, operating system, description, and resources in the tabs of the bottom pane
- Creating, copying, exporting, importing, or restoring VMs, as described in [Creating and Migrating Virtual Machines](#)
- [Opening a Virtual Machine Console Session](#)
- [Reprovisioning Virtual Machine Resources](#)
- Controlling the power state of a VM, as described in:
 - [Starting a Virtual Machine](#)
 - [Shutting Down a Virtual Machine](#)
 - [Powering Off a Virtual Machine](#)
- [Removing a Virtual Machine](#) or [Renaming a Virtual Machine](#)
- Performing advanced tasks or troubleshooting, as summarized in [Advanced Topics \(Virtual Machines\)](#)
- Mounting (and unmounting) a USB device or a network-mounted folder for use by the guest operating system, as described in [Mounting a USB Device or Network-mounted Folder on the ztC Edge System](#)
- Attaching (and detaching) as USB device to a VM, as described in [Attaching a USB Device to a Virtual Machine](#)
- Monitoring Windows-based VMs and applications, as described in [Monitoring the System, Windows-based VMs, and Applications](#)

Users who are assigned the role **Administrator** or **Platform Manager** can perform all tasks on the **Virtual Machines** page. Users who are assigned the role **VM Manager** can perform all tasks, except the **VM Manager** cannot expand a volume. For details on the **VM Manager** privileges, see [Managing Virtual Machines](#). For information on assigning these roles, see [Managing Local User Accounts](#).






Related Topics









[Managing Virtual Machines](#)



[Using the ztC Edge Console](#)

Virtual Machine Actions

When you select a virtual machine (VM), the following action buttons can appear, with inactive buttons grayed out, depending on the VM's state and activity.

Action	Description
 Create	Launches the Create VM Wizard. See Creating a New Virtual Machine .
 Copy	Copies an existing VM on your system to create a new VM or to create a duplicate VM for troubleshooting. See Copying a Virtual Machine .
 Import/Restore	Imports a VM from a set of OVF and VHD files. See Creating and Migrating Virtual Machines . The import wizard allows you to <i>import</i> a VM to create a new instance of the VM or <i>restore</i> a VM to create an identical VM with the same hardware IDs provided in the OVF and VHD files.
The following actions are available for use if the VM is running.	
 Mount	Mounts a USB device or a network-mounted folder (that is, a directory) to make it available to the guest operating system. You can then export a VM to the mounted location. See Mounting a USB Device or Network-mounted Folder on the ztC Edge System .
 Unmount	Unmounts a mounted USB device or a network-mounted folder. See Mounting a USB Device or Network-mounted Folder on the ztC Edge System .

Action	Description
 Console	Opens a console for the selected VM. See Opening a Virtual Machine Console Session .
 Shutdown	Shuts down the selected VM. See Shutting Down a Virtual Machine .
 Power Off	Immediately stops processing in the selected VM and destroys its memory state. Use this only as a last resort, when the VM cannot be successfully shutdown. See Powering Off a Virtual Machine .
The following actions are available if the VM is shut down or stopped.	
 Config	Launches the Reprovision Virtual Machine wizard. The VM must be shut down prior to launching this wizard. See Reprovisioning Virtual Machine Resources .
 Restore	Recovers an existing VM on your ztC Edge system by overwriting the VM from a previous copy of OVF and VHD files. See Replacing/Restoring a Virtual Machine from an OVF File .
 Export	Saves the image of a VM to a set of OVF and VHD files. You can import these files on another system or import them back to the same ztC Edge system to restore or duplicate the original VM. See Exporting a Virtual Machine .
 Start	Boots the selected VM. See Starting a Virtual Machine .
 Boot From CD	Boots a VM from the selected virtual CD. See Bootting from a Virtual CD .

Action	Description
 Remove	Removes a VM. See Removing a Virtual Machine .
The following action is available if the Stratus Redundant Linux software has removed the VM from service and powered it off because an excessive failure rate.	
 Reset Device	<p>Resets the mean time between failures (MTBF) counter for a VM so it can be brought back into service. See Resetting MTBF for a Failed Virtual Machine.</p> <p>When a VM crashes, the Stratus Redundant Linux software automatically restarts it, unless it has fallen below its MTBF threshold. If the VM is below the MTBF threshold, the Stratus Redundant Linux software leaves it in the crashed state. If necessary, you can click Reset Device to restart the VM and reset the MTBF counter.</p>

Related Topics



[Managing the Operation of a Virtual Machine](#)






[Virtual Machines Page](#)









[Using the ztC Edge Console](#)

Virtual Machine States and Activities

A virtual machine (VM) can have the following states and activities, during which only certain actions are enabled.

State	Activity	Enabled Actions	Description
	 Installing		The Stratus Redundant Linux software is installing the boot volume for a new VM.

State	Activity	Enabled Actions	Description
	 stopped	Start Copy Config Export Boot From CD Remove	VM has been shut down or powered off.
	 booting	Console Power Off	<p>VM is starting.</p> <p>A VM remains in the booting state until the system detects network activity from the guest operating system, at which point the VM enters the running state.</p> <p>If a VM fails to enter the running state, open a console window to the VM and verify that the network settings in the guest operating system are correct. If you recently imported or migrated the VM from another system, see any OS-specific procedures or troubleshooting information in Importing an OVF or OVA File or Migrating a Physical Machine or Virtual Machine to a System.</p>
	 running	Console Shutdown Power Off	VM is operating normally on redundant physical machines

State	Activity	Enabled Actions	Description
	 running	Console Shutdown Power Off	VM is operating normally, but is not running on fully redundant resources.
	 stopping	Power Off Remove	VM is being shut down in response to the Shutdown action, or shut down because the remaining physical machine is transitioning into maintenance mode.
	 crashed		VM crashed and is restarting. If enabled, e-Alerts and support notification messages are sent.
	 crashed		VM crashed too many times and exceeded its MTBF threshold. The VM is left in a crashed state until Reset Device is clicked. See Resetting MTBF for a Failed Virtual Machine .

Related Topics

[Managing the Operation of a Virtual Machine](#)

[Virtual Machines Page](#)

[Using the ztC Edge Console](#)

Volumes Page

The **Volumes** page displays information about volumes that are attached to virtual machines (VMs) in the ztC Edge system. To open this page, click **Volumes** in the left-hand navigation panel of the ztC Edge Console. The **Volumes** page displays the following columns with information about volumes in the top pane:

- **State**
- **Name**

- **Disk Synchronization** (if it exists)
- **Size**
- **Bootable**
- **Used By**, which displays one of the following:
 - A link to a VM when a VM is using the volume.
 - A link to the physical machine (PM) page (**node0** or **node1**, if it exists) when the volume is **root** or **swap**.
 - **System** for a shared volume (**shared.fs**) .
 - **None** when the volume is not a system volume and is not used by a VM.

Click the name of a volume in the top pane of the **Volumes** page to display additional information about the volume in the bottom pane. (You can also display information about volumes using the `snmptable` command; see [Obtaining System Information with snmptable](#).) You can perform some administrative tasks on volumes from the bottom pane, including:

- Add a description for each volume in the **Description** text box.
- Rename a volume (see [Renaming a Volume on the ztC Edge System](#)).
- Remove a volume by clicking **Remove**. Note, though, that the **Remove** button is grayed out when a VM is using a volume.

You perform other volume management tasks from the virtual machines page. These tasks include:

- [Attaching a Volume to a Virtual Machine](#)
- [Creating a Volume in a Virtual Machine](#)
- [Detaching a Volume from a Virtual Machine](#)
- [Removing a Volume from a Virtual Machine](#)

Related Topics

[ztC Edge Console](#)

[Using the ztC Edge Console](#)

Networks Page

The **Networks** page displays information about the shared networks attached to the ztC Edge system. To open this page, click **Networks** in the left-hand navigation panel of the ztC Edge Console.

You can use the **Networks** page to view information about a specific network, including its state, link condition, name, internal name, type, number of connected Virtual Machines (VMs), speed, and MTU. You can also add a description for the network using the **Description** tab in the bottom pane.

To manage a specific network or simply view information about it, click the network name under **Name** or **Internal Name** in the top pane of the **Networks** page, or click a port in the network connectivity diagram on the **Summary** tab. The bottom pane displays additional information about nodes on the network. Columns in the **Summary** tab display information about the node's state, physical interface, speed, MAC address, slot, and port. To display or hide columns, move the cursor to the right of a column heading, click the down-arrow that appears, and then click **Columns**, selecting or de-selecting the columns that you want to show or hide.

You can use the **Networks** page for administrative tasks, including:

- Viewing a list of the physical adapters that compose the network, on the **Summary** tab.
- Adding a description for a network, on the **Description** tab.
- Viewing a list of virtual machines that use the network, on the **Virtual Machines** tab.
- Changing the name by double-clicking the name in the **Name** column.
- [Setting the MTU](#) for A-Link and business networks.

For additional information on networks, see the following:

- [Network Architecture](#)
- [Connecting Ethernet Cables](#)
- [General Network Requirements and Configurations](#)
- [Meeting Network Requirements](#) for ALSR configurations



Note: The **Networks** page displays only networks that have physical connectivity on both physical machines. If a network that you expect to see does not appear, check that both network connections are cabled correctly and that their LINK is active.

Related Topics

[ztC Edge Console](#)

[Using the ztC Edge Console](#)

Setting the MTU

Network performance improves with the highest maximum transmission unit (MTU) that the network can support. You can specify the MTU value for A-link and business (biz) networks using the **Networks** page of the ztC Edge Console.



Note: When you change the MTU of either business network `ibiz0` (also referred to as `network0`) or `ibiz1` (also referred to as `network1`) on a dual-node system, the system automatically migrates the VMs from one node to the other. If you change the MTU for `ibiz0` specifically, the system also automatically fails over from the primary node to the secondary node. To avoid this issue, avoid changing the MTU of the business networks, or change the MTU only during a planned maintenance period.

On a single-node system, the VMs shutdown, so you should avoid changing the MTU. If you must change it, do so only during a planned maintenance period.



Prerequisite: If you want to change the MTU on a business network of a single-node system, shut down all VMs using that network before changing the MTU.

To set the MTU of an A-Link or business network

1. Click **Networks** in the left-hand navigation panel, to open the **Networks** page.
2. In the top pane, select the A-link or business network whose MTU you want to set.
3. Click **Config**.
4. In the **Configure Shared Network** window, select the **Network Role (Business or A-Link)**.

5. Under **MTU**, type a bytes value from 1280 to 65535. The default values are:

System Model	MTU Values for Ethernet Ports	
	Port A1 (for A-Link1) and Port A2 (for priv0) (Dual-node Systems, Only)	Ports P1 - P6 (ibiz0 - ibiz5)
100i	1500	1500
110i	9000	1500
200i	9000	1500
250i	9000	1500

6. Click **Save**.

Related Topics

[Networks Page](#)

[ztC Edge Console](#)

[Using the ztC Edge Console](#)

Virtual CDs Page

Use the **Virtual CDs** page to create virtual CDs (VCDs). Use VCDs to make software installation or recovery media available to the virtual machines on the system. To open this page, click **Virtual CDs** in the left-hand navigation panel of the ztC Edge Console.

To manage a specific VCD, click the name of a VCD in the top pane of the **Virtual CDs** page. The bottom pane displays a description of the VCD.

You can use the **Virtual CDs** page for administrative tasks including:

- [Creating a Virtual CD](#)
- [Removing a Virtual CD](#)
- [Renaming a Virtual CD](#)
- Adding a description for each volume, in the **Description** text box

To complete other VCD management tasks, see [Managing Virtual CDs](#).

Related Topics

[Inserting a Virtual CD](#)

[Ejecting a Virtual CD](#)

[Using the ztC Edge Console](#)

Upgrade Kits Page

The **ztC Edge Upgrade Kits** page enables you to upload and manage upgrade kits that you use to upgrade the system to newer versions of the Stratus Redundant Linux software. You can check whether or not a new version of system software is available, and then download it, if available. You can also copy an upgrade kit to a USB medium in order to use the medium when reinstalling the system software.

To open the **Upgrade Kits** page, click **Upgrade Kits** in the left-hand navigation panel in the ztC Edge Console.



Note: You can specify that an available upgrade kit is downloaded automatically. You can also enable an email alert (e-Alert) to be sent to system administrators, notifying them when an update of system software is available. See [Managing Software Updates](#).

To check for and download a new version of the system software



Note: Your user role must be **Administrator** or **Platform Manager** to perform this procedure.

1. Click **Upgrade Kits** in the left-hand navigation panel to open the **Upgrade Kits** page.
2. Click **Check for Updates** beneath the masthead.

A message box appears, indicating whether or not a new version of the system software is available.

3. If an update is available, the **Software Update Available** box appears, and you can click **Download Software** to download the software. You can also click **View Release Notes** to read about the update (English version).



Note: The **Upgrade Kits** page allows only two saved kits. If the page lists two kits and you want to download another kit, you first need to delete a kit.

When you click **Download Software**, the following occurs:

- If the ztC Edge system is connected to the Internet, a **.kit** file with the software update is downloaded directly to the system and is listed on the **Upgrade Kits** page. Various status messages appear in the **Software Update Available** box, indicating the progress of the download.
 - If the system is not connected to the Internet, the **.kit** file is downloaded to the remote management computer that is running the ztC Edge Console. Save the file to the browser's default downloads folder, or navigate to another location. You will receive an Alert (if configured) notifying you that a new version of the system software is available and that you need to upload it to the system.
4. To continue the upgrade, see [Upgrading Stratus Redundant Linux Software Using an Upgrade Kit](#).

For information about upgrading the Stratus Redundant Linux software, see [Upgrading Stratus Redundant Linux Software](#).

For information about creating a USB medium, see [Creating a USB Medium with System Software](#).

Related Topics

[ztC Edge Console](#)

[Using the ztC Edge Console](#)

Creating a USB Medium with System Software

You can use the **Upgrade Kits** page to create a USB medium with a copy of the deployment ISO file of the system software, Stratus Redundant Linux. You then use the USB medium to reinstall the software if you need to manually recover or replace a failed node.



Note: Copying an upgrade kit to a USB medium dismounts file systems, if any, from the medium.

To create a USB medium with system software

1. Download an upgrade kit, if you have not already done so. See [Upgrading Stratus Redundant Linux Software Using an Upgrade Kit](#).
2. Insert a USB medium into the primary node. On the **Physical Machines** page, check that the **USB Devices** tab lists the device.
3. In the ztC Edge Console, click **Upgrade Kits** in the left-hand navigation panel.
4. If the **Upgrade Kits** page lists more than one kit, select the version with the ISO that you want to copy.
5. Click the **Create USB Medium** button (beneath the masthead).

The **Create USB Medium** dialog box opens.

6. If the node has more than one USB medium, you need to select a medium from the drop-down list. Then, click **Continue** (or click **Cancel** to cancel the procedure).

The **Create USB Medium** dialog box displays the percentage of progress. The window closes when copying has finished.

Use the USB medium to reinstall the software if you need to manually recover or replace a failed node. See [Recovering a Failed Physical Machine \(Manual\)](#) or [Replacing Physical Machines \(Manual\)](#).

Related Topics

[Upgrade Kits Page](#)

4

Chapter 4: Upgrading Stratus Redundant Linux Software

To upgrade Stratus Redundant Linux software, use an upgrade kit. See [Upgrading Stratus Redundant Linux Software Using an Upgrade Kit](#).

Related Topics

[Managing Software Updates](#)

[Upgrade Kits Page](#)

[ztC Edge Console](#)

[Using the ztC Edge Console](#)

Upgrading Stratus Redundant Linux Software Using an Upgrade Kit

This topic describes how to use an upgrade kit of Stratus Redundant Linux software to upgrade the system software. The topic also explains how to download the kit and then upload it to the system, if you need to do so before upgrading the system. For systems configured with two nodes, you can optionally control the upgrade by enabling pauses (you cannot enable pauses on a system configured with one node). Inspecting a system during a pause is useful for verifying or reconfiguring third-party tools or other services that are not managed by the system.



Caution: Do not update the CentOS host operating system of the ztC Edge system from any source other than Stratus. Use only the release that is installed with the Stratus Redundant Linux software.

Prerequisites:

- For the latest information about upgrade paths and restrictions, see the Stratus Redundant Linux Release 2.3.0.0 Release Notes at <http://ztcedgedoc.stratus.com>.
- All PMs and VMs must be in good health before upgrading the system software. Before starting an upgrade, examine the ztC Edge Console to verify that there are no alerts indicating PM or VM problems.
- Eject any VCDs or USB media from the VMs before upgrading the system software. If VCD or USB media is still connected to the VMs, it prevents the system from migrating the VMs and putting the PMs into maintenance mode for the upgrade process.
- To verify that the system meets the requirements of the upgrade kit, use the **Qualify** button, as described in this topic.
- Before you upgrade a system configured with one node, you should back up the VMs. Then, upgrade and qualify the software following the instructions below. Finally, upgrade the one PM of the system using the procedure in [To upgrade a system configured with one node](#). The upgrade includes at least a 15-minute loss of access to the ztC Edge Console as the system reboots during the upgrade procedure.

The steps are:

- I. [To download the upgrade kit](#)
- II. [To upload the upgrade kit to the system](#)
- III. [To qualify the software](#) (optional)
- IV. [To upgrade the system software](#)

I. To download the upgrade kit

When an update is available, you can download the upgrade kit that contains the new system software, if it is not already downloaded. From the **Upgrade Kits** page, click **Download Software** in the **Software Update Available** window (see the [Upgrade Kits Page](#)).

Alternatively, you can download the software from the Stratus **Downloads** page.



Note: The **Upgrade Kits** page of the ztC Edge Console allows only two saved kits. If the page lists two kits and you want to download another kit, you first need to delete a kit.

1. Open the **Downloads** page at <https://www.stratus.com/services-support/downloads/?tab=ztcedge>.
2. Scroll down to the upgrade section and then click the upgrade link to download the kit.
3. Navigate to a location on a local computer to save the file. If necessary, transfer the file to the remote management computer running the ztC Edge Console.

II. To upload the upgrade kit to the system

Upload the upgrade kit, if necessary, to the ztC Edge system from the remote management computer that is running the ztC Edge Console.

1. In the ztC Edge Console, click **Upgrade Kits** in the left-hand navigation panel.
2. On the **Upgrade Kits** page, click the **Add a Kit** button beneath the masthead, which opens the **ztC Edge - Kit Upload Wizard**.
3. In the **ztC Edge - Kit Upload Wizard** dialog box, click **Choose File** (in Google Chrome) or **Browse** (in Firefox or Internet Explorer), and then browse to select a .kit file.
4. After you have selected a .kit file, click **Upload**, **Import**, or **Finish** (they perform the same function). A message such as **Uploading file (DO NOT CLOSE WIZARD)** appears while the file is uploading. The upload may require up to two minutes for a file stored locally, to ten or more minutes for a file stored over a network. If the upload fails, the wizard displays the message **Failed to upload file**.
5. After the upload is complete, the wizard closes and the **Upgrade Kits** page lists the state and version number of the upgrade kit. The **Qualify**, **Upgrade**, and **Delete** buttons also appear with the **Add a Kit** button.
6. If more than one upgrade kit is loaded, select the one to use.

III. To qualify the software

Qualify the software to verify that your system meets the requirements of the upgrade kit. (Qualifying the software is recommended, but not required.)

To do so, select the upgrade kit you want to qualify on the **Upgrade Kits** page, and then click **Qualify**.

The qualification may require up to six minutes. If the qualification succeeds, continue with the next step.

If the qualification fails, a pop-up window appears with messages indicating the cause of the failure. These messages may indicate unsupported releases, insufficient storage, partition problems, VMs that need to be shut down, or other information associated with upgrading the system. For example, if the system has insufficient disk space to complete the upgrade, the message `Insufficient free space` appears

reporting the amount of space needed. If you need help resolving a qualification issue, search for the qualification error message in the **Knowledge Base** in the **Stratus Customer Service Portal** at <https://service.stratus.com>.

IV. To upgrade the system software

1. Begin the upgrade by clicking **Upgrade** on the **Upgrade Kits** page.

A **Confirm** window appears, stating that you have chosen to upgrade the system and displaying a message asking you to confirm the upgrade to the selected upgrade kit. The window also includes a check box for you to enable pauses, allowing you to control the upgrade. Enable pauses by clicking the box **Pause after individual node upgrades**.

2. Click **Yes** to continue the upgrade.

The upgrade begins. If you enabled pauses, the diagram illustrating the upgrade steps displays the current state of the upgrade. When the upgrade pauses, you must click **Finalize** to continue.

After one node has been upgraded, but the other node (if it exists) has not yet been upgraded, the nodes are running different versions of the software. During this time, the masthead displays the message **System is running with mismatched versions**.

After the upgrade is complete, check for updated virtIO drivers on all Windows-based VMs, as described in [Updating the VirtIO Drivers \(Windows-based VMs\)](#).

To upgrade a system configured with one node

1. Shut down all VMs that are running on the ztC Edge system.
2. Upgrade the system with an upgrade kit, using the instructions in the steps above.



Note: The upgrade includes at least a 15-minute loss of access to the ztC Edge Console as the system reboots during the upgrade procedure.

3. Ensure that the system is running correctly.
4. Start all of the VMs.

Related Topics

[Managing Software Updates](#)

[Upgrade Kits Page](#)

[ztC Edge Console](#)

[Using the ztC Edge Console](#)

[ztC Edge System Description](#)

5

Chapter 5: Managing Physical Machines

Manage a physical machine (PM), or node, to control its operation and perform maintenance.

You view and manage PMs using the **Physical Machines** page of ztC Edge Console; for information, see the [Physical Machines Page](#).

Many of the tasks you perform from the **Physical Machines** page require maintenance mode; for information, see [Maintenance Mode](#).

To manage the operational state of a PM (in maintenance mode), see:

- [Rebooting a Physical Machine](#)
- [Shutting Down a Physical Machine](#)
- [Load Balancing](#)

To power on a PM (at the physical console of the PM), see [Powering On a Physical Machine](#).

To troubleshoot a PM by recovering a failed PM or resetting MTBF for a failed machine, see [Troubleshooting Physical Machines](#).

To perform maintenance tasks on the PM hardware, such as replacing a PM, see [Maintaining Physical Machines](#).

To monitor the host operating system of the ztC Edge system on systems licensed for such monitoring, see [Monitoring the ztC Edge System](#).

Maintenance Mode

When a physical machine (PM) enters maintenance mode, it goes offline for service. When you finalize service, the PM exits maintenance mode and goes back online, becoming available for running virtual

machines (VMs).

For a system configured with two nodes (that is, two PMs), note the following:

- When one PM enters maintenance mode, the PM migrates the VMs running on it to the other PM, which protects the VMs from any potential disruption caused by the service. When both PMs enter maintenance mode, the PMs perform an orderly shutdown of all VMs, which protects their memory state before the PMs shut down or reboot.
- When the primary PM (**nodex (primary)**) enters maintenance mode, the other PM becomes primary.
- If you want both PMs in maintenance mode, first enter the secondary PM into maintenance mode, and then enter the primary PM into maintenance mode. This sequence avoids the unnecessary migration of VMs.

For a system configured with one node (that is, one PM), the PM shuts down VMs when it enters maintenance mode. So, place the PM in maintenance mode only during a planned maintenance period.

Shut down the PMs only from the **Physical Machines** page with the PM in maintenance mode because the ztC Edge Console protects the system from disruptive action that results from manually powering down a PM.


Cautions:



1. The system is not fault tolerant when a PM is in maintenance mode. For continuous uptime, finalize service as soon as possible so that the PM can exit maintenance mode and go back online.
2. Place all PMs in maintenance mode only if you are able to shut down all business processing. If you need to keep VMs running on a system configured with two PMs, avoid entering both PMs into maintenance mode at the same time. To keep VMs running, at least one PM must be up and running normally. (If you need to shut down the entire ztC Edge system, see [Shutting Down a Physical Machine.](#))

To enter a PM into maintenance mode

1. Select a PM from the **Physical Machines** page.
2. Click **Work On**.

When the PM is in maintenance mode, its state displays .

To finalize and exit a PM from maintenance mode

1. Select a PM from the **Physical Machines** page.
2. Click **Finalize**, which exits the PM from maintenance mode.

Related Topics

[ztC Edge Console](#)

[Managing Physical Machines](#)

[Physical Machines and Virtual Machines](#)

[Physical Machines Page](#)

[Virtual Machines Page](#)

Powering On a Physical Machine

Power on a physical machine (PM) at the physical console of the PM.



Note: If a PM loses power because you disconnect the power cord or the AC mains power is lost, each PM in a ztC Edge system is set to power on automatically as soon as power is restored.

To power on a PM

1. Press the power button on the front panel of the PM.
2. Ensure that the **PWR** LED or power button on the front panel is lit.

If you want to power on the system, press the power button on the front panel of each PM in the system, as described in [Powering On the System](#).

Related Topics

[Maintenance Mode](#)

[ztC Edge Console](#)

[Managing Physical Machines](#)

[Physical Machines Page](#)

Identifying a Physical Machine

If your user account has the role **Administrator** or **Platform Admin**, you can identify a physical machine (PM) by flashing its SYS LED.

To identify a physical machine

1. Determine the PM (node0 or node1, if it exists) that you want to identify.
2. In the ztC Edge Console, click **Physical Machines** in the left-hand navigation panel.
3. Select the appropriate PM (node0 or node1, if it exists) and then click **Identify**, which causes the selected PM's SYS LED to flash rapidly for 30 seconds.

Related Topics

[ztC Edge Console](#)

[Physical Machines Page](#)

[Using the ztC Edge Console](#)

Rebooting a Physical Machine

Reboot a physical machine (PM) to restart its Stratus Redundant Linux software, and optionally exit the PM from maintenance mode. (If you need to reboot both PMs in a system configured with two nodes, see [Rebooting the System](#).)

If you are rebooting the one PM of a single-node system, do so only during a planned maintenance period, since rebooting the PM will shutdown VMs and you need to manually restart them.

To reboot a PM

1. Determine which PM (node0 or node1, if it exists) you want to reboot. If appropriate, use the **Identify** button (see [Identifying a Physical Machine](#)).
2. In the ztC Edge Console, click **Physical Machines** in the left-hand navigation panel.
3. Select the appropriate PM (node0 or node1, if it exists) and then click **Work On**, which changes the PM's **Overall State** to **Maintenance Mode** and the **Activity** state to **running (in Maintenance)**.
4. Click **Reboot**. As the PM reboots, the **Activity** state displays:
 - **preparing for reboot (in Maintenance)**
 - **rebooting (in Maintenance)**

- booting (in Maintenance)
 - running (in Maintenance).
5. To exit the PM from maintenance mode and make it available for running virtual machines, click **Finalize**.

On a single-node system, you need to manually restart VMs.

Related Topics

[Maintenance Mode](#)

[ztC Edge Console](#)

[Managing Physical Machines](#)

[Physical Machines Page](#)

Shutting Down a Physical Machine

Shut down a physical machine (PM), or node, to stop it from running when you need to service or replace the PM. Use the following procedures to shut down one and only one PM by using the ztC Edge Console or the power button on the PM.

Cautions:



1. Data loss will occur if you use the following procedures to shut down both PMs of a ztC Edge system configured with two nodes or the one PM of a system configured with one node. If you need to stop both PMs of a system configured with two nodes or the one PM of a system configured with one node, shut down the system (which also shuts down the virtual machines (VMs)), as described in [Shutting Down the System](#).
2. Do not use the `-f` (force) option with the `halt`, `poweroff`, or `reboot` command of the host operating system of a PM. Doing so causes guests that are active on the same PM to hang.
3. A ztC Edge system configured with two nodes is not fault tolerant when you shut down a PM. For continuous uptime, bring an offline PM back into service as soon as possible.



Note: When you shut down a PM, standby power remains on for lights-out management unless you disconnect the power cord or AC mains power is lost.

To shut down a PM in the ztC Edge Console

To shut down a PM, you must place the PM into maintenance mode, which migrates any VMs running on that PM to the remaining PM (if it exists). On a system with two nodes, the VMs continue to run during this process, which takes a minute or two.

1. Determine which PM you want to shut down. If appropriate, use the **Identify** button (see [Identifying a Physical Machine](#)).
2. In the ztC Edge Console, click **Physical Machines** in the left-hand navigation panel.
3. Select the appropriate PM (node0 or node1, if it exists) and then click **Work On**, which changes the PM's **Overall State** to **Maintenance Mode** and the **Activity** state to **running (in Maintenance)**.
4. After the PM displays **running (in Maintenance)**, click **Shutdown**.

After the PM has shut down, its activity is **✗ off (in Maintenance)**. You must manually restart the PM.

To shut down a PM with the power button

To shut down a PM by using the power button

You can also shut down a PM by using the power button on the PM. On a system configured with two nodes, the VMs continue to run during this process, which takes a minute or two.

1. While both PMs are running, press and release the power button on the front panel of the PM that you want to shut down.
2. The system automatically places the PM into maintenance mode, which migrates the VMs running on the PM to the remaining PM.
3. The PM automatically shuts down.

When the PM shuts down, the **PWR** LED or power button on the front panel is not lit, though standby power remains. You must manually restart the PM.

To forcibly power off a PM by using the power button



Caution: If a PM does not turn off after you click **Shutdown** or press the power button, you may need to forcibly power off the PM. Forcibly powering off a PM destroys its memory state; therefore, do this only as a last resort.

Press the power button on the PM for several seconds to forcibly remove power.

When the PM powers off, the **PWR** LED or power button on the front panel is not lit, though standby power remains. You must manually restart the PM.

Related Topics

[Maintenance Mode](#)

[ztC Edge Console](#)

[Managing Physical Machines](#)

[Physical Machines Page](#)

Load Balancing

On systems configured with two nodes, HA Load Balancing distributes VMs across both PMs to improve performance and availability. Load balancing is configured per VM and is enabled automatically on ztC Edge systems. (Systems configured with one node do not provide load balancing.) If a PM is out of service, all VMs will run on the surviving PM. VMs automatically migrate back as soon as the PM they are targeted to run on returns to service and is fully synchronized.

Modes of Operation

Load balancing is set for a VM on its **Load Balance** tab on the **Virtual Machines** page. The following modes are supported:

- **automatically balance.** This provides automatic load balancing of a VM. When a VM is set to balance automatically, it will run on the available PM with the most resources. When the system determines that better load balancing can be achieved by moving one or more VMs with the automatic setting, an alert is generated. The alert appears on the Dashboard, and a Load Balancing notification appears on the masthead. In response to the alert, click **Load Balance** in the masthead to initiate automatic load balancing of a VM.

The icon on the **Virtual Machines** page under **Current PM** column indicates VMs that will migrate imminently.

- **manually place on nodeN.** Advanced users can manually assign a preferred PM (node) for each individual VM, rather than relying on the automatic policy, if preferred.

A graphic appears on the **Virtual Machine** page in the **Current PM** column for each VM. It indicates the current status of the VM's load-balancing state, the PM the VM is running on, and its preference.

The following sample graphic indicates that the VM is currently on PM 0 and that PM 1 is the preference.



ztC Edge policy ensures that a VM is always running. In the event that one PM is predicted to fail, is under maintenance, or is taken out of service, the VM will run on the healthy PM. When both PMs are healthy, a VM migrates to its preferred PM.

Related Topic

[Selecting a Preferred PM for a Virtual Machine](#)

Troubleshooting Physical Machines

The following topics describe troubleshooting procedures for PMs:

- [Understanding ztC Edge LED States](#)
- [Recovering a Failed Physical Machine \(Manual\)](#)

If you cannot recover a PM using the software-based troubleshooting procedure above, see [Maintaining Physical Machines](#) for information about replacing the physical PM hardware.

Understanding ztC Edge LED States

Status LEDs are located on the front panel of each ztC Edge node. The following tables summarize the LED states and meanings.

SYS LED (All ztC Edge Nodes)

The SYS LED reports the overall status of a ztC Edge node, indicating whether the node is healthy or unhealthy. Although the color of the SYS LED varies by ztC Edge model, the SYS LED states and meanings are identical for each model.



Note: The SYS LED state is only a summary of system health. For more detailed system status, alerts, and especially information about the health of virtual machines running on the system, it is also important to monitor the system in the ztC Edge Console.

Some of the states and activities reported in the ztC Edge Console are summarized in online Help topics including [Physical Machine States and Activities](#) and [Virtual Machine States and Activities](#).

LED State	Meaning	Duration
Off	Node is unhealthy, unless powered off or just powered on	Constant
On	Node is unhealthy, unless just starting to boot or upgrading software	Constant
Flashing (1 second)	Normal/healthy operation: capable of managing VMs	Continues flashing as long as the system is healthy. There is a 5 minute grace period of flashing for system management restarts and other recovery. If system management cannot recover after 5 minutes, it sets the LED to Off (unhealthy).
Flashing (500ms)	Identifying node: clicking Identify on the Physical Machines page of the ztC Edge Console identifies a physical node for special attention	Continues flashing for 1 minute, then reverts to previous state

PWR LED (ztC Edge 1xxi Nodes) or Power Button (ztC Edge 2xxi Nodes)

The PWR LED or illuminated power button on a ztC Edge node reports the power state of the node.

LED State	Meaning	Duration
Off	Powered off	Constant
On	Powered on	Constant

HDD or SSD LED (ztC Edge 1xxi Nodes Only)

The HDD or SSD LED reports the hard disk activity of a ztC Edge node.

LED State	Meaning	Duration
Off	No activity, or node is powered off	Constant
Flashing	Disk reads/writes are in progress	Varies based on level of activity

Recovering a Failed Physical Machine (Manual)



Caution: If you need to recover or replace a PM in a ztC Edge system, use the instructions in [ztC Edge 100i/110i Systems: Replacing a Node \(R013Z\)](#) or [ztC Edge 200i/250i Systems: Replacing a Node \(R019Z\)](#). (If needed, see [Replacing Physical Machines \(Automated\)](#) for additional details.) Avoid using the manual procedure described in this topic unless specifically instructed by your authorized Stratus service representative.

Recover a physical machine (PM), or node, when it cannot boot or if it fails to become a PM of a dual-node ztC Edge system. In some cases, the ztC Edge Console displays the state of a failed PM as **Unreachable (Syncing/Evacuating)**.

To recover a PM, you must reinstall the Stratus Redundant Linux release that the PM has been running. Recovering a failed PM, though, is different from installing the software for the first time. The recovery preserves all data, but it re-creates the `/boot` and `root` file systems, re-installs the Stratus Redundant Linux system software, and attempts to connect to the existing system. (If you need to replace the physical PM hardware instead of recovering the system software, see [Replacing Physical Machines \(Manual\)](#).)

To reinstall the system software, you can allow the system to automatically boot the replacement node from a temporary Preboot Execution Environment (PXE) server on the primary PM. As long as each PM contains a full copy of the most recently installed software kit (as displayed on the **Upgrade Kits** page of the ztC Edge Console), either PM can initiate the recovery of its partner PM with PXE boot installation. If needed, you can also manually boot the replacement node from USB installation media.

Use one of the following procedures based on the media you want to use for the installation, either **PXE** or **USB** installation.



Caution: The recovery procedure deletes any software installed in the host operating system of the PM and all PM configuration information entered before the recovery. After you complete this procedure, you must manually re-install all of your host-level software and reconfigure the PM to match your original settings.

Prerequisites:

1. Determine which PM you need to recover.
2. If you want to use a USB medium to install the system software on the replacement PM, create a bootable USB medium as described in [Creating a USB Medium with System Software](#).



When creating the USB medium, ensure that it contains the most recently installed upgrade kit. For example, if the release shown in the masthead of the ztC Edge Console window is version 1.2.0-550, where 550 is the build number, the kit you select to create the USB medium on the **Upgrade Kits** page must also be version 1.2.0-550. If the system detects a different build on the target PM, it automatically overrides the recovery process, **initializes all data** on the target PM, and uses PXE boot installation to reinstall the most recently installed software kit on the PM with no user interaction.

3. If using a USB medium, connect a keyboard and monitor to the replacement PM to monitor the installation process and specify settings.

To recover a PM (with PXE boot installation)

Use the following procedure to recover a PM by using PXE boot installation to reinstall the system software from the software kit on the primary PM.

1. In the ztC Edge Console, click **Physical Machines** in the left-hand navigation panel.
2. Select the appropriate PM (node0 or node1) and then click **Work On**, which changes the PM's **Overall State** to **Maintenance Mode** and the **Activity** state to **running (in Maintenance)**.
3. After the PM displays **running (in Maintenance)**, click **Recover**.
4. When prompted to select the type of repair, click **PXE PM Recover - Preserve Data**.



Caution: It is important to select **PXE PM Recover: Preserve data**; otherwise, the installation process may delete data on the target PM.

5. Click **Continue** to begin the recovery process. The system reboots the target PM in preparation for the system software reinstallation.
6. The recovery process continues with no user interaction, as follows:

- The target PM begins to boot from a PXE server that temporarily runs on the primary node.
- The target PM automatically starts the system software installation, which runs from a copy of the installation kit on the primary node.
- The installation process reinstalls the system software, while preserving all data.

You do not need to monitor the progress of the software installation or respond to prompts at the physical console of the target PM. The recovery process is automated, and it is normal for the PM to display a blank screen for a long period of time during the software installation.

7. When the software installation is complete, the target PM reboots from the newly installed system software.
8. As the target PM boots, you can view its activity on the **Physical Machines** page of the ztC Edge Console. The **Activity** column displays the PM as **(in Maintenance)** after the recovery is complete.
9. If applicable, manually reinstall applications and any other host-level software, and reconfigure the PM to match your original settings.
10. When you are ready to bring the target PM online, click **Finalize** to exit maintenance mode. Verify that both PMs return to the **running** state and that the PMs finish synchronizing.



Note: When the target PM exits maintenance mode, the system automatically disables the PXE server on the primary node that was used for the recovery process.

To recover a PM (with USB installation)

Use the following procedure to recover a PM by reinstalling the system software from a USB medium.

1. In the ztC Edge Console, click **Physical Machines** in the left-hand navigation panel.
2. Select the appropriate PM (node0 or node1) and then click **Work On**, which changes the PM's **Overall State** to **Maintenance Mode** and the **Activity** state to **running (in Maintenance)**.
3. After the PM displays **running (in Maintenance)**, click **Recover**.
4. When prompted to select the type of repair, click **USB PM Recover - Preserve Data**.



Caution: It is important to select **USB PM Recover: Preserve data**; otherwise, the installation process may delete data on the target PM.

5. Click **Continue** to begin the recovery process. The system shuts down the target PM in preparation for the system software reinstallation.
6. Connect the bootable USB medium to the target PM, and then manually power on the PM.
7. As the target PM powers on, enter the firmware (UEFI) setup utility. In the **Save & Exit** menu, under **Boot Override**, select the **UEFI** entry for the USB medium to boot from the device one time during the next boot sequence. The PM restarts.



Note: Use the **Boot Override** property to temporarily change the boot device instead of modifying the persistent **BOOT ORDER Priorities** in the **Boot** menu. The top boot priority must remain **UEFI Network** (default) to support the automated node replacement that is typically performed on ztC Edge systems.

8. Monitor the installation process at the physical console of the target PM.
9. At the **Welcome** screen, use the arrow keys to select the country keyboard map for the installation.
10. At the **Install or Recovery** screen, select **Recover PM, Join system: Preserving data** and press **Enter**. The recovery process continues with no user interaction.



Caution: It is important to select **Recover PM, Join system: Preserving data**; otherwise, the installation process may delete data on the target PM.

11. When the software installation is complete, the target PM reboots from the newly installed system software.
12. As the target PM boots, you can view its activity on the **Physical Machines** page of the ztC Edge Console. The **Activity** column displays the PM as **(in Maintenance)** after the recovery is complete.
13. If applicable, manually reinstall applications and any other host-level software, and reconfigure the PM to match your original settings.
14. When you are ready to bring the target PM online, click **Finalize** to exit maintenance mode. Verify that both PMs return to the **running** state and that the PMs finish synchronizing.

Related Topics

[Maintenance Mode](#)

[Managing Physical Machines](#)

[ztC Edge Console](#)

[Physical Machines Page](#)

6

Chapter 6: Managing Virtual Machines

Manage a virtual machine (VM) to control its operation, provision its resources, or configure its guest operating systems and applications.

You can view and manage VMs on the **Virtual Machines** page of the ztC Edge Console, which you access as described in [Virtual Machines Page](#). To perform specific management tasks, see the following topics.

To manage the operational state of a VM, see:

- [Starting a Virtual Machine](#)
- [Shutting Down a Virtual Machine](#)
- [Powering Off a Virtual Machine](#)
- [Opening a Virtual Machine Console Session](#)
- [Renaming a Virtual Machine](#)
- [Removing a Virtual Machine](#)

To display information about a VM, use the `snmptable` command (see [Obtaining System Information with snmptable](#)).

To create or configure a VM, see:

- [Planning Virtual Machine Resources](#) (virtual CPUs, memory, storage, and networks)
- [Creating and Migrating Virtual Machines](#)
- [Managing Virtual CDs](#)
- [Configuring Windows-based Virtual Machines](#)

- [Configuring Linux-based Virtual Machines](#)
- [Managing Virtual Machine Resources](#)

To attach a USB device to a VM, see [Attaching a USB Device to a Virtual Machine](#).

To complete advanced tasks, see:

- [Assigning a Specific MAC Address to a Virtual Machine](#)
- [Selecting a Preferred PM for a Virtual Machine](#)
- [Changing the Protection Level for a Virtual Machine \(HA or FT\)](#)
- [Configuring the Boot Sequence for Virtual Machines](#)
- [Resetting MTBF for a Failed Virtual Machine](#)

The local-user role of **VM Manager** can perform many of these tasks. Specifically, the **VM Manager** can:

- Perform tasks of the available function buttons and actions on the [Virtual Machines Page](#).
- View all available tabs on the [Virtual Machines Page](#).
- Create and delete VCDs from the [Virtual CDs Page](#).

For information on assigning the role of **VM Manager**, see [Managing Local User Accounts](#).

Planning Virtual Machine Resources

When creating virtual machines, plan to allocate system resources to maximize system performance and continuous uptime.

To plan for allocating resources to your virtual machines, see:

- [Planning Virtual Machine vCPUs](#)
- [Planning Virtual Machine Memory](#)
- [Planning Virtual Machine Storage](#)
- [Planning Virtual Machine Networks](#)

Planning Virtual Machine vCPUs

Allocate virtual CPUs (vCPUs) to assign computing resources to a virtual machine (VM) on the ztC Edge system.

When allocating vCPUs to a VM, consider the following information and restrictions:

- Each vCPU represents a virtual unit of processing power. The total number of vCPUs available on a system is equal to the minimum of the number of hardware threads presented by either physical machine (PM) in the system. For example, in a system where one PM that has 4 cores and 2 threads per core (8 vCPUs) and a second PM (in that system) that has 8 cores and 2 threads per core (16 vCPUs), the total number of vCPUs available is 8 vCPUs (fewest threads of either PM).
- The number of vCPUs available for the VMs is equal to the total number of vCPUs on the system.
- The maximum number of vCPUs you can allocate to any one VM is the total number of vCPUs in the system.
- Windows-based VMs: If you change the number of assigned vCPUs from 1 to n or n to 1, after restarting the VM at the end of the reprovisioning process (see [Reprovisioning Virtual Machine Resources](#)), you must shut down and restart the VM a second time. This allows the VM to correctly reconfigure itself for Symmetric Multiprocessing (SMP). The VM displays odd behavior and is not usable until it is restarted.
- The **System** page of the ztC Edge Console (see the [System Page](#)) indicates the total number of vCPUs, the number of vCPUs allocated to the ztC Edge system software, the number of vCPUs consumed by running VMs, and the number of free vCPUs.
- The Stratus Redundant Linux software allows the over-provisioning of vCPUs. If the number of free vCPUs on the **System** page is less than zero, you have over-provisioned the vCPUs; the console indicates this and displays an estimate of the degree to which vCPUs have been over-provisioned.
- The over-provisioning of vCPUs does not prevent you from creating or starting VMs; however, it is best to avoid running the system in an over-provisioned state.

Considerations When Over-Provisioning Virtual CPUs



Note: In general, avoid over-provisioning VM resources. It is best to isolate each VM's resources to protect the VM against other VMs that might experience resource leaks or unexpected performance peaks. When you create and configure VMs, assign dedicated resources that cannot be used by other VMs.

You should over-provision physical CPUs only under the following conditions:

- The peak vCPU resources consumed by the combined VMs does not exceed the physical resources of the ztC Edge system.
- One or more VMs are used at different times (such as off-peak backups).

- One or more of the VMs will be stopped while the other is running, for example, during VM upgrades or VM point-in-time backup or recovery.
- Peak total CPU use by VMs will not affect service level agreements or required response times.
- Each VM's CPU use is well understood, and its application(s) are not prone to resource leaks. When CPUs are over-provisioned, a leak in one VM can affect the performance of other VMs.

Related Topics

[System Requirements Overview](#)

[Creating and Migrating Virtual Machines](#)

[Managing Virtual Machine Resources](#)

Planning Virtual Machine Memory

Allocate memory to assign physical memory to a virtual machine (VM) on your ztC Edge system.

When allocating memory to a VM, consider the following information and restrictions:

- The total memory you can allocate to the VMs is equal to the total amount of memory available on the ztC Edge system (see [System Requirements Overview](#)) minus the memory allocated to the ztC Edge system software. For example, if the total amount of memory is 32 GB, and 2 GB is allocated to the system software, there are 30 GB of memory available to the VMs.
- For systems configured with two nodes, you can provision a single VM with memory up to the total amount of memory available to the VMs. Each VM consumes its requested amount of memory plus an additional 20% memory for overhead.
- The minimum memory allocation is 256 MB, but 64-bit operating systems require 600 MB or more. Be sure to verify the memory requirements for your guest operating systems.
- The **System** page of the ztC Edge Console (see the [System Page](#)) indicates the total amount of memory, the memory allocated to the ztC Edge system software, the memory consumed by running VMs, and the amount of free memory. Use this page to verify your memory allocations.
- The Stratus Redundant Linux software does not allow over-provisioning of memory for **running** VMs; it prevents you from starting VMs that would exceed the total physical memory of the physical machines. You may safely allow over-provisioning of memory to occur only if one or more of the VMs is **stopped** while the other is running, for example, during VM upgrades or VM point-in-time backup or recovery.

- If necessary, you can manually redistribute memory by shutting down or reconfiguring one or more under-utilized VMs and then reassigning the available resources to a more heavily-utilized VM.

Related Topics

[System Requirements Overview](#)

[Creating and Migrating Virtual Machines](#)

[Managing Virtual Machine Resources](#)

Planning Virtual Machine Storage

Plan the allocation of storage on your ztC Edge system to ensure that you have space for your virtual machines (VMs) and system management needs.

When allocating storage to your virtual machines (VMs), consider the following actions:

- Observe storage maximums

The Stratus Redundant Linux software does not allow over-provisioning of storage. The aggregate required storage for all VMs and VCDs must be no more than the total available storage in the ztC Edge system.

- Leave storage space for additional VCDs

Leave at least 5 GB of free space to allow room to create VCDs for installing additional VMs and applications. (To conserve this storage space, consider deleting VCDs when you are finished using them.)

- Create separate boot and data volumes for each VM

Install the guest operating system and applications in the first (boot) volume, and create separate volumes for associated data. Separating the boot and data volumes helps to preserve the data and makes it easier to recover a VM if the boot volume crashes.

- Create a boot volume with enough capacity for the guest operating system plus overhead

Observe the minimum space requirements of your guest operating system and consider allocating slightly more space to account for the formatted capacity of the volume and usage. For example, if you allocate 5 GB to the boot drive when creating the VM, the formatted capacity of the boot volume starts at approximately 4.8 GB before usage, and this might be insufficient to meet a 5 GB requirement.

- Observe the maximum volume size

When exporting, importing, or restoring a volume, note the maximum volume size, as listed in [Important Considerations](#).

Related Topic

[Creating and Migrating Virtual Machines](#)

[Managing Virtual Machine Resources](#)

Planning Virtual Machine Networks

Plan network resources to determine how you will allocate available virtual networks to the virtual machines (VMs) on your ztC Edge system.

When you deploy a system configured with two physical machines (PMs), software binds pairs of physical network ports across the two PMs, to form redundant virtual networks. When you create or reprovision VMs on your ztC Edge system, you connect the VMs to these virtual networks instead of the physical network ports.

When connecting VMs to virtual networks, consider the following information and restrictions:

- You can connect one VM to multiple virtual networks, and you can connect multiple VMs to the same virtual network.
- The Stratus Redundant Linux software allows unlimited over-provisioning of network resources; therefore, be sure to profile a VM's network bandwidth/response time requirements when allocating virtual networks.
- When multiple VMs share the same virtual network, available network bandwidth is shared equally between the VMs. Unlike vCPU capacity, there is no way to proportionately allocate bandwidth resources. Therefore, high use of network resources by one VM can reduce the performance of all VMs on that network. If a VM has a large bandwidth requirement, consider connecting a dedicated virtual network to that VM.

Related Topics

[General Network Requirements and Configurations](#)

[Creating and Migrating Virtual Machines](#)

[Managing Virtual Machine Resources](#)

Creating and Migrating Virtual Machines

Generate a new virtual machine (VM) on a system by creating a new VM, migrating an existing VM or physical machine (PM) directly over the network, or importing an Open Virtualization Format (OVF) file or Open Virtualization Appliance (OVA) file from an existing VM.

To create a new VM (without an existing source VM or PM), see [Creating a New Virtual Machine](#).

To copy an existing VM for the purpose of creating a new VM or creating a duplicate VM for troubleshooting, see [Copying a Virtual Machine](#).

To migrate or import a VM from another system, or to restore a VM on the same system, see one of the following topics:

- [Migrating a Physical Machine or Virtual Machine to a System](#)

Use the *P2V client* (**virt-p2v**) to transfer a PM or VM directly over the network to a new VM on the system.

- [Exporting a Virtual Machine](#)

Use the ztC Edge Console to export the source VM to OVF and VHD files on a network share.

- [Importing an OVF or OVA File](#)

Use the ztC Edge Console to import OVF and VHD files from another ztC Edge system to the ztC Edge system, or to import OVF and VHD files or an OVA file from a VMware vSphere-based system to the ztC Edge system.

- [Replacing/Restoring a Virtual Machine from an OVF File](#)

Use the ztC Edge Console to import OVF and VHD files back to the same system to overwrite and restore an existing VM from a previous backup copy.

Related Topics

[Managing Virtual Machines](#)

Creating a New Virtual Machine

Create a new virtual machine (VM) to install a guest operating system on your ztC Edge system. (You can also migrate an existing VM or physical machine (PM), as summarized in [Creating and Migrating Virtual Machines](#).)

Launch the **VM Creation Wizard** by clicking **Create** on the **Virtual Machines** page. The wizard steps you through the process of allocating resources to the VM.

Prerequisites:



- Review the prerequisites and considerations for allocating CPUs, memory, storage, and network resources to the VM, as listed in [Planning Virtual Machine Resources](#) as well as [Virtual Machine Recommendations and Limits](#), which also lists which systems allow High Availability (HA) and Fault Tolerant (FT) operation.
- You can create VMs that run supported guest operating systems and boot interfaces, as described in [Tested Guest Operating Systems](#).
- You can select a remote ISO or a bootable virtual CD (VCD) as the source that the VM boots from. For a remote ISO, you must have a URL or path name for the repository; and for a remote ISO on a shared network drive, you must have a user name and password. If you need a bootable VCD of the Windows or Linux installation media, create it as described in [Creating a Virtual CD](#). The bootable VCD must be a single CD or DVD. Multiple CDs or DVDs are not supported.
- Ensure that both PMs of the ztC Edge system are online and are connected to the network; otherwise, the system cannot properly create the VM.

To create a new VM

1. On the **Physical Machines** page (see the [Physical Machines Page](#)) of a system configured with two nodes, verify that both PMs are in the **running** state and that neither PM is in maintenance mode or in the process of synchronizing.
2. On the **Virtual Machines** page (see [Virtual Machines Page](#)), click **Create** to open the **VM Creation Wizard**.
3. On the **Name, Description, Protection and OS** page:
 - a. Type the **Name** and an optional **Description** for the VM as they will appear in the ztC Edge Console.

The VM name must meet the following requirements:

- A VM name must start with a word or a number, and the name cannot include the special characters (for example, #, %, or \$).

- A VM name cannot use hyphenated prefixes such as Zombie- or migrating-.
 - A VM name has a maximum of 85 characters.
- b. Select the level of protection to use for the VM:
- **Fault Tolerant (FT)**—Transparently protects an application by creating a redundant environment for a VM running across two PMs. Use FT for applications that need greater downtime protection than HA provides.
 - **High Availability (HA)**—Provides basic failover and recovery, with some faults requiring an (automatic) VM reboot for recovery. Use HA for applications that can tolerate some downtime and that do not need the downtime protection that FT provides.

For more information about these levels of protection, see [Modes of Operation](#).

- c. For **Boot Interface**, select one of the following:
- **BIOS**—Basic Input/Output System
 - **UEFI**—Unified Extensible Firmware Interface

Notes:



1. Ensure that the guest operating system supports the **Boot Interface** that you select; otherwise, the guest operating system cannot boot properly. For a list of guest operating systems and boot interfaces that are supported on ztC Edge systems, see [Tested Guest Operating Systems](#).
2. You can set the **Boot Interface** only when creating a VM. You cannot modify the setting later.

- d. For **Boot From**, select one of the following as the boot source:
- **VCD**—The boot source is a VCD. Select a source from the pull-down menu.
 - **Remote ISO via Windows Share (CIFS/SMB)**—The boot source is a remote ISO file on a shared network drive. You must enter values for **User Name** and **Password**. For **Repository**, enter a value in the format `\\machine_URL\ShareName` (for example, `\\192.168.1.34\MyISO_Folder`).

- **Remote ISO via NFS**—The boot source is a remote ISO file, accessed through NFS. For **Repository**, enter the URL of the remote system in the format *nnn.nnn.nnn.nnn* (do not include **http://** or **https://**).

For a list of available ISO repositories, click **List ISOs**, and select an ISO file. The full path name of the selected ISO file appears under **Repository**. You cannot edit the ISO URL that is displayed.

- e. Click **Next**.

4. On the **vCPUs and Memory** page:

- a. Specify the number of **vCPUs** and the amount of **Memory** to assign to the VM. For more information, see [Planning Virtual Machine vCPUs](#) and [Planning Virtual Machine Memory](#).
- b. Click **Next**.

5. On the **Volumes** page:

- a. Type the **Name** of the boot volume as it will appear in the ztC Edge Console.

The volume name must meet the following requirements:

- Valid characters are a-z, A-Z, 0-9 , +, _, and . (dot).
- A volume name cannot be only . or .. (dots).
- A volume name cannot be snapshot or pvmove.
- A volume name cannot contain any of the following reserved strings: _cdata, _cmeta, _corig, _mlog, _mimage, _pmspare, _rimage, _rmeta, _tdata, _tmeta, or _vorigin.

- b. Type the **Volume Size** of the volume to create in gigabytes (GB). For more information about allocating storage, see [Planning Virtual Machine Storage](#).
- c. If applicable, create additional data volumes by clicking **Add New Volume** and specifying the parameters for each volume. (You can also add volumes after you create the VM by using the **Reprovision Virtual Machine** wizard, as described in [Creating a Volume in a Virtual Machine](#).)
- d. Click **Next**.

6. On the **Networks** page, select the shared networks to attach to the VM (for more information, see [Planning Virtual Machine Networks](#)). You can also enable (or disable) the network and specify the MAC address. To continue, click **Next**.

7. On the **Creation Summary** page:

- a. Review the creation summary. If you need to make changes, click **Back**.
- b. If you want to prevent a console session from automatically starting to observe the software installation, deselect **Launch Console**.
- c. To accept the VM as provisioned and begin the software installation, click **Finish**.

The **VM Creation Wizard** displays progress of the creation and opens the console window, if applicable. When the console window opens, it may take up to a minute for the console to connect to the VM.

8. For Windows-based VMs, when the VM console opens, click inside the console window and be prepared to press any key to run **Windows Setup** from the VCD or remote ISO.

```
Press any key to boot from CD or DVD...
```

For Windows-based VMs with the UEFI boot type, you need to press a key within one or two seconds; otherwise, the **UEFI Interactive Shell** appears. If this happens, you can recover and run **Windows Setup** as follows:

- a. In the **UEFI Interactive Shell**, at the `Shell>` prompt, type `exit` and press **Enter**.

```
Shell> exit
```

- b. Use the arrow keys to select **Continue**, and press **Enter**.

```
Select Language
Device Manager
Boot Manager
Boot Maintenance Manager

Continue
Reset
```

- c. As the VM restarts, press any key to run **Windows Setup** from the VCD or remote ISO.

```
Press any key to boot from CD or DVD...
```

- d. If you miss pressing any key, and the **UEFI Interactive Shell** is displayed again, repeat steps a-c.

9. If applicable, observe the progress of the installation of the operating system (allow pop-ups in your browser, if necessary) and respond to any prompts in the VM console session.
10. After you install the operating system, configure the additional resources and software necessary for production use, as described in:
 - [Configuring Windows-based Virtual Machines](#)
 - [Configuring Linux-based Virtual Machines](#)



Caution: If the primary PM fails or the VM crashes before the final reboot after the installation process is completed, the installation of the VM may need to be restarted.

The VM may not reboot if installations of any of the following are aborted:

- The guest operating system, including the configuration steps
- Any middleware or applications that manipulate system files

Related Topics

[Copying a Virtual Machine](#)

[Renaming a Virtual Machine](#)

[Removing a Virtual Machine](#)

[Creating and Migrating Virtual Machines](#)

[Managing Virtual Machine Resources](#)

[Managing the Operation of a Virtual Machine](#)

Copying a Virtual Machine

Copy a virtual machine (VM) if you want to clone an existing VM on your ztC Edge system. For example, you can copy a healthy VM to create a new VM, or you can copy a VM that is not working properly and use the copy for troubleshooting purposes. (If you want to import or migrate a VM from a different system, see the overview in [Creating and Migrating Virtual Machines](#).)

To copy a VM, select a VM on the **Virtual Machines** page and click **Copy**. A wizard steps you through the process of renaming and allocating resources to the new VM.

Copying a VM creates an identical VM with a unique SMBIOS UUID, system serial number, MAC addresses, and hardware ID.

Notes:

- To prevent conflicts with the source VM, the copy wizard automatically assigns a new MAC address to each network interface in the new VM; however, you may need to manually update any IP addresses and host names.
- If the ztC Edge system switches from the primary PM to the secondary PM while copying a VM, the copy process fails. This does not affect the continuous uptime of your system, but you must delete any volumes associated with the copied VM and start the copy again.
- For information on the modes of operation that systems support, see [Virtual Machine Recommendations and Limits](#).

Prerequisites:

- You must shut down a VM before copying it.
- On a system configured with two nodes, both PMs of the ztC Edge system must be online for the copy process to function properly.

To copy a VM on the ztC Edge system

1. On the **Physical Machines** page (see the [Physical Machines Page](#)) of a system configured with two nodes, verify that both PMs are in the **running** state and that neither PM is in maintenance mode or in the process of synchronizing. On a system configured with one node, verify that the PM is in the **running** state.
2. On the **Virtual Machines** page (see the [Virtual Machines Page](#)), select the VM that you want to copy and click **Shutdown**.
3. When the VM has stopped, click **Copy** to open the copy wizard.
4. On the **Name, Description, and Protection** page:
 - a. Type the **Name** and an optional **Description** for the VM as they will appear in the ztC Edge Console.
 - b. Select the level of protection to use for the VM:
 - **Fault Tolerant (FT)**
 - **High Availability (HA)**

For information about these levels of protection, see [Creating a New Virtual Machine](#) and [Modes of Operation](#).

- c. Click **Next**.
5. On the **vCPUs and Memory** page:
 - a. Specify the number of **vCPUs** and the amount of **Memory** to assign to the VM. For more information, see [Planning Virtual Machine vCPUs](#) and [Planning Virtual Machine Memory](#).
 - b. Click **Next**.
6. On the **Volumes** page, you can:
 - Type the volume **Name**.
 - Specify the **Volume Size** of each volume.
 - Click **Add New Volume** to create a new data volume. (If the button is not visible, scroll down to the bottom of the wizard page.)

For more information, see [Planning Virtual Machine Storage](#). To continue, click **Next**.

7. On the **Networks** page, activate the check box for each shared network that you want to attach to the VM.
8. On the **Copy Summary** page:
 - a. Review the configuration summary. If you need to make changes, click **Back**.
 - b. To proceed with copying the VM, click **Finish**.

After the copy process is complete; the ztC Edge system may continue to synchronize data between PMs to enable HA or FT operation.

Troubleshooting

If necessary, use the following information to resolve problems with the copy process.

To clean up after a canceled or failed copy process

Remove any volumes associated with the copied VM.

Related Topics

[Creating and Migrating Virtual Machines](#)

[Managing Virtual Machine Resources](#)

[Managing the Operation of a Virtual Machine](#)

Migrating a Physical Machine or Virtual Machine to a System

Migrate a physical machine (PM) or virtual machine (VM) to transfer it over an A-link network to a new VM on the system. (You can also import an Open Virtualization Format (OVF) or Open Virtualization Appliance (OVA) file to a system, as summarized in [Creating and Migrating Virtual Machines](#).)

Procedures below describe how to migrate a PM or VM over the network: download the *P2V client* (**virt-p2v**) ISO file, boot the P2V client ISO file on the source PM or VM, and then use the client to configure, initiate, and monitor the secure network transfer from source side. No configuration steps are required on the system until after the migration is complete, but you can confirm that the migration is in progress on the **Volumes** page of the ztC Edge Console as volumes associated with the new VM begin to appear.



Caution: Consider backing up the source PM or VM before preparing to migrate it. To backup a VM, export it (see [Exporting a Virtual Machine](#)). For additional information on backing up VMs or PMs, see [Security Hardening](#).

Notes:

- The migration process supports PMs or VMs running only the following operating systems:
 - CentOS/RHEL 7.5
 - Microsoft Windows 10 Desktop; or Windows Server 2012, 2016, or 2019.
 - Ubuntu 18.04 Server—After migrating this VM, you need to perform additional procedures; otherwise, the VM fails to enter the **running** state on the ztC Edge system. See [To complete the migration of an Ubuntu VM](#).
 - VMware Release 6.x
- For Windows-based VMs that support *hibernation* or *fast startup* mode, you must disable these features before the migration process. To fully disable hibernation or fast startup mode, see the instructions to recover from a migration that fails with the error message `Failed to mount '/dev/sda1: Operation not permitted below in` **Troubleshooting**.
- For Linux-based PMs or VMs, consider editing the `/etc/fstab` file before the migration process to comment out entries for data volumes and allow only the boot volume to mount. Because Linux-based VMs use different device names on the ztC Edge system, a new VM may boot into single-user mode if it cannot mount volumes with their original device names. You can restore the `/etc/fstab` entries with the correct device names after the migration, as described below in **Troubleshooting**.
- When migrating a VMware VM, you must shutdown the VM using operating system shutdown commands in addition to powering it off from the VMware console. If you shutdown the VM using only the VMware console, the migration will fail.
- The source PM or VM must be offline for the duration of the migration process. Consider scheduling a planned maintenance period for the migration.
- While migrating a VM from an everRun or ztC Edge system, it is normal if the source system displays the alert "The VM *name* has failed to start" during the migration process, because although the source VM is powered on and running the P2V client, the guest operating system does not start.





- The time required for the migration depends on the size and number of volumes on the source system as well as the network bandwidth between the source and the target system. For example, transferring a source system with one 20 GB boot volume over a 1Gb network may take about 30 minutes.
- You can migrate multiple PMs or VMs at one time, but sharing network bandwidth may increase migration times.
- To prevent conflicts with the original PM or VM, the P2V client automatically assigns a new MAC address to each network interface in the new VM; however, you must manually update any IP addresses and host names as needed.
- If the system switches from the primary PM to the secondary PM during a migration, the migration process fails. This does not affect the continuous uptime of your system, but you must reboot the P2V client on the source PM or VM and start over. See **Troubleshooting** below for more information.
- After migrating a PM or VM, the network driver might not be properly installed. In this situation, manually install the driver. See **Troubleshooting** below for more information.



Prerequisite: For a system configured with two nodes, both PMs of the system must be online for the migration process to function properly (you cannot migrate PMs or VMs on a system configured with one node). On the **Physical Machines** page of the ztC Edge Console, verify that both PMs are in the **running** state and that neither PM is in maintenance mode or in the process of synchronizing.

Perform the following migration procedures (click drop-down menus, if applicable).

To prepare for migrating a PM to the ztC Edge system

1. Download the P2V client ISO file from the **Downloads** page at <https://www.stratus.com/services-support/downloads/?tab=ztcedge>.
 - a. On the **Downloads** page, click **ztC Edge** (if it is not already displayed) and then select the appropriate version.
 - b. Scroll down to **Drivers and Tools** and then continue scrolling to **ztC Edge P2V Client for Virtual or Physical Machine Migration**.
 - c. Select the **P2V Client (virt-p2v)** file.

2. If you want to verify the integrity of the ISO image, use the MD5 checksum hash function.

Open a command prompt window as an administrator, and enter the following:

CertUtil -hashfile *path_to_file* MD5

The **CertUtil** command displays a message indicating whether or not it completed successfully. If the command succeeds, continue with the next step. If the command fails, repeat the download.

3. Burn the P2V client ISO file to a CD-ROM that you will use to boot the source PM.
4. Insert the P2V client CD into the CD/DVD drive of the source PM.
5. Shut down the PM in preparation to boot the P2V client.

To prepare for migrating a VM to the ztC Edge system

1. Download the P2V client ISO file from the **Drivers and Tools** section of the **Downloads** page at <https://www.stratus.com/services-support/downloads/?tab=ztcedge>. Ensure that you download the version of the P2V client that matches the version of the ztC Edge system to which you are migrating the VM.

2. If you want to verify the integrity of the ISO image, use the MD5 checksum hash function.

Open a command prompt window as an administrator, and enter the following:

CertUtil -hashfile *path_to_file* MD5

The **CertUtil** command displays a message indicating whether or not it completed successfully. If the command succeeds, continue with the next step. If the command fails, repeat the download.

3. Insert or connect the P2V client ISO file to the source VM and set the virtual CD drive as the boot device in the associated hypervisor.
4. Shut down the VM in preparation to boot the P2V client.

To migrate a PM or VM to the ztC Edge system

1. Power on the source PM or VM to boot the P2V client. After a minute or so, the **virt-p2v** window is displayed.
2. The P2V client automatically obtains network settings through DHCP. Static settings are unnecessary for the migration process, but you can optionally click **Configure network** to

specify the settings. (If necessary, configure the network settings of the target VM later on the ztC Edge system.)

3. Enter the connection settings for the **Conversion server** (the ztC Edge system). Enter the hostname or IP address of the system and the **Password** for the `root` account. (You must use the `root` account of the ztC Edge host operating system, as described in [Accessing the Host Operating System](#).)
4. Click **Test connection**. If the P2V client connects to the ztC Edge system, click **Next** to continue. A page appears with sections for **Target properties**, **Fixed hard disks**, and other settings.

If the P2V client cannot connect, verify the connection settings and try to connect again.

5. In the **Target properties** section, enter the **Name** for the target VM that will be displayed in the ztC Edge Console. (The name must be different from any existing VMs on the ztC Edge system.)
6. The **# vCPUs** and **Memory(MB)** values are automatically detected and completed, but optionally modify them if you want the VM on the ztC Edge system to have more CPUs or memory than the source PM or VM.
7. Specify the **Virt-v2v output options** for the target VM, as follows:
 - a. Next to **Output to**, select **HA** (High Availability) or **FT** (Fault Tolerant) operation. (For information about operation options, see [Creating a New Virtual Machine](#) and [Modes of Operation](#).)
 - b. Next to **Output format**, select the disk image format, **raw** or **qcow2**.
8. If you want to save debugging messages from the migration process, optionally select the **Enable server-side debugging** check box. (The debugging messages are included if you generate a diagnostic file for your authorized Stratus service representative, as described in [Creating a Diagnostic File](#).)
9. Select which **Fixed hard disks** (volumes) to include in the migration by activating the check box next to each device.

You must select at least one volume, including the boot volume. (Because the P2V client is a Linux-based utility, all devices are listed by Linux device names, where **sda** or **vda** represents the boot volume.)

10. Select which **Network Interfaces** to include in the migration by activating the check box next to each device.

If the target ztC Edge system has more than one shared network, you can also select the shared network to connect with each network interface. Double-click the network interface to open the **Configure Network** dialog box and select the shared network from a drop-down list.

In the **Configure Network** dialog box, you can also specify a MAC address for a specific network interface. If you do not specify an address, the system automatically sets the MAC address for each network interface.

Click **OK** when you have finished configuring the network interface.

11. When you are ready to migrate the PM or VM to the ztC Edge system, click **Start conversion**. (If you need to cancel the migration for any reason, see **Troubleshooting** below.)
12. When the migration is complete, the P2V client displays a success message. If applicable, you can eject the CD or virtual CD and click **Power Off** to shut down the source PM or VM.



Note: After the migration, the new VM on the ztC Edge system is located on the primary PM, and it remains in a stopped state. Before starting the VM, complete the migration as described in the next procedure.

To complete the migration on the ztC Edge system

1. Open the **Virtual Machines** page (see the [Virtual Machines Page](#)) in the ztC Edge Console.
2. Select the new VM in the top pane and click **Config** to open the **Reprovision Virtual Machine** wizard, as described in [Reprovisioning Virtual Machine Resources](#). Use the wizard to configure the desired vCPUs, memory, storage, and network settings for the VM:
 - If your source PM or VM had more than one network interface, configure the additional network interfaces that were not included in the migration process.
 - If you will continue running the source PM or VM, ensure that the MAC address for each network interface in the new VM is different from the source PM or VM.

Click **Finish** on the last wizard page to implement the changes.

3. Click **Start** to boot the new VM.
4. Click **Console** to open the console of the VM and log on to the guest operating system. (For information about using the console, see [Opening a Virtual Machine Console Session](#).)

5. Disable any guest operating system services that are unnecessary for operation on the ztC Edge system:

- If you migrated from a PM source, disable any services that interact directly with hardware. Examples include:
 - Dell OpenManage (OMSA)
 - HP Insight Manager
 - Diskeeper
- If you migrated from a VM source, disable any services associated with other hypervisors. Examples include:
 - VMware Tools
 - Hyper-V Tools
 - Citrix Tools for Virtual Machines

After disabling these services, restart the guest operating system to implement your changes.

6. If necessary, update the network configuration settings in the guest operating system and restart it to enable the settings.
7. Verify that you have configured your guest operating system with the additional Windows- or Linux-based system settings described in:
 - [Configuring Windows-based Virtual Machines](#)
 - [Configuring Linux-based Virtual Machines](#)

After you verify that the new VM is functioning properly, the migration process is complete; however, the system may continue to synchronize data between PMs to enable High Availability (HA) operation.

To complete the migration of an Ubuntu VM

After migrating a VM using P2V from a bare metal machine running an Ubuntu release, the guest operating system might have no active network, which prevents the VM from transitioning from the **booting** state to the **running** state. To correct the problem, perform the procedure below after migrating the Ubuntu VM.

After migrating an Ubuntu 18.04 VM

1. From the ztC Edge Console, open a console window into the VM.
2. Log in to the VM and go to the terminal.
3. Enter the following command: `cd /etc/netplan.`
4. Enter the following command: `sudo vi 01-netcfg.yaml.`
5. In the file `01-netcfg.yaml`, change `eno1` to `ens3f0`.
6. Enter the following command: `sudo netplan apply.`
7. Enter the following command: `ifconfig.`

You do not need to reboot the VM because, after issuing these commands, the VM is on the network with its configured IP address.

Troubleshooting

If necessary, use the following information to resolve problems with the migration process.

To cancel the migration process

Power down the source PM or VM running the P2V client.

To clean up after a canceled or failed migration

Open the ztC Edge Console and remove any migrated volumes associated with the source PM or VM. If you want to restart the migration process, reboot the P2V client on the source PM or VM.

To recover from a failed migration

If the migration process fails, an error message is displayed in the P2V client on the source PM or VM. Another message may be displayed on the ztC Edge system. Use these messages to determine the problem.

If the migration continues to fail, and the option is available, enable server-side debugging. After the migration, generate a diagnostic file to send to your authorized Stratus service representative, as described in [Creating a Diagnostic File](#). The diagnostic file includes any server-side debugging messages from the migration process.

To recover from a migration that fails with the error message, **Failed to mount '/dev/sda1: Operation not permitted**

For Windows-based PMs or VMs, if the migration process fails with the following error message, it may indicate that *hibernation* or *fast startup* mode are enabled:

```
Failed to mount '/dev/sda1': Operation not permitted
The NTFS partition is in an unsafe state. Please resume and
shutdown Windows fully (no hibernation or fast restarting), or
mount the volume read-only with the 'ro' mount option.
```

To resolve the issue, disable hibernation and fast startup in the source PM or VM:

1. Log on to the operating system of the source PM or VM.
2. Open the **Power Options** control panel and click **Choose what the power buttons do**.
3. Next to **When I press the power button**, select **Shutdown** (instead of **Hibernate** or **Sleep**, if present).
4. Under **Shutdown Settings**, clear the check box next to **Turn on fast startup (recommended)**, if present.
5. Click **Save changes**.
6. Open **Administrator Power Shell** and execute the following command:

```
> powercfg /h off
```
7. Shut down the operating system and restart the migration process.

To recover when a newly migrated Linux-based VM is stuck in the "booting" state

A Linux-based VM may fail to exit the **booting** state in ztC Edge Console if the VM's network is offline.

During the migration process, the P2V client attempts to set a new MAC address for each network interface to prevent conflicts with the original VM. Some Linux-based operating systems detect a new MAC address and automatically create a new network interface for it while still retaining the original interface. The guest operating system boots, but the network may remain offline until you manually configure the network settings.

To correct the problem, open the VM console, log on to the guest operating system, and update the network startup scripts. Ensure that you retain only one entry for each network interface, and that each interface uses a unique MAC address and correct network settings for your environment.

To recover missing data volumes in the VM on the ztC Edge system

If the data volumes do not appear in the VM on the ztC Edge system after the import, you may need to manually restore the volumes, as follows:


- Shut down the VM, run the **Reprovision Virtual Machine** wizard, and verify that you have included the volumes on the **Volumes** page.
- For Windows-based VMs, use **Disk Management** to bring data volumes online.
- For Linux-based VMs, edit the `/etc/fstab` file to reflect the new device names for the storage devices (`/dev/vda` through `/dev/vdh`). Device names also may have shifted, for example, if volumes were not included in the import.

To recover missing network devices in the VM on the ztC Edge system


If the network devices do not appear in the VM on the ztC Edge system after the import, you may need to manually restore them, as follows:

- Shut down the VM, run the **Reprovision Virtual Machine** wizard, and verify that you have included the networks on the **Networks** page.
- For Linux-based VMs, reconfigure the network startup script to reflect the new device names for the network interfaces.

To manually install a new network driver

After migrating a PM or VM, the network driver might not be properly installed (for example, Device Manager might list the driver with a warning, ). In this situation, manually install the driver:

1. In the VM console window, open **Device Manager** in the guest operating system.
2. Expand **Network adapters** and right-click the **Red Hat VirtIO Ethernet Adapter** (the driver that does not work correctly).
3. Select **Update Driver Software**.
4. In the pop-up window, click **Browse my computer for the driver software**.
5. Click **Let me pick from a list of device drivers**.
6. Select **Red Hat VirtIO Ethernet Adapter**.
7. Click **Next** to install the network driver.

After the driver is installed, check the VM's state in the ztC Edge Console. If the state is running () , the driver is working properly.

Related Topics

[Creating and Migrating Virtual Machines](#)

[Configuring Windows-based Virtual Machines](#)

[Configuring Linux-based Virtual Machines](#)

[Managing Virtual Machine Resources](#)

[Managing the Operation of a Virtual Machine](#)

Importing an OVF or OVA File

Import an Open Virtualization Format (OVF) or an Open Virtual Appliance (or Application) (OVA) file from a system if you want to transfer a VM from one system to another, or if you want to transfer an image that you created back to the same system to restore or duplicate the original VM. (To migrate a physical machine (PM) or virtual machine (VM) to a system without using an OVF or OVA file, see [Migrating a Physical Machine or Virtual Machine to a System](#).)

You can *import* or *restore* the VM. Importing a VM creates a new instance of the VM with unique hardware IDs. Restoring a VM creates an identical VM with the same hardware IDs (SMBIOS UUID, system serial number, and MAC addresses, if provided in the VM image) that your guest operating system and applications may require for software licensing. To prevent conflicts with the original VM, restore a VM only if you want to transfer it to the ztC Edge system and stop using it on the source system.

This topic explains how to import an OVF or OVA file from a local computer, a USB device, or a remote file system such as an NFS export or a Windows share (also known as a CIFS share, such as, for example, Samba). If you want to restore an existing VM on the same system to overwrite the VM and recover it from a previous backup copy, see [Replacing/Restoring a Virtual Machine from an OVF File](#).

Notes:

- Import a VM if you are trying to create or clone a VM from a golden image, since the system will assign unique hardware ID and MAC addresses when importing a VM. (A golden image is typically a template VM created for the purpose of copying multiple times.) To prevent conflicts with the source VM, the import wizard automatically assigns a new MAC address to each network interface in the new VM; however, you may need to manually update any IP addresses and host names as needed.

- You can import VMs only if they are running supported guest operating systems and boot interfaces, as described in [Tested Guest Operating Systems](#).

When you import a VM, the system imports the boot interface setting (BIOS or UEFI) from the OVF or OVA file; you cannot modify this setting.

- You can import a VM from a VMware source only if the source is running VMware Release 6.x.

When importing a VMware VM, you must shutdown the VM using operating system shutdown commands in addition to powering it off from the VMware console. If you shutdown the VM using only the VMware console, the import will fail.

- If you import a VM from a VMware OVA file, ensure that your system has sufficient disk space for the operation. The system requires an amount of disk space equal to the size of the OVA file + the total size of the VM volume(s) to be created + 100 GB disk space that is temporarily reserved for expanding and processing the compressed OVA file. For example, if you need to import a 3 GB OVA file for a VM that requires a 32 GB volume, the minimum storage needed is 3 GB + 32 GB + 100GB = 135 GB.

You can check the amount of **Free** disk space on your system on the **System** page of the ztC Edge Console under **Storage Allocation**. If your system lacks the amount of disk space needed to import a VMware OVA file, you can clear some disk space or instead migrate the VM directly over the network (with no OVF or OVA file) as described in [Migrating a Physical Machine or Virtual Machine to a System](#).

- When you import a VM back to the same system to duplicate the VM, you must rename the VM and duplicate volumes during either the export or import process. If you do not rename the VM, the import wizard automatically renames the new VM and new volumes, to prevent conflicts with the source VM. The wizard appends a number to the VM name

and volume name, incrementing the number for additional duplicates of the VM: **MyVM**, **MyVM0**, **MyVM1**, and so on.



- If you begin to import an OVA file and then the node is placed into maintenance mode or loses power, the OVA import fails, and any future attempt to import an OVA file fails. For information on a work-around for this problem, see [KB0014855](#).
- The time required to import a VM depends on the size and number of volumes in the source VM as well as network bandwidth. For example, transferring a VM with one 20 GB boot volume over a 1Gb network may take about 30 minutes.
- If the system switches from the primary PM to the secondary PM during an import process, the process fails. This does not affect the continuous uptime of your system, but you must delete the incomplete VM and associated volumes on the system, and import them again.
- After migrating a PM or VM, the network driver might not be properly installed. In this situation, manually install the driver. See **Troubleshooting** below for more information.
- After Importing a Linux VMware OVA file, you need to manually configure network information. See [After Importing a Linux VMware OVA File, Manually Configure Network Information](#).

Prerequisite:

Before you import a VM image from an OVF file, use the ztC Edge Console on the source system to export a VM (see [Exporting a Virtual Machine](#)) to OVF and Virtual Hard Disk (VHD) files on a supported network share or a USB device. Copy these files to your management PC, or mount the USB device or network share on the target ztC Edge system as described in



[Mounting a USB Device or Network-mounted Folder on the ztC Edge System](#), and then use the ztC Edge Console on the target system to import the OVF and VHD files.

Before you import a VM image from an OVA file, create the OVA file on a VMware system. The ztC Edge system supports VMware OVA files that contain a metadata file and one or more disk image files.

To import an OVF or OVA file

1. Log on to the ztC Edge Console on the target system.
2. On the **Physical Machines** page (see the [Physical Machines Page](#)) of a system configured with two nodes, verify that both PMs are in the **running** state and that neither PM is in maintenance mode or in the process of synchronizing.
3. If you are importing a VM from a USB device or network share (instead of the PC running the ztC Edge Console), mount the device or share on the ztC Edge system as described in [Mounting a USB Device or Network-mounted Folder on the ztC Edge System](#).
4. On the **Virtual Machines** page (see [Virtual Machines Page](#)), click **Import/Restore** to open the **Import/Restore Virtual Machine** wizard.
5. Select one of the following:
 - **Import from my PC**—Imports the VM from the PC running ztC Edge Console.



Note: Browsing for VMware OVF's and OVAs is not supported when importing from a PC, but you can use any of the remaining methods to import VMware OVF's and OVAs.

Click **Next** and then click **Browse** to locate the appropriate file on a local computer.

- **Import from USB**—Imports the VM from a USB device mounted on the ztC Edge system.

Click **Next** and then select a partition from the pull-down menu. Click **List OVF's/OVAs** and select the appropriate file from the pull-down menu. You can optionally search for a file by entering the file name or partial file name in the *Search Files* box. The box lists OVA files that have names matching the name entered in the box, and that reside in various directories:

 - With the parent (root) directory as the search directory, the listed files reside in sub-directories in addition to the parent (root) directory.
 - With a sub-directory as the search directory, the listed files reside in the parent (root) directory in addition to the sub-directory.
- **Import from remote/network Windows Share(CIFS/SMB)**—Imports the VM from a Windows share on your local network. Note that the maximum length of the path to the VM, including the VM name, is 4096 characters.

Click **Next** and enter values for **Username** and **Password**. For **Repository**, enter a value in the format `\\machine_URL\ShareName` (for example, `\\192.168.1.34\MyOVFsForImport`). Then, click **List OVFs/OVAs** and select the appropriate file from the list.

- **Import from remote/network NFS**—Imports the VM from an NFS share on your local network. Note that the maximum length of the path to the VM, including the VM name, is 4096 characters.

Click **Next** and for **Repository**, enter the URL of the remote system in the format `nnn.nnn.nnn.nnn/folder_name` (do not include `http://` or `https://`).

Click **List OVFs/OVAs** to display a list of all files in the remote folder. Select the appropriate file to import. You can optionally search for a file by entering the file name or partial file name in the *Search Files* box, or you can reorganize the list by clicking a column heading (*Name*, *Date Modified*, or *Size*). Click the file name to select the file, and then click **Next**.

If you have selected an OVA file, continue with the next step (import is the only option with an OVA file).

If you have selected an OVF file, click **Next**. Messages appear confirming whether or not it is a ztC Edge-created file and whether or not you have the option to import or restore the VM. When selecting a ztC Edge-created OVF file, you have the option of importing or restoring the file, and you can optionally display the following message:

Restoring a VM attempts to preserve the hardware ID and MAC addresses of all network interfaces. Select **Restore** only if you are specifically trying to restore a particular instance of a VM and that it will be the only copy of this VM running across all systems on your network. Typically a **Restore** is used to recover a VM from a previous backup. Select **Import** if you are trying to create or clone a VM from a "golden" image, as this will assign a unique hardware ID and MAC addresses.

6. Select **Import** (scroll down the window, if necessary). (For a ztC Edge-created OVF, you can also select **Restore**. See [Replacing/Restoring a Virtual Machine from an OVF File](#) for information.)
7. The wizard displays the **Prepare for Importing Virtual Machine** window, prompting you to upload additional files, if necessary. If prompted, select the appropriate file(s) to include for each volume associated with the VM.
8. If you have selected an OVF file, you can review and, if necessary, edit the information (you may need to scroll down the window):

- **Name, Boot Interface, CPU, and Memory**

Displays the name of the VM, the boot interface, the number of vCPUs, and the total memory the VM can use. Edit the information, if necessary. (You cannot modify the **Boot Interface**; the system imports this setting from the OVF or OVA file.)

- **Storage**

Displays the name and size of each volume. In the **Create** column, select a box for a volume to allocate storage for the volume on the system (the boot volume is required). In the **Restore Data** column, select a box to import data for a volume from the VHD file.

- **Network**

Displays the available networks. You can remove a network or add one that is not already allocated. You can also specify a MAC address for each selected network. A minimum of one network is required.

The total number of networks cannot exceed the number of business networks on the ztC Edge system. If you import the VM from an OVF file, you can select which networks to remove in the wizard. If you import the VM from an OVA file, the system automatically ignores the excess networks during the import process. In either case, you can connect more business networks to the ztC Edge system before or after importing the VM to restore the network connections.

9. Optionally, clear the check box for **Auto start Virtual Machine after import** if you need to reprovision the VM before starting it for the first time.
10. Click **Import** to begin importing the VM. You can optionally click **Cancel** to cancel the procedure.

The wizard displays progress information. When the transfer is complete, click **Done** to close the wizard.



Note: Imported volumes begin to appear on the **Volumes** page of the ztC Edge Console while the import is still in progress. Do not attach or remove any of these imported volumes until the import window reports that the process is complete; otherwise, the import fails.

11. If applicable, use the **Reprovision Virtual Machine** wizard to allocate additional resources to the VM, as described in [Reprovisioning Virtual Machine Resources](#).

When you are finished reprovisioning the VM, click **Start** to boot the VM.

12. Click **Console** to open the console of the VM and log on to the guest operating system.
13. For Windows-based VMs only, download and update the VirtIO drivers to the latest supported versions, as described in [Updating the VirtIO Drivers \(Windows-based VMs\)](#). (The correct VirtIO drivers are already present in Linux-based VMs.)



Note: After updating the drivers, you may need to restart the guest operating system.

14. If necessary, update the network settings in the guest operating system.

After you verify that the new VM is functioning properly, the import process is complete; however, the system may continue to synchronize data between PMs to enable High Availability (HA) or Fault Tolerant (FT) operation.



Note: The new VM and its associated volumes may be marked with warning symbols until the data has been synchronized and the VirtIO drivers are running.

Troubleshooting

If necessary, use the following information to resolve problems with the export or import process.

To clean up after a canceled or failed import

In the ztC Edge Console on the target system, remove the imported VM and any volumes associated with the imported VM, if present.

To recover missing data volumes in the target VM

If data volumes do not appear in the VM on the target system after the import, you may need to manually restore the volumes, as follows:

- Shut down the VM, run the **Reprovision Virtual Machine** wizard, and verify that you have included the volumes on the **Volumes** page.
- For Windows-based VMs, use **Disk Management** to bring data volumes online.


- For Linux-based VMs, edit the `/etc/fstab` file to reflect the new device names for the storage devices. Device names may have shifted, for example, if volumes were not included in the import.

To recover missing network devices in the VM on the ztC Edge system


If network devices do not appear in the VM on the target system after the import, you may need to manually restore them, as follows:

- Shut down the VM, run the **Reprovision Virtual Machine** wizard, and verify that you have included the networks on the **Networks** page. If the VM requires more networks than shown in the wizard, connect additional business networks to the ztC Edge system and then reprovision the VM to include the new networks.
- For Linux-based VMs, reconfigure the network startup script to reflect the new device names for the network interfaces.

To manually install a new network driver

After importing a PM or VM, the network driver might not be properly installed (for example, Device Manager might list the driver with a warning, ). In this situation, manually install the driver:

1. In the VM console window, open **Device Manager** in the guest operating system.
2. Expand **Network adapters** and right-click the **Red Hat VirtIO Ethernet Adapter** (the driver that does not work correctly).
3. Select **Update Driver Software**.
4. In the pop-up window, click **Browse my computer for the driver software**.
5. Click **Let me pick from a list of device drivers**.
6. Select **Red Hat VirtIO Ethernet Adapter**.
7. Click **Next** to install the network driver.

After the driver is installed, check the VM's state in the ztC Edge Console. If the state is running () , the driver is working properly.

After Importing a Linux VMware OVA File, Manually Configure Network Information

Importing a Linux VMware OVA file changes the network interface and `networks-scripts` file. After you import the file, you need to manually configure the network information using the following

procedure:

1. On the **Virtual Machines** page, select the VM.
2. Click **Console** in the bottom panel to open the VM login page (for additional information, see [Opening a Virtual Machine Console Session](#)).
3. Log in to the VM.
4. Open a command prompt window.
5. Issue the `ifconfig` command. In the command output, check if `ip address` is assigned to the virtual network interface `eth0`.
6. If `ip address` is not assigned to `eth0`, list the contents of the `/etc/sysconfig/network-scripts` directory.
7. Note the value of `ifcfg-xxxx` (though not `ifcfg-lo`).
8. Rename `ifcfg-xxxx` to be `ifcfg-eth0`.
9. Edit the `ifcfg-eth0` file, changing the values of `DEVICE` and `ONBOOT`, as follows:

```
DEVICE=eth0
ONBOOT=yes
```

Save the file.

10. Issue the following command to restart network services:

```
systemctl restart network
```
11. Verify the IP assignment by issuing the command `ifconfig`. In the command output, confirm that `ip address` is assigned to `eth0`.

Related Topics

[Mounting a USB Device or Network-mounted Folder on the ztC Edge System](#)

[Creating and Migrating Virtual Machines](#)

[Configuring Windows-based Virtual Machines](#)

[Configuring Linux-based Virtual Machines](#)

[Managing Virtual Machine Resources](#)

[Managing the Operation of a Virtual Machine](#)

Replacing/Restoring a Virtual Machine from an OVF File

Replace a virtual machine (VM) from a ztC Edge-created Open Virtualization Format (OVF) file if you want to restore a VM on your ztC Edge system by overwriting the VM with a previous backup copy. (If you want to import a VM from a different system, see the overview in [Creating and Migrating Virtual Machines](#).)

Typically, importing a VM creates a new instance of the VM with unique hardware IDs. Restoring a VM creates an identical VM with the same SMBIOS UUID, system serial number, and MAC addresses, if provided in the VM image, that your guest operating system and applications may require for software licensing. The hardware ID, though, of the restored VM is unique. If an identical VM already exists on the ztC Edge system, restoring the VM allows you to replace the VM and overwrite it with your previous copy.

You can restore a VM that already exists on a ztC Edge system only if you have previously exported a VM (see [Exporting a Virtual Machine](#)) from a ztC Edge system to OVF and Virtual Hard Disk (VHD) files on a supported network share or a USB device. Copy these files to your management PC, or mount the USB device or network share on the target ztC Edge system as described in [Mounting a USB Device or Network-mounted Folder on the ztC Edge System](#), and then use the ztC Edge Console on the target ztC Edge system to restore the OVF and VHD files from your management PC.



Caution: Consider backing up your existing VM on the ztC Edge system before overwriting and restoring it. If you export the VM to create the backup, ensure that you do not overwrite the OVF and VHD files that you want to restore.

Notes:

- You can restore a VM from only an OVF created from a ztC Edge system. You cannot restore a VM from an OVF created from a third-party system. You also cannot restore a VM from an OVA file.
- You typically restore a VM to replace a VM from a previous backup. When restoring a VM, the system attempts to preserve the hardware ID and MAC addresses of all network interfaces.
- Restore a VM only if you are specifically trying to restore a particular instance of a ztC Edge VM and that the restored VM will be the only copy of this VM running across all ztC Edge servers in your network.
- The time required to restore a VM depends on the size and number of volumes in the source VM as well as network bandwidth. For example, transferring a VM with one 20 GB boot volume over a 1Gb network may take about 30 minutes.
- If you overwrite and restore an existing VM, the ztC Edge system removes the existing VM and its volumes.
- If the ztC Edge system switches from the primary PM to the secondary PM while restoring a VM, the restore process fails. This does not affect the continuous uptime of your system, but you must delete the incomplete VM and associated volumes on the ztC Edge system, and restore them again.

Prerequisites:

- Before you replace (that is, restore) a VM image from a ztC Edge system, use the ztC Edge Console on the source ztC Edge system to export a VM (see [Exporting a Virtual Machine](#)) to OVF and Virtual Hard Disk (VHD) files on a supported network share or a USB device. Copy these files to your management PC, or mount the USB device or network share on the target ztC Edge system as described in [Mounting a USB Device or Network-mounted Folder on the ztC Edge System](#), and then use the ztC Edge Console on the target ztC Edge system to restore the OVF and VHD files
- Both PMs of the ztC Edge system must be online for the restore process to function properly.

To restore a VM

1. Log on to the ztC Edge Console on the target ztC Edge system.
2. On the **Physical Machines** page (see the [Physical Machines Page](#)) of a system configured with two nodes, verify that both PMs are in the **running** state and that neither PM is in maintenance mode or in the process of synchronizing.
3. If you are restoring a VM from a USB device or network share (instead of the PC running the ztC Edge Console), mount the device or share on the ztC Edge system as described in [Mounting a USB Device or Network-mounted Folder on the ztC Edge System](#).
4. On the **Virtual Machines** page (see [Virtual Machines Page](#)), select the VM that you want to restore in the upper panel.
5. In the lower panel, click **Restore** or click **Import/Restore** near the top pane.
6. Select one of the following:
 - **Import from my PC**—Imports the VM from the PC running ztC Edge Console.
 - a. Click **Next**.
 - b. Click **Browse** to locate the appropriate folder on a local computer.
 - c. Click the name of the desired file.
 - d. Click **Open**.
 - **Import from USB**—Imports the VM from a USB device mounted on the ztC Edge system.

Click **Next** and then select a partition from the pull-down menu. Click **List OVF/OVAs** and select the appropriate file from the pull-down menu. You can optionally search for a file by entering the file name or partial file name in the *Search Files* box. The box lists OVA files that have names matching the name entered in the box, and that reside in various directories:

 - With the parent (root) directory as the search directory, the listed files reside in sub-directories in addition to the parent (root) directory.
 - With a sub-directory as the search directory, the listed files reside in the parent (root) directory in addition to the sub-directory.
 - **Import from remote/network Windows Share(CIFS/SMB)**—Imports the VM from a Windows share on your local network.

Click **Next** and enter values for **Username** and **Password**. For **Repository**, enter a value in the format `\\machine_URL\ShareName` (for example, `\\192.168.1.34\MyOVFsForImport`). Then, click **List OVFs/OVAs** and select the appropriate OVF file from the list.

- **Import from remote/network NFS**—Imports the VM from an NFS share on your local network.

Click **Next** and for **Repository**, enter the URL of the remote system in the format `nnn.nnn.nnn.nnn/folder_name` (do not include `http://` or `https://`).

Click **List OVFs/OVAs** to display a list of all files in the remote folder. Select the appropriate OVF file. You can optionally search for a file by entering the file name or partial file name in the *Search Files* box, or you can reorganize the list by clicking a column heading (*Name*, *Date Modified*, or *Size*). Click the file name to select the file, and then click **Next**.

7. Select **Restore**. (Scroll down the window, if necessary.) A warning message appears, stating that **Restore** will overwrite all existing data and configuration details and that you should proceed with caution.
8. Click **Continue** to proceed.
9. If prompted, add VHD files.
10. Review the information and make any desired edits, if necessary:

- **Name, Boot Interface, CPU, and Memory**

Displays the name of the VM, the boot interface, the number of vCPUs, and the total memory the VM can use. Edit the information, if necessary. (You cannot modify the **Boot Interface**; the system imports this setting from the OVF file.)

- **Storage**

Displays the name and size of each volume. In the **Create** column, select a box for a volume to allocate storage for the volume on the ztC Edge system (the boot volume is required). In the **Restore Data** column, select a box to import data for a volume from the VHD file.

- **Network**

Displays all of the available networks. You can remove a network or add one that is not already allocated. A minimum of one network is required.

The total number of networks cannot exceed the number of business networks on the ztC Edge system. You can select which networks to remove in the wizard, or connect more business networks to the ztC Edge system before or after restoring the VM to restore the network connections.

11. Optionally, clear the check box for **Auto start Virtual Machine after restore** if you need to reprovision the VM before starting it for the first time.
12. Click **Restore** to begin restoring the VM. When the transfer is complete, click **Done** to close the wizard.



Note: Restored volumes begin to appear on the **Volumes** page of the ztC Edge Console while the restore process is still in progress. Do not attach or remove any of these restored volumes until the restore window reports that the process is complete; otherwise, the restore process fails.

13. If applicable, use the **Reprovision Virtual Machine** wizard to allocate additional resources to the VM, as described in [Reprovisioning Virtual Machine Resources](#).

When you are finished reprovisioning the VM, click **Start** to boot the VM.

After you verify that the restored VM is functioning properly, the restore process is complete; however, the ztC Edge system may continue to synchronize data between PMs to enable High Availability (HA) or Fault Tolerant (FT) operation.



Note: Your restored VM and its associated volumes may be marked with warning symbols until the data has been synchronized and the VirtIO drivers are running.

Troubleshooting

If necessary, use the following information to resolve problems with the restore process.

To clean up after a canceled or failed restore process

In the ztC Edge Console on the target system, remove the restored VM and any volumes associated with the restored VM, if present.

Related Topics

[Creating and Migrating Virtual Machines](#)

[Managing Virtual Machine Resources](#)

[Managing the Operation of a Virtual Machine](#)

Exporting a Virtual Machine

Export a virtual machine (VM) from a system in order to save an image of the VM to a network-mounted folder (that is, directory) or to a USB device. Exporting a VM from an ztC Edge system makes the VM image available for importing to another system or for importing back to the same ztC Edge system to restore or duplicate the original VM. An exported VM can function as a backup of the original VM. You can directly export a VM from the ztC Edge system as described in this topic.



Note: Exporting VMs is particularly important for VMs on a single-node system. In the event of a failure or loss of the original VM, you can use the OVF and VHD files to restore the VM (see [Replacing/Restoring a Virtual Machine from an OVF File](#)).

Prepare for exporting a VM by inserting a USB device or by creating a network-mounted folder to store an exported VM in your environment. If you are using a USB device, insert it into the current primary node of the system (displayed as **node n (primary)** on the **Physical Machines** page). If you are using a folder, create a folder for either a Windows share or a Network File System (NFS) export. A Windows share is also known as a Common Internet File System (CIFS) share (Samba, for example). Then mount the folder or USB device in the host operating system of the ztC Edge system, as described in this topic. When you initiate an export in the ztC Edge Console, the ztC Edge system saves the VM as standard Open Virtualization Format (OVF) and Virtual Hard Disk (VHD) files.

Notes:

- Because the source VM must be shut down to export it, consider scheduling a planned maintenance period for this process.
- The time required for the export depends on the size and number of volumes in the source VM as well as network bandwidth. For example, transferring a VM with one 20 GB boot disk over a 1Gb network may take about 30 minutes.
- If you will continue to use the source VM after exporting it, remember to set a different MAC address and IP address for the VM when you import it on the target system.
- If the ztC Edge system switches from the primary PM to the secondary PM during an export, the process fails. This does not affect the continuous uptime of the system. You can delete the partially exported files from the network-mounted folder and export the files again.
- The maximum size of VM volume data that you can export to an external file share or USB device formatted as a FAT or VFAT file system is 4 GB, even if the total size of the target device is much larger. If you attempt to export data more than 4 GB to a FAT or VFAT file system, the export will fail.
- For Linux-based VMs, when exporting a VM to another system, you do not need to modify the `/etc/fstab` file.
- For Ubuntu-based VMs running some older Ubuntu releases, you may need to edit the `/boot/grub/grub.cfg` file and change the `gfxmode` parameter to `text` (for example, set `gfxmode=text`) before exporting a VM; otherwise, the new VM's console may hang on another system. You can restore the original setting in the source VM after the migration.

Prerequisites:

- You must shut down a VM before exporting it.
- Prepare the export destination:
 - If you are using a USB device, insert it into the current primary node of the system (displayed as **node1 (primary)** on the **Physical Machines** page). Confirm that the system displays the USB device. Navigate to the **Physical Machines** page. Click the node into which you inserted the device, and in the lower pane, select the **USB Device** tab. The USB device you inserted should appear in the tab's display.
 - If you are using a network-mounted folder for a Windows/CIFS share or an NFS export, create the folder in your environment where you can store the exported VM. Set full read/write permissions on the network-mounted folder to permit file transfers, or, for a Windows/CIFS share only, assign read/write permissions to a specific user on the system/domain that hosts the share. Record the URL or pathname of the NFS export or CIFS share as well as the username/password of the CIFS share, which you use when you export the VM.

Ensure that you have enough storage for the VMs that you want to export.

In addition, Windows-based VMs require Windows-specific preparation.

To prepare for exporting a VM (Windows-based VMs only)

1. Log on to the ztC Edge system with the ztC Edge Console.
2. On the **Virtual Machines** page, select the VM to export.
3. Click **Console** to open the console of the VM and log on to the Windows guest operating system.
4. Ensure that all volumes are labeled accurately, as summarized in [Managing Windows Drive Labels](#).
5. If you plan to create a golden image of a VM that you can export to other systems for redeployment, run the Windows System Preparation Tool (`Sysprep`) to prepare the guest operating system for redeployment.



Caution: Do not use `Sysprep` on a VM that is needed for production use, because this utility resets the configuration of the guest operating system to its default settings for redeployment. If needed, you can make a copy of the VM, run `Sysprep` on the copy, and then export the copy.

To export a VM

1. Log on to the ztC Edge system with the ztC Edge Console.
2. On the **Virtual Machines** page, select the VM that you want to export, and click **Shutdown**. Wait for the VM to shut down. See [Virtual Machines Page](#).
3. With the VM selected, click **Export** to open the export wizard.
4. Select one of the following:



Note: If you have already mounted a location using the **Mount** button (as described in [Mounting a USB Device or Network-mounted Folder on the ztC Edge System](#)), the export wizard displays the mounted device URL in green. To change it, click the **Change** button.

- **Mount device via Windows Share (CIFS/SMB)**

The export destination is a folder on a CIFS share. Enter a **Username**, **Password**, and **Repository** value. For **Repository**, enter a value in the format `\\machine_URL\ShareName` (for example, `\\192.168.1.34\MyExportVMs`).

- **Mount device via NFS**

The export destination is a folder on a remote system, accessed through NFS. Enter a **Repository** value, which is the URL of the remote system, in the format `nnn.nnn.nnn.nnn` (do not include `http://` or `https://`).

- **Mount USB**

For **USB partition list**, select a partition from the pull-down menu.

5. For **Export Path: /mnt/ft-export:**, type the path of the location where you want the VM to be exported and its OVF and VHD files to be stored. For example, if you want to export the VM to a new folder named `ocean1`, type `ocean1`.
6. Click **Mount**.

If the mount succeeds, the repository appears under **Device URL** and the **Export VM** button becomes active; otherwise, an alert appears.

7. Select the volumes to include under **Boot Volume to Export** and **Data Volumes to Export**.
(The boot volume is required.)
8. Click **Export VM** to export the VM.

You can monitor the **Export Status** in the **Summary** tab for the VM that you are exporting. Progress is reported as the percentage (%) completed for the whole export and for each volume. When the process is complete, the status changes to **Export completed successfully**.

To cancel the export, click **Cancel** next to the **Export progress** percentage. A dialog box opens, asking you to confirm the cancellation. Click **Yes** to cancel.

The ztC Edge system exports the VHD files (volumes) first, then it exports the OVF file. You can confirm that the process is finished when the OVF file appears in the folder.

After the export process, if you want to import or restore the OVF and VHD files on an ztC Edge system, see [Importing an OVF or OVA File](#).

To unmount the device, see [Mounting a USB Device or Network-mounted Folder on the ztC Edge System](#).

Troubleshooting

If necessary, use the following information to resolve problems with the export process.

To clean up after a canceled or failed export from the ztC Edge system

Remove the VM files from the export folder or create a new folder for a subsequent export.

Related Topics

[Attaching a USB Device to a Virtual Machine](#)

[Creating and Migrating Virtual Machines](#)

[Managing Virtual Machine Resources](#)

[Managing the Operation of a Virtual Machine](#)

Mounting a USB Device or Network-mounted Folder on the ztC Edge System

You can mount (or unmount) a USB device or a network-mounted folder (that is, a directory) on the ztC Edge system using the **Mount** (or **Unmount**) button on the **Virtual Machines** page. Mounting a location makes it available to the primary node at the mount point `/mnt/ft-export/`. You can then export a VM

on the primary node to the mounted location, or import a VM from the mounted location to the ztC Edge system. When the export or import is finished, use the **Unmount** button to unmount the location.

(If you need to mount a USB device to access the device in the guest operating system of a VM, see [Attaching a USB Device to a Virtual Machine](#).)

Notes:

1. You cannot unmount a mounted location that is in use. For example, you cannot unmount a location while a VM is being exported or imported.
2. The Stratus Redundant Linux software on ztC Edge systems does not support the exFAT File system. Before you mount a USB medium, format the device with NTFS. (By default, most USB media are formatted with the FAT file system, which has a limited file size of 4 GB that may be too small for most VMs.)

Prerequisite: Prepare the mount location:

- If you are using a USB device to export or import a VM, attach the device to the current primary node for the system (displayed as **noden (primary)** on the **Physical Machines** page). Confirm that the system displays the USB device: navigate to the **Physical Machines** page, click the node to which you attached the device, and in the lower pane, select the **USB Device** tab. The USB device you attached should appear in the tab's display.
- If you are using a network-mounted folder for a Windows/CIFS share or an NFS export, create the folder in your environment where you can store the exported VM. Set full read/write permissions on the network-mounted folder to permit file transfers, or, for a Windows/CIFS share only, assign read/write permissions to a specific user on the system/domain that hosts the share. Record the URL or pathname of the NFS export or CIFS share as well as the username/password of the CIFS share, which you use when mounting an NFS export of CIFS share.

To mount a USB device or network-mounted folder

1. On the **Virtual Machines** page, select a VM.
2. In the lower pane, click the **Mount** button.
3. Select one of the following for the mount point **/mnt/ft-export/**:

- **Mount device via Windows Share (CIFS/SMB)**

The mount location is a folder on a CIFS share. Enter a **Username**, **Password**, and **Repository** value. For **Repository**, enter a value in the format `\\machine_URL\ShareName` (for example, `\\192.168.1.34\MyMountLocation`).

- **Mount device via NFS**

The mount location is a folder on a remote system accessed through NFS. For **Repository**, enter the URL of the remote system in the format `nnn.nnn.nnn.nnn` (do not include `http://` or `https://`).

- **Mount USB**

For **USB partition list**, select a partition from the pull-down menu.

4. Click **Mount**.

The location is mounted on the primary node, and the **Mount** button changes to **Unmount**.

To unmount a USB device or network-mounted folder

1. On the **Virtual Machines** page, select a VM.
2. In the lower pane, click the **Unmount** button.
3. A **Confirm** dialog box appear, asking if you are sure you want to unmount the location. Click **Yes** to unmount it.

The location is unmounted, and the **Unmount** button changes to **Mount**.

Related Topics

[Exporting a Virtual Machine](#)

[Managing Virtual Machines](#)

Managing Windows Drive Labels

Label volumes in a Windows-based virtual machine to ensure that they are correctly mapped before you export the virtual machine.



Caution: If you plan to run `Sysprep` to create a golden image of a VM that you can export to other systems for redeployment, ensure that each volume has a unique identifiable label before running `Sysprep`. This process requires administrator privileges.

To set a label from the command prompt, type:

```
C:\>label C:c-drive
```

To list and verify all volume labels, use the **diskpart** utility:

```
C:\> diskpart

DISKPART> list volume

...

DISKPART> exit
```

After importing the virtual machine, use **Disk Manager** to reassign the drive letters. The labels you assigned before the export will help to identify the drives. For instructions on reassigning drive letters on a Windows system, search for the Microsoft Support web site.

Related Topics

[Creating and Migrating Virtual Machines](#)

[Configuring Windows-based Virtual Machines](#)

Configuring Windows-based Virtual Machines

After installing a Windows-based virtual machine, configure the additional resources and software necessary for production use, as described in:

- [Updating the VirtIO Drivers \(Windows-based VMs\)](#)
- [Creating and Initializing a Disk \(Windows-based VMs\)](#)
- [Installing Applications \(Windows-based VMs\)](#)

In addition, ensure that you configure the following settings:

- Change the time zone in the guest operating system to correspond to the time zone configured on the **Date and Time** preference page in the ztC Edge Console (see [Configuring Date and Time](#)); otherwise, the VM's time zone changes whenever VMs restart or migrate. Network Time Protocol (NTP) is recommended for both the VM and the ztC Edge system.
- Disable hibernation (enabled by default in some cases) to prevent the guest operating system from going into a power-saving state.
- Configure the power button action in the guest operating system to shut down the guest (and not to hibernate it) to allow the **Shutdown** VM button in the ztC Edge Console to work properly (see

[Shutting Down a Virtual Machine](#)).

- Configure the guest operating system to generate a crash dump file if the operating system crashes. Follow the instructions in the Microsoft article, [How to generate a complete crash dump file or a kernel crash dump file by using an NMI on a Windows-based system](#) (Article ID: 927069). Follow the instructions in the **More Information** section.

For information on monitoring Windows-based VMs on systems licensed for such monitoring, see [Monitoring Windows-based Virtual Machines](#).

Related Topics

[Managing Virtual Machines](#)

Updating the VirtIO Drivers (Windows-based VMs)

Update the Red Hat VirtIO drivers in your Windows-based virtual machines (VMs) to the latest supported versions, to ensure the proper operation of the VMs. For example, you should update the VirtIO drivers after upgrading the system software ([Upgrading Stratus Redundant Linux Software](#)) or after using the P2V client to migrate a VM or a physical machine (PM) to the ztC Edge system ([Migrating a Physical Machine or Virtual Machine to a System](#)).

A VCD with the ISO file of the VirtIO drivers is installed on the system during the installation of system software as well as during an upgrade of the system software. To confirm that the VCD exists, check **The Virtual CDs Page** (see the [Virtual CDs Page](#)) for a VCD with **virtio** in the name. If the VCD exists, update the VirtIO drivers (see [To update the VirtIO drivers in a Windows-based virtual machine](#)). If the VCD does not exist, create it (see [To download the VirtIO drivers and create a VCD](#)) and then update the drivers.

Notes:

- For proper operation, ensure that you download the VirtIO drivers only from the **ztC Edge Support** page, as described in the following procedure. The VirtIO ISO file on the support page contains versions of the VirtIO drivers that have been tested with the Stratus Redundant Linux software, and they are known to work. VirtIO drivers from other sources could have compatibility issues.
- When updating the VirtIO drivers, use only the **Browse my computer for the driver software** option and select the specific folder or .inf file that applies to the guest operating system. If you use the **Search automatically for updated driver software** option or select only the top level of the VirtIO VCD, Windows might automatically install an incorrect driver.
- In some cases, the guest operating system requests a restart after drivers are updated. If so, restart the guest operating system.

To download the VirtIO drivers and create a VCD

1. Download the VirtIO ISO file from the **Downloads** page at <https://www.stratus.com/services-support/downloads/?tab=ztcedge>.
 - a. On the **Downloads** page, click **ztC Edge** (if it is not already displayed) and then select the appropriate version.
 - b. Scroll down to **Drivers and Tools** and then continue scrolling to **ztC Edge VirtIO Driver Update**.
 - c. Click the link to the appropriate file.

Ensure that you download the version of the VirtIO ISO file that matches the version of your ztC Edge system.

2. If you want to verify the integrity of the ISO image, use the MD5 checksum hash function.

Open a command prompt window as an administrator, and enter the following:

CertUtil -hashfile *path_to_file* MD5

The **CertUtil** command displays a message indicating whether or not it completed successfully. If the command succeeds, continue with the next step. If the command fails, repeat the download.

3. Open the ztC Edge Console and create a VCD of the VirtIO ISO file (see [Creating a Virtual CD](#)).

To update the VirtIO drivers in a Windows-based virtual machine

1. Open the ztC Edge Console and insert the VCD into the Windows-based VM (see [Inserting a Virtual CD](#)).
2. In the VM console window, open **Device Manager** in the guest operating system.

The method to open Device Manager varies depending on the release of the guest operating system. One method is to open the Control Panel and select **Device Manager**. Another method is to open a search window and type **Device Manager**.

3. Expand **Network adapters** and locate the **Red Hat VirtIO Ethernet Adapter**. There may be more than one adapter present depending on the number of network interfaces in your VM.

If the **Red Hat VirtIO Ethernet Adapter** is not present, the VirtIO driver is not installed. Expand **Other devices** and locate the unknown **Ethernet Controller** device. Update the driver for this device.

- a. Right-click the **Red Hat VirtIO Ethernet Adapter** (or **Ethernet Controller**) and select **Update Driver Software**. Click **Browse my computer for the driver software**, specify the location of the VirtIO Ethernet driver (**netkvm**) for your guest operating system, and finish updating the driver. (For example, to update the driver in a Windows Server 2012 R2 guest, select the NetKVM\2k12R2\amd64**netkvm.inf** file on the VirtIO VCD.)
 - b. Repeat the driver update for each additional **Red Hat VirtIO Ethernet Adapter** (or **Ethernet Controller**) device.
4. Expand **Storage controllers** and locate the **Red Hat VirtIO SCSI controller**. There may be more than one controller present depending on the number of volumes in your VM. If the **Red Hat VirtIO SCSI controller** is not present, the VirtIO driver is not installed. Locate the unknown **SCSI controller** device, and update the driver for this device:
 - a. Right-click the **Red Hat VirtIO SCSI controller** (or **SCSI controller**) and select **Update Driver Software**. Click **Browse my computer for the driver software**, specify the location of the VirtIO SCSI driver (**viostor**) for your guest operating system, and finish updating the driver. (For example, to update the driver in a Windows Server 2012 R2 guest, specify the viostor\2k12R2\amd64**viostor.inf** file on the VirtIO VCD.)
 - b. Repeat the driver update for each additional **Red Hat VirtIO SCSI** (or **SCSI controller**) device.



Caution: Although the device name is the **Red Hat VirtIO SCSI** controller, you must select the storage driver file that is labeled **viostor**, and not **vioscsi** (if present). Installing the **vioscsi** driver may crash your VM.

5. If applicable, restart the guest operating system to load the updated drivers.

Related Topics

[Configuring Windows-based Virtual Machines](#)

[Creating and Migrating Virtual Machines](#)

[Managing the Operation of a Virtual Machine](#)

Creating and Initializing a Disk (Windows-based VMs)

Create and initialize a disk to prepare it for partitioning into volumes in a Windows-based virtual machine.

To create and initialize a disk in a Windows-based virtual machine

1. Use the ztC Edge Console to create a new volume on the ztC Edge system, as described in [Creating a Volume in a Virtual Machine](#).
2. In the Windows guest operating system, open **Disk Management** or a similar utility.
3. Initialize the newly-added disk. (You may be prompted to do so automatically.)
4. Convert the disk to a dynamic disk.
5. Create one or more simple volumes on the disk.
6. Restart the Windows guest operating system.

See your Windows documentation for complete instructions.



Note: Because the Stratus Redundant Linux software already mirrors data at the physical level, volume redundancy is not required in the Windows guest operating system.

Related Topics

[Opening a Virtual Machine Console Session](#)

[Configuring Windows-based Virtual Machines](#)

[Creating and Migrating Virtual Machines](#)

[Managing the Operation of a Virtual Machine](#)

Installing Applications (Windows-based VMs)

Install an application in a Windows-based virtual machine by doing one of the following:

- Download the installation program to the guest operating system as an executable file or ISO file.
- Mount a network drive that contains the installation program.
- Create and insert a Virtual CD (VCD) that contains the installation program. See [Managing Virtual CDs](#).

For information on monitoring applications on Windows-based VMs (on systems licensed for such monitoring), see [Monitoring Applications on Windows-based Virtual Machines](#).

Related Topics

[Opening a Virtual Machine Console Session](#)

[Configuring Windows-based Virtual Machines](#)

[Creating and Migrating Virtual Machines](#)

[Managing the Operation of a Virtual Machine](#)

Configuring Linux-based Virtual Machines

After installing a Linux-based virtual machine, configure the additional resources and software necessary for production use, as described in:

- [Creating and Initializing a Disk \(Linux-based VMs\)](#)
- [Installing Applications \(Linux-based VMs\)](#)

In addition, ensure that you configure the following settings:

- Disable hibernation (enabled by default in some cases) to prevent the guest operating system from going into a power-saving state.
- Configure the power button action in the guest operating system to shut down the guest (and not to hibernate it) to allow the **Shutdown** VM button in the ztC Edge Console to work properly. For the minimal server version of Ubuntu Linux, optionally install the `acpid` package to enable the **Shutdown** button. See [Shutting Down a Virtual Machine](#).
- Install the `kexec-tools` package and configure the guest operating system to generate a crash dump file if the system crashes.

- For Ubuntu Linux guest operating systems, to prevent a problem where the VM console hangs in ztC Edge Console, edit the `/boot/grub/grub.cfg` file and change the `gfxmode` parameter to `text` (for example, set `gfxmode=text`). If the VM console hangs before you can set the parameter, see the troubleshooting information in [Opening a Virtual Machine Console Session](#) to resolve the issue.

For more information about these settings, see your Linux documentation.

Related Topics

[Managing Virtual Machines](#)

Creating and Initializing a Disk (Linux-based VMs)

Create and initialize a disk to make it available for storing data in a Linux-based virtual machine.

To create and initialize a disk in a Linux-based virtual machine

1. In the ztC Edge Console, create a new volume, as described in [Creating a Volume in a Virtual Machine](#).
2. In the Linux-based virtual machine, use the volume management tool or edit files as needed to initialize and mount the volume. See your Linux documentation for complete instructions.

The disk device names for a Linux-based virtual machine are `/dev/vda` through `/dev/vdh`, not the standard `/dev/sda` through `/dev/sdh`. The ztC Edge virtual disk volumes appear in the guest operating system and are used as if they were physical disks.

Related Topics

[Opening a Virtual Machine Console Session](#)

[Configuring Linux-based Virtual Machines](#)

[Creating and Migrating Virtual Machines](#)

[Managing the Operation of a Virtual Machine](#)

Installing Applications (Linux-based VMs)

Install an application in a Linux-based virtual machine by doing one of the following:

- Download the installation package to the guest operating system as an executable file or ISO file.
- Mount a network drive that contains the installation package.

- Create and insert a Virtual CD (VCD) that contains the installation package. See [Managing Virtual CDs](#).

Related Topics

[Opening a Virtual Machine Console Session](#)

[Configuring Linux-based Virtual Machines](#)

[Creating and Migrating Virtual Machines](#)

[Managing the Operation of a Virtual Machine](#)

Managing the Operation of a Virtual Machine

Manage the operation of a virtual machine as described in:

- [Starting a Virtual Machine](#)
- [Shutting Down a Virtual Machine](#)
- [Powering Off a Virtual Machine](#)
- [Opening a Virtual Machine Console Session](#)
- [Renaming a Virtual Machine](#)
- [Removing a Virtual Machine](#)

For additional information configuration and troubleshooting information, see [Advanced Topics \(Virtual Machines\)](#).

Starting a Virtual Machine

Start a virtual machine (VM) to boot the VM's guest operating system. You can also configure a starting mode for a VM, for when the ztC Edge system boots.

To start a virtual machine

1. On the **Virtual Machines** page, select a VM.
2. Click **Start** in the bottom panel.

To configure a starting mode for a virtual machine, for when the system boots

1. On the **Virtual Machines** page, select a VM.
2. Click the **Boot** tab in the bottom panel.

3. For **Auto Start Mode**, select one of the following:

- **Last**—Return the VM to its state when the system was shutdown: if the VM was running, the VM is restarted when the system boots; if the VM was stopped, the VM is not started when the system boots.
- **On**—Start the VM when the system boots.
- **Off**—Do not start the VM when the system boots.

4. Click **Save**.

Related Topics

[Shutting Down a Virtual Machine](#)

[Powering Off a Virtual Machine](#)

[Managing the Operation of a Virtual Machine](#)

Shutting Down a Virtual Machine

Shut down a virtual machine (VM) to begin an orderly shutdown of the guest operating system.



Note: You can shut down a VM with guest operating system commands. Some guests allow (or can be configured to allow) you to shut down a VM using the ztC Edge Console.

Shutting down a VM in the ztC Edge Console is similar to pressing the power button on a physical machine, which typically results in an orderly shutdown of the operating system. In some cases, you may need to explicitly enable this feature in the guest operating system. For example:

- For any guest, verify that the power button action is set to shut down the guest operating system and not to hibernate it. If you click **Shutdown** in the ztC Edge Console for a guest that is set to hibernate, the VM remains in a **stopping** state and never properly shuts down.
- On some guests, the power button does not shut down the system unless a user is logged on to the operating system. You may be able to update security settings to enable the power button even in the absence of a login session.
- On some minimal server versions of Ubuntu, the `acpid` package that enables the power button is not included in the default installation. You can manually install this package to enable the power button using the following command (or see the documentation for your guest operating system):

```
sudo apt-get install acpid
```

For versions of Ubuntu running the desktop, the ztC Edge Console **Shutdown** button causes the VM's Ubuntu desktop to prompt you with selecting one of three icons: suspend, sleep, or shutdown. To allow the Ubuntu VM to shutdown without the desktop prompts, you must modify the `powerbtn` file.

To modify the `powerbtn` file

1. In the VM, edit the `/etc/acpi/events/powerbtn` file.
2. Comment out these lines:

```
event=button[ /]power
action=/etc/acpi/powerbtn.sh
```

3. Add these lines:

```
event=button/power (PWR.||PBTN)
action==/sbin/poweroff
```

4. Issue the following command to restart `acpid`:

```
systemctl restart acpid
```

See the documentation for your guest operating system to configure the behavior of the system power button, thus enabling the **Shutdown** button to work in the ztC Edge Console.

To shut down a VM in ztC Edge Console

1. On the **Virtual Machines** page, select a VM.
2. Click **Shutdown** in the bottom panel.

A warning message appears, asking you to confirm the shutdown. Click **Yes** to shutdown or **No** to discontinue the shutdown.

If the VM is not responding, you can also **Power Off** the VM to stop it without properly shutting down the guest operating system.

Related Topics

[Starting a Virtual Machine](#)

[Powering Off a Virtual Machine](#)

[Managing the Operation of a Virtual Machine](#)

Powering Off a Virtual Machine

Power off a virtual machine (VM) to stop it without properly shutting down the guest operating system.



Caution: Use the **Power Off** command only if the **Shutdown** command or guest operating system commands fail. Powering off a VM is similar to pulling the power cord, which may result in data loss.

To power off a virtual machine

1. On the **Virtual Machines** page, select a VM.
2. Click **Power Off** in the bottom panel.

Related Topics

[Starting a Virtual Machine](#)

[Shutting Down a Virtual Machine](#)

[Managing the Operation of a Virtual Machine](#)


[Advanced Topics \(Virtual Machines\)](#)

Opening a Virtual Machine Console Session

Open a virtual machine (VM) console session to display the console of the guest operating system running in the VM.

The following procedure describes how to open a VM console session in the ztC Edge Console, but you can also use a remote desktop application for this purpose.

To open a VM console session

1. On the **Virtual Machines** page, select a VM.
2. Ensure that the VM is in a running state.
3. Click **Console** () in the bottom panel.

Note:

After you click **Console**, the console session that opens may be blank if the browser has an HTTPS connection to the system, but does not have a security exception for it. In this situation, click the IP address in the upper-right corner of the session window. This IP address, which is in the format `https://system_IP_address:8000`, adds the system IP address as a security exception site in the browser. A security exception allows the browser to open the site.

Depending on the browser, additional security windows or messages may appear. With some browsers, one or more security messages appear, and you need to click through those messages. With other browsers, the address bar turns red with no message, and you need to click the address to proceed. Some specific examples are:



- If **Certificate error** appears in the address bar, you may need to (1) click the address; (2) on a page displaying **The website cannot display the page**, click **More information**; and then (3) on a page displaying **This site is not secure**, click **Go on to the webpage (not recommended)**.
- If the page **Warning: Potential Security Risk Ahead** appears, click **Advanced** and in the next window, click **Accept Risk and Continue**.
- If **Error response** with **Error code 405** appears, close the window or tab.


This security exception will then apply to all VMs. You need to perform these actions only once for each browser. When you click **Console** in the future, the console session to the VM opens successfully.


After you have opened the VM console session, you can resize the browser window and the VM console session. You can also use keyboard shortcuts.


To resize the browser window and the VM session

1. Open the VM console session (see procedure above).

Icons appear at the left edge of the window. To display the icons, you may need to click the arrow in the tab at the left edge of the window.







2. To resize the browser window to full screen, click the full-screen icon (.

When in full screen, click the full-screen icon () again to resize the browser to a smaller window.

3. To resize the VM session inside the browser, click the Settings icon () and select a **Scaling Mode** (click the current mode to view a pull-down menu with other settings):
 - **Remote Resizing** (the default)—The size of the VM session changes when you change the resolution of the guest OS.
 - **Local Scaling**—The size of the VM session changes automatically to fill the full screen with the original width and height ratio.

To use keyboard shortcuts

1. Open the VM console session (see procedure above).

Icons appear at the left edge of the window. To display the icons, you may need to click the arrow in the tab at the left edge of the window.
2. Click the **A** icon () at the left edge of the window to display the keyboard shortcut-selection icons.
3. The following icons appear:
 - —Click for the **Ctrl**-key function.
 - —Click for the **Alt**-key function.
 - —Click for the **Tab**-key function.
 - —Click for the **Esc**-key function.
 - —Click for the **Ctrl+Alt+Delete**-keys function.

Troubleshooting

To resolve an issue where the VM console window does not open

Ask your network administrator to open ports 6900-6999 (inclusive).

To resolve an issue where the VM console window is blank

Verify that the VM is powered on and not in the process of booting. Also, click in the console window and press any key to deactivate the screen saver.

To resolve an issue where more than one VM console window is displayed and they are behaving erratically

Close all console windows and open only one console window.

To resolve an issue where the VM console window hangs on the ztC Edge system

For Ubuntu-based VMs, the VM console hangs in the ztC Edge Console if you do not properly set the `gfxmode` parameter. In the guest operating system, edit the `/boot/grub/grub.cfg` file and change the `gfxmode` parameter to `text` (for example, set `gfxmode=text`).

If the console hangs before you can set the parameter, do the following:

1. Restart the VM in the ztC Edge Console.
2. At the GRUB menu, press `e` to edit the grub command.
3. On the next screen, on the `gfxmode` line, change `$linux_gfx_mode` to `text` so the line reads:

```
gfxmode text
```

4. Press **Ctrl-x** or **F10** to boot the guest operating system.
5. To update the setting so it persists for each boot cycle, edit the `/boot/grub/grub.cfg` file and change the `gfxmode` parameter to `text` so the line reads:

```
set gfxmode=text
```

6. Save the `/boot/grub/grub.cfg` file.

To change the terminal type in a Linux-based VM if the console screen is unreadable

By default, the Linux operating system sets the `TERM` variable to `vt100-nav`, which is not properly supported by the `vncterm` program, the basis for the VM console in ztC Edge Console. If you use anything other than the command line, the screen becomes unreadable. To resolve this issue, change the terminal type in the Linux guest operating system:

1. Open the `inittab` file in the guest operating system.
2. In the following line, replace `vt100-nav` with `vt100` by deleting `-nav` at the end of the line.

The updated line appears as follows:

```
# Run gettys in standard runlevels co:2345:respawn:/sbin/agetty xvc0
9600 vt100
```

3. Save the `inittab` file.

Related Topics

[Starting a Virtual Machine](#)

[Shutting Down a Virtual Machine](#)

[Managing the Operation of a Virtual Machine](#)

Renaming a Virtual Machine

Rename a virtual machine (VM) to change its name as it appears on the **Virtual Machines** page.

If you need to change the host name of the guest operating system running in a VM, use guest operating system tools.



Prerequisite: To rename a VM, you must shut it down.

To rename a virtual machine

1. On the **Virtual Machines** page, select a VM.
2. Click **Shutdown** and wait for the VM to shut down.
3. Double-click the name of the VM.
4. Type the new name. The VM name must meet the following requirements:
 - A VM name must start with a word or a number, and the name cannot include the special characters (for example, #, %, or \$).
 - A VM name cannot use hyphenated prefixes such as Zombie- or migrating-.
 - A VM name has a maximum of 85 characters.
5. Press **Enter**.

Related Topics

[Removing a Virtual Machine](#)

[Creating and Migrating Virtual Machines](#)

[Managing the Operation of a Virtual Machine](#)

Removing a Virtual Machine

Remove a virtual machine (VM) to permanently delete it and optionally delete associated volumes from the ztC Edge system.



Prerequisite: Both PMs of the ztC Edge system must be online to properly remove a VM. On the **Physical Machines** page of the ztC Edge Console, verify that both PMs are in the **running** state and that neither PM is in maintenance mode or in the process of synchronizing.

To remove a virtual machine

1. On the **Virtual Machines** page, select a VM.
2. Click **Shutdown** in the bottom panel.
3. When the VM has stopped, click **Remove**.
4. In the **Remove Virtual Machine** dialog box, activate the check box next to volumes that you want to delete. Clear the check box for volumes to save as archives or save for attachment to another VM.



Caution: Make sure that you select the correct VM and volumes for removal. When you click **Delete VM**, these items are permanently removed.

5. Click **Delete VM** to permanently delete the VM and any selected volumes.

Related Topics

[Renaming a Virtual Machine](#)

[Creating and Migrating Virtual Machines](#)

[Managing the Operation of a Virtual Machine](#)

Managing Virtual Machine Resources

Manage virtual machine resources to reconfigure the vCPUs, memory, storage, or network resources of an existing virtual machine.

To reconfigure virtual machine resources, use the **Reprovision Virtual Machine** wizard, as described in:

- [Reprovisioning Virtual Machine Resources](#)

To reconfigure virtual machine volumes, see the following task-specific topics:

- [Creating a Volume in a Virtual Machine](#)
- [Attaching a Volume to a Virtual Machine](#)
- [Detaching a Volume from a Virtual Machine](#)

- [Removing a Volume from a Virtual Machine](#)
- [Expanding a Volume on the ztC Edge System](#)

To recover virtual machine resources, freeing space for new volumes or virtual CDs, see:

- [Recovering Virtual Machine Resources](#)

Reprovisioning Virtual Machine Resources

Reprovision a virtual machine (VM) to change its allocation of virtual CPUs (vCPUs), memory, storage, or network resources.

Launch the **Reprovision Virtual Machine** wizard by clicking **Config** in the bottom pane of the **Virtual Machines** page. The wizard steps you through the process of reallocating resources to the VM.

Prerequisites:



- Review the prerequisites and considerations for allocating vCPUs, memory, storage, and network resources to the VM, as listed in [Planning Virtual Machine Resources](#). For more information about storage resources, see [Planning Virtual Machine Storage](#).
- To reprovision a VM, you must shut down the VM.

To reprovision a virtual machine

1. Open the **Virtual Machines** page (see the [Virtual Machines Page](#)).
2. Select a VM and click **Shutdown**.
3. When the VM has stopped, click **Config** to display the **Reprovision Virtual Machine** wizard.
4. On the **Name, Description, and Protection** page:
 - a. Type the **Name** and an optional **Description** for the VM as they will appear in the ztC Edge Console

The VM name must meet the following requirements:

- A VM name must start with a word or a number, and the name cannot include the special characters (for example, #, %, or \$).
- A VM name cannot use hyphenated prefixes such as Zombie- or migrating-.
- A VM name has a maximum of 85 characters.

b. Select the level of protection to use for the VM:

- **Fault Tolerant (FT)**
- **High Availability (HA)**

For information about these levels of protection, see [Creating a New Virtual Machine](#) and [Modes of Operation](#).

c. Click **Next**.

5. On the **vCPUs and Memory** page:

- a. Specify the number of **vCPUs** and the amount of **Memory** to assign to the VM. For more information, see [Planning Virtual Machine vCPUs](#) and [Planning Virtual Machine Memory](#).
- b. Click **Next**.

6. On the **Volumes** page, you can:

Note:



You cannot modify the VM boot volume, only data volumes. However, you can detach the boot volume.

- Click **Boot Volume** to detach the boot volume.



Caution: If you detach the boot volume, the VM becomes unbootable.

A warning appears saying that detaching the boot value causes the VM to become unbootable. If you want to undo detaching the boot volume, click **Undo Detach**.

- Click **Detach** to disconnect a volume from a VM and keep it for future use.
- Click **Delete** to permanently remove a volume from the ztC Edge system.
- Select an unattached volume from a pulldown menu (if displayed) and click **Attach**.

You can also, if applicable, click **Add New Volume** to create a new data volume. (If the button is not visible, scroll down to the bottom of the wizard page.)

For an unattached volume or a new volume, specify the volume's parameters:

- a. Type the **Name** of the volume.
- b. Type the **Volume Size** of the volume in gigabytes (GB). For more information about allocating storage, see and [Planning Virtual Machine Storage](#).
- c. If applicable, click **Attach** to connect a volume to a VM.

To continue, click **Next**.

7. On the **Networks** page, activate the check box for each shared network that you want to attach to the VM.

For each shared network that you attach, you can also optionally:

- Set a custom MAC address (for details, see [Assigning a Specific MAC Address to a Virtual Machine](#)).
- Set the **State** to **Enabled** or **Disabled**, which allows you to allow or block network traffic to the selected network.

For more information, see [Planning Virtual Machine Networks](#). To continue, click **Next**.

8. On the **Configuration Summary** page:



Caution: Make sure that any volumes marked for removal are correct. When you click **Finish**, permanent data loss occurs on disks marked for removal.

- a. Review the configuration summary. If you need to make changes, click **Back**.
 - b. To accept the VM as provisioned, click **Finish**.
9. Click **Start** to restart the VM.
 10. For Windows-based VMs, if you changed the number of assigned virtual CPUs in a Windows-based VM from 1 to n or n to 1, after restarting the VM at the end of the re-provisioning process, you must shut down and restart the VM a second time. This allows the VM to correctly reconfigure itself for Symmetric Multiprocessing (SMP). The VM displays odd behavior and is not usable until it is restarted.

Related Topics

[Managing Virtual Machine Resources](#)

[Planning Virtual Machine Resources](#)

[Managing Virtual Machines](#)

Creating a Volume in a Virtual Machine

Create a volume to attach a new, blank volume to a virtual machine (VM). (You can also attach an existing, unattached volume as described in [Attaching a Volume to a Virtual Machine](#).)



Prerequisite: Before creating a volume for a VM, you must shut down the VM.

To create a new volume in a VM

1. Open the **Virtual Machines** page (see the [Virtual Machines Page](#)).
2. Select a VM and click **Shutdown**.
3. When the VM has stopped, click **Config** to display the **Reprovision Virtual Machine** wizard.
4. Click **Next** on each wizard page until the **Volumes** page is displayed. (If applicable, see [Reprovisioning Virtual Machine Resources](#) to configure additional VM resources.)
5. On the **Volumes** page, click **Add a new volume**. (If the button is not visible, scroll down to the bottom of the wizard page.)
6. Under **To Be Created**, do the following:

- a. Type the **Name** of the volume as it will appear in the ztC Edge Console.

The volume name must meet the following requirements:

- Valid characters are a-z, A-Z, 0-9 , +, _ , and . (dot).
- A volume name cannot be only . or .. (dots).
- A volume name cannot be snapshot or pvmove.
- A volume name cannot contain any of the following reserved strings: _cdata, _cmeta, _corrig, _mlog, _mimage, _pmspare, _rimage, _rmeta, _tdata, _tmeta, or _vorigin.

- b. Type the **Volume Size** of the volume to create in gigabytes (GB). For more information about allocating storage, see [Planning Virtual Machine Storage](#).
7. Click **Next** on each wizard page until the **Configuration Summary** page is displayed. Verify the configuration changes.
 8. Click **Finish** to create the volume.

9. Start the VM and prepare the volume for use in the guest operating system, as described in:

- [Creating and Initializing a Disk \(Windows-based VMs\)](#)
- [Creating and Initializing a Disk \(Linux-based VMs\)](#)

Related Topics

[Detaching a Volume from a Virtual Machine](#)

[Removing a Volume from a Virtual Machine](#)

[Managing Virtual Machine Resources](#)

[Planning Virtual Machine Resources](#)

[Managing Virtual Machines](#)

Attaching a Volume to a Virtual Machine

Attach a volume to connect a currently unused volume to a virtual machine.



Note: If you attach a boot volume to a VM that already has a boot volume, the newly added volume is attached as a data volume. You might want to attach a volume in this manner to diagnose a boot problem or data corruption in another VM's boot volume. After using guest operating system tools to resolve the issue, detach the volume and reattach it to its original VM.



Prerequisite: Before attaching a volume to a virtual machine, you must shut down the virtual machine.

To attach a volume to a virtual machine

1. Ensure that the volume you want to attach is not in use by another virtual machine; otherwise, you cannot attach it. Open the **Volumes** page, locate the volume, and ensure that the value in the **Used By** column is **None**.
2. Open the **Virtual Machines** page (see the [Virtual Machines Page](#)).
3. Select a VM and click **Shutdown**.
4. When the VM has stopped, click **Config** to display the **Reprovision Virtual Machine** wizard.
5. Click **Next** on each wizard page until the **Volumes** page is displayed. (If applicable, see [Reprovisioning Virtual Machine Resources](#) to configure additional VM resources.)

6. On the **Volumes** page, locate the pulldown menu next to the **Add a new volume** button. Select an unattached volume from the pulldown menu and click **Attach**.

(If the pulldown menu is not visible, scroll down to the bottom of the wizard page. The pulldown menu is displayed only if there are unattached volumes on the ztC Edge system.)

7. Click **Next** on each wizard page until the **Configuration Summary** page is displayed. Verify the configuration changes.
8. Click **Finish** to attach the selected volume.

Related Topics

[Creating a Volume in a Virtual Machine](#)

[Detaching a Volume from a Virtual Machine](#)

[Removing a Volume from a Virtual Machine](#)

[Managing Virtual Machine Resources](#)

[Planning Virtual Machine Resources](#)

[Managing Virtual Machines](#)

Detaching a Volume from a Virtual Machine

Detach a volume to disconnect it from a virtual machine and keep it for future use, or attach it to another virtual machine as described in [Attaching a Volume to a Virtual Machine](#). (You can also permanently delete the volume from the ztC Edge system, as described in [Removing a Volume from a Virtual Machine](#).)



Note: If you detach a boot volume from a VM, you cannot boot the VM; however, you might want to detach the boot volume to diagnose a boot problem or data corruption in the volume. You can temporarily attach the boot volume to another VM as a data volume, as described in [Attaching a Volume to a Virtual Machine](#). After using guest operating system tools to resolve the issue, detach the volume and reattach it to its original VM.



Prerequisite: Before detaching a volume from a virtual machine, you must shut down the virtual machine.

To detach a volume from a virtual machine

1. Open the **Virtual Machines** page (see the [Virtual Machines Page](#)).
2. Select a VM and click **Shutdown**.
3. When the VM has stopped, click **Config** to display the **Reprovision Virtual Machine** wizard.
4. Click **Next** on each wizard page until the **Volumes** page is displayed. (If applicable, see [Reprovisioning Virtual Machine Resources](#) to configure additional VM resources.)
5. On the **Volumes** page, locate the volume to detach. (If the volume is not visible, scroll down on the wizard page.)
6. Click **Detach** beside the volume name to mark the volume for detachment.



Caution: Be careful to mark the correct volume to detach, avoiding any volumes that are currently in use.

7. Click **Next** on each wizard page until the **Configuration Summary** page is displayed. Verify the configuration changes.
8. Click **Finish** to detach the selected volume.

Related Topics

[Attaching a Volume to a Virtual Machine](#)

[Removing a Volume from a Virtual Machine](#)

[Managing Virtual Machine Resources](#)

[Planning Virtual Machine Resources](#)

[Managing Virtual Machines](#)

Removing a Volume from a Virtual Machine

Remove a virtual machine (VM) volume to permanently delete it from the ztC Edge system. (You can also detach a volume from the VM but keep it for future use, as described in [Detaching a Volume from a Virtual Machine](#).)



Prerequisite: Before removing a volume attached to a virtual machine, you must shut down the virtual machine.

To remove a volume that is attached to a virtual machine

1. Open the **Virtual Machines** page (see the [Virtual Machines Page](#)).
2. Select a VM and click **Shutdown**.
3. When the VM has stopped, click **Config** to display the **Reprovision Virtual Machine** wizard.
4. Click **Next** on each wizard page until the **Volumes** page is displayed. (If applicable, see [Reprovisioning Virtual Machine Resources](#) to configure additional VM resources.)
5. On the **Volumes** page, locate the volume to delete. (If the volume is not visible, scroll down on the wizard page.)
6. Click **Delete** beside the volume name to mark the volume for deletion.



Caution: Be careful to mark the correct volume to remove, avoiding any volumes that are currently in use.

7. Click **Next** on each wizard page until the **Configuration Summary** page is displayed. Verify the configuration changes.
8. Click **Finish** to permanently delete the selected volume.

To remove an unattached volume



Caution: Before removing a volume, ensure that it is no longer needed by other administrators.

1. Open the **Volumes** page.
2. Select an unattached volume. (The **Used By** column must read **None**, otherwise, the **Remove** button is not displayed.)
3. Click **Remove**.

Related Topics

[Detaching a Volume from a Virtual Machine](#)

[Attaching a Volume to a Virtual Machine](#)

[Managing Virtual Machine Resources](#)

[Planning Virtual Machine Resources](#)

[Managing Virtual Machines](#)

Renaming a Volume on the ztC Edge System

Rename a volume on the ztC Edge system to change its name as it appears on the **Volumes** page.

If you need to change the name of a disk or volume in the guest operating system running in a virtual machine, use guest operating system tools.

To rename a volume on the ztC Edge system

1. Locate the volume on the **Volumes** page.
2. Double-click the name of the volume.
3. Specify the new name and press **Enter**. For volume naming restrictions, see [Creating a Volume in a Virtual Machine](#).

Related Topics

[Creating a Volume in a Virtual Machine](#)

[Detaching a Volume from a Virtual Machine](#)

[Removing a Volume from a Virtual Machine](#)

[Managing Virtual Machine Resources](#)

[Planning Virtual Machine Resources](#)

[Managing Virtual Machines](#)

Expanding a Volume on the ztC Edge System

Expand a virtual machine (VM) volume to allocate more space for programs and data in the guest operating system.

You can expand a volume, but you cannot reduce the size of a volume. Use the following procedure to expand a volume only when the VM is stopped.

Prerequisites:



- You must shut down the VM before expanding a volume that it contains.
- Ensure that both PMs of the ztC Edge system are online; otherwise, the system cannot properly expand a volume.

To expand a volume

1. On the **Physical Machines** page (see the [Physical Machines Page](#)) of a system configured with two nodes, verify that both PMs are in the **running** state and that neither PM is in maintenance mode or in the process of synchronizing.
2. On the **Virtual Machines** page (see the [Virtual Machines Page](#)), select the VM that contains the volume that you want to expand. Ensure that the VM is **stopped**.
3. In the bottom pane, click the **Volumes** tab and select the volume that you want to expand. In the **Action** column, click **Expand Volume**.
4. Next to **Expand By**, type the amount of storage space to add to the volume (in gigabytes (GB)). When you type the number, the dialog box displays the **Expanded Volume Size** that will result if you complete the operation.



Note: Consider the **Expand By** entry carefully, because after expanding a volume, you cannot undo the change or reduce the size of the volume; you can only expand the volume further.

5. Click **Expand Volume** to commit the change and expand the volume. The dialog box displays the expansion progress and automatically closes when the operation is complete.

Related Topics

[Creating a Volume in a Virtual Machine](#)

[Detaching a Volume from a Virtual Machine](#)

[Removing a Volume from a Virtual Machine](#)

[Managing Virtual Machine Resources](#)

[Planning Virtual Machine Resources](#)

[Managing Virtual Machines](#)

Recovering Virtual Machine Resources

To conserve storage space, remove VM resources when they are no longer needed. You may also need to immediately recover storage space when there is insufficient space for certain tasks, such as creating a volume or VCD.

To recover storage space, remove unused resources as described in the following topics:

- [Removing a Virtual Machine](#)
- [Removing a Volume from a Virtual Machine](#)
- [Removing a Virtual CD](#)

Related Topics

[Managing Virtual Machine Resources](#)

[Planning Virtual Machine Resources](#)

[Managing Virtual Machines](#)

Managing Virtual CDs

Create and manage virtual CDs (VCDs) to make software installation media available to the virtual machines on your ztC Edge system in ISO format.

A VCD is a read-only ISO image file that resides on a storage device of the ztC Edge system. Use the **Virtual CD Creation Wizard** (in ztC Edge Console) to upload an existing ISO file, as described in [Creating a Virtual CD](#).

After you create a VCD, you can boot from it to install a Windows or Linux guest operating system, or start a VM from a bootable recovery VCD. You can download a VCD to your local computer. You can also insert a VCD into a running VM to install software applications.

You manage VCDs as described in:

- [Creating a Virtual CD](#)
- [Inserting a Virtual CD](#)
- [Ejecting a Virtual CD](#)
- [Booting from a Virtual CD](#)
- [Renaming a Virtual CD](#)
- [Downloading a Virtual CD](#)
- [Removing a Virtual CD](#)

Users who are assigned the role **Administrator** or **Platform Manager** can perform all VCD tasks. Users who are assigned the role **VM Manager** can perform all VCD tasks, except rename a VCD. (For information on assigning these roles, see [Managing Local User Accounts](#).)

Creating a Virtual CD

Create a virtual CD (VCD) to make software installation media available to the virtual machines (VM) on your ztC Edge system.

To create a VCD, use the **Virtual CD Creation Wizard** to upload or copy an ISO file to a storage device on the ztC Edge system. Thereafter, you can boot from it (see [Booting from a Virtual CD](#)) to install a guest operating system or start a VM from a bootable recovery VCD. You can also insert a VCD into a running VM (see [Inserting a Virtual CD](#)) to install software applications.

Notes:






1. Unless you use a VCD on a regular basis, remove it when it is no longer needed.
2. If you create a bootable VCD for installation, it must be a single CD or DVD. Multiple CDs or DVDs are not supported.

To create a VCD

1. If necessary, create ISO files of any physical media for which you will create VCDs.
2. Open the **Virtual CDs** page in the ztC Edge Console.
3. Click **Create VCD** to open the **Virtual CD Creation Wizard**.
4. Type a name for the VCD.
5. Select a source for the VCD:
 - **Upload ISO file** uploads a file from your system running the ztC Edge Console. Click **Browse**, select the ISO file on your system, and click **Open**.
 - **Copy CD ISO from network source** copies the file from a Web URL. Specify the URL of the ISO file.
6. Click **Finish** to upload or copy the ISO file from the specified source.

The **Virtual CD Creation Wizard** displays progress of the upload.

You can determine the status of a VCD by checking the **State** column on the **Virtual CDs** page:

- A syncing icon () indicates that the VCD is still being created.
- A broken icon () indicates that the VCD creation failed. Remove the VCD and try creating it again.
- A normal icon () indicates that the transfer is complete and that the VCD is ready to use.

Related Topics

[Inserting a Virtual CD](#)

[Ejecting a Virtual CD](#)

[Managing Virtual CDs](#)

[Creating and Migrating Virtual Machines](#)

Inserting a Virtual CD

Insert a virtual CD (VCD) in a virtual machine (VM) to access installation media when installing applications in a guest operating system. (To attach a USB device, see [Attaching a USB Device to a Virtual Machine](#). To boot a virtual machine from a VCD, see [Booting from a Virtual CD](#).)



Caution: When you insert a VCD into a running VM, it prevents the Stratus Redundant Linux software from migrating the VM to a different physical machine in the event of a failure. To restore redundancy, unmount and eject the VCD as soon as you finish using it.



Note: By default, VCDs are enabled for insertion in VMs. To change this configuration, see [Configuring VM Devices](#).

To connect a VCD to a VM

1. If necessary, create a VCD (see [Creating a Virtual CD](#)) for the software installation media you need to access.
2. On the **Virtual Machines** page, select a VM.
3. In the bottom pane, click the **CD Drives & USB Devices** tab.
4. To select a VCD, click **Insert a CD** and select a VCD. Use the pulldown menu, if it exists.

When the system has inserted the VCD, its name appears to the right of **CD-ROM**.

Related Topics

[Creating a Virtual CD](#)

[Ejecting a Virtual CD](#)

[Booting from a Virtual CD](#)

[Managing Virtual CDs](#)

Ejecting a Virtual CD

Eject a virtual CD (VCD) to disconnect it from a virtual machine (VM). Ejecting a VCD allows you to insert another VCD into the VM. It also makes the VCD available for inserting into another VM.

To eject a VCD from a VM

1. Unmount the VCD from the guest operating system to ensure that it is not in use.
2. On the **Virtual Machines** page, select a VM.
3. Click the **CD Drives & USB Devices** tab in the lower frame.
4. On the **CD Drives** tab, click **Eject CD**.

Related Topics

[Creating a Virtual CD](#)

[Inserting a Virtual CD](#)

[Booting from a Virtual CD](#)

[Managing Virtual CDs](#)

Booting from a Virtual CD

Boot a virtual machine from a virtual CD (VCD) to install a guest operating system or to perform maintenance.

Before booting from a VCD, you must shut down the virtual machine.

To boot a virtual machine from a VCD

1. If necessary, create a VCD from a bootable CD/DVD (see [Creating a Virtual CD](#)).
2. On the **Virtual Machines** page, select a virtual machine.
3. If the virtual machine is running, click **Shutdown**.
4. When the virtual machine status shows **stopped**, click **Boot from CD** in the lower pane.
5. Select the bootable VCD, then click **Boot**.



Note: A Windows-based virtual machine booted from a VCD boots as a hardware virtual machine (HVM), and it can access only the first three disk volumes.

Related Topics

[Creating a Virtual CD](#)

[Inserting a Virtual CD](#)

[Ejecting a Virtual CD](#)

[Managing Virtual CDs](#)

[Creating and Migrating Virtual Machines](#)

[Managing the Operation of a Virtual Machine](#)

Renaming a Virtual CD

Rename a virtual CD (VCD) to change its name as it appears on the **Virtual CDs** page.

To rename a VCD

1. Locate the VCD on the **Virtual CDs** page.
2. Double-click the name of the VCD.
3. Specify the new name and press **Enter**.

Related Topics

[Removing a Virtual CD](#)

[Inserting a Virtual CD](#)

[Ejecting a Virtual CD](#)

[Creating a Virtual CD](#)

[Managing Virtual CDs](#)

Downloading a Virtual CD

Download a virtual CD (VCD) to make the software on the VCD available for uploading at a future time.



Prerequisite: You must first create a VCD, if you have not yet done so. See [Creating a Virtual CD](#).

To download a VCD

1. Open the **Virtual CDs** page in the ztC Edge Console.
2. Click the name of the VCD you want to download.
3. Click **Download**. A window opens, displaying a folder on your local computer.
4. Select a destination for the file and click **Save**.

Depending on the size of the file, the download may require several minutes to complete.

Related Topics

[Managing Virtual CDs](#)

Removing a Virtual CD

Remove a virtual CD (VCD) to permanently delete it from the ztC Edge system.

To remove a VCD

1. In the ztC Edge Console, click **Virtual CDs**.
2. Locate the VCD you want to remove in the list.
3. Ensure that the **Can Remove** column displays **Yes** for the VCD. If the value is **No**, the VCD is currently in use.
4. Select the VCD and click **Remove** in the lower panel.

Related Topics

[Renaming a Virtual CD](#)

[Inserting a Virtual CD](#)

[Ejecting a Virtual CD](#)

[Creating a Virtual CD](#)

[Managing Virtual CDs](#)

Advanced Topics (Virtual Machines)

The following topics describe procedures and information for advanced users:

- [Assigning a Specific MAC Address to a Virtual Machine](#)
- [Selecting a Preferred PM for a Virtual Machine](#)

- [Forcing a VM to Boot](#)
- [Changing the Protection Level for a Virtual Machine \(HA or FT\)](#)
- [Configuring the Boot Sequence for Virtual Machines](#)
- [Resetting MTBF for a Failed Virtual Machine](#)
- [Attaching a USB Device to a Virtual Machine](#)

To manage the operation of a virtual machine, see [Managing the Operation of a Virtual Machine](#).

Assigning a Specific MAC Address to a Virtual Machine

Assign a specific Media Access Control (MAC) address to a virtual machine (VM) if you need to override its default MAC address.

Warnings:



1. By default, the Stratus Redundant Linux software automatically assigns MAC addresses to the VMs. Do not override the default settings unless you have specific requirements (for example, to support software applications that are licensed on a MAC-address basis).
2. If you change the **Static System IP** address, any MAC addresses automatically assigned to the VMs will change when the VMs reboot, because the Stratus Redundant Linux software generates MAC addresses for the VMs based on the system IP address. To prevent changes to the MAC address for a VM, set a persistent MAC address as described in the following procedure. Contact your network administrator to generate a valid MAC address for your environment, and remember to update any firewall rules based on the new MAC address.



Prerequisite: Before modifying the MAC address for a virtual machine, you must shut down the VM.

To assign a specific MAC address to a VM

1. Open the **Virtual Machines** page (see the [Virtual Machines Page](#)).
2. Select a VM and click **Shutdown**.
3. When the VM has stopped, click **Config** to display the **Reprovision Virtual Machine** wizard.

4. Click **Next** on each wizard page until the **Networks** page is displayed. (If applicable, see [Reprovisioning Virtual Machine Resources](#) to configure additional VM resources.)
5. On the **Networks** page, locate the network to modify and make a note of the current MAC address in case you need to restore it.
6. Type the new address in the **MAC address** column, or leave the text area blank to allow the Stratus Redundant Linux software to automatically assign the MAC address.
7. Click **Finish**.

Related Topics

[Advanced Topics \(Virtual Machines\)](#)

[Managing Virtual Machine Resources](#)

[Managing the Operation of a Virtual Machine](#)

Selecting a Preferred PM for a Virtual Machine

On systems configured with two nodes, select a preferred physical machine to ensure that a virtual machine runs on a particular physical machine in the ztC Edge system.



Note: By default, the system automatically balances the load of virtual machines over the two physical machines. Do not modify this setting unless you have specific load balancing requirements .

To select a preferred physical machine

1. On the **Virtual Machines** page, select a virtual machine.
2. In the bottom pane, click the **Load Balance** tab.
3. Choose your preference from the pulldown list and click **Save**.

Related Topics

[Advanced Topics \(Virtual Machines\)](#)

[Managing the Operation of a Virtual Machine](#)

Forcing a VM to Boot

You can force a VM to boot using the **Force Boot** button on the VIRTUAL MACHINES page. However, the **Force Boot** button is active only when the ztC Edge Console reports that the partner node is powered off or otherwise unreachable. When you use **Force Boot** to bring a VM online, you manually by-pass the system's safety checks to protect data, so you must use **Force Boot** with extreme caution and with full understanding of the conditions and consequences of using it.



Caution: Before using **Force Boot**, read this entire topic and consult with your authorized Stratus service representative. The service representative can review your system, including the date of the last volume synchronization, and can then discuss with you the full impact of using **Force Boot**. Then, you can decide, with your service representative, whether or not to force a VM to boot.

When you force a VM online with **Force Boot**, you select a node (that is, the node that is reachable) on which to force the VM to boot. All data on that node is marked as valid, regardless of the actual condition of the data (for example, the data's state, the last synchronization, the condition of the volume, etc.).

During the **Force Boot** process, the VM's volumes are tagged with the date and time that the force-boot process was initiated. The VM's AX components (that is, the VM's AX pair) use the data on the VM's volumes and communicate the status of that data to determine which AX contains the up-to-date volume information. The **Force Boot** process overrides the built-in logic that protects a VM from running in a split-brain condition. If the AX pair cannot communicate, a split-brain condition occurs and damages data integrity (for information on the split-brain condition, see [Creating an ALSR Configuration](#)).

Warnings: Do not use **Force Boot** in the following situations:



- One or more volumes is the target of an unfinished mirror copy on the node where you will perform **Force Boot**.
- A target of an unfinished mirror copy is not good and will not be available even with **Force Boot**.
- The volumes are not synchronized. The following two situations are examples:
 - Both of the VM's AXs must have access to all of the VM's data volumes.
 - On a system with multiple volumes, the VM needs both AXs to be running in order for the VM to have access to all of its volumes because each node has a green-checked copy of a different volume, and the volume's mirror copy on the opposite node is not green-checked.
- Both nodes are required because multiple VMs are degraded, yet are green-checked on opposite nodes (for example, Node0 has a good boot volume but a bad data volume, while Node1 has a bad boot volume but a good data volume).
- The system is configured with one node.

If you perform a **Force Boot** on a system with outdated volumes, contact your authorized Stratus service representative immediately. If both nodes are powered on and have started to synchronize data, the system uses data from the VM that you forced to boot, and you cannot recover the data on the node that was unreachable.

In some circumstances, however, you might be able to recover data after you use **Force Boot** on a system with outdated volumes:

- If the unreachable node is still powered off, do not power it on.
- If the unreachable node was powered off before you clicked **Force Boot**, then the VM's AX on the powered-off node is preserved and you can reverse the **Force Boot** without data loss under the following conditions:
 - The VM that you forced to boot does not have new data (that is, the VM has not been put in production).
 - Before you forced the VM to boot, the VM's AX on the unreachable node did not exchange status with the AX of the VM that you will force to boot.

- The issue preventing the VM's AX on the unreachable node from booting is resolved.
- All VM data between the two nodes is accurately synchronized. The system has no VMs where, of each VM's two AX components, the data of the VM's AX on one node is in a different state from the data of the VM's AX on the other node.

If your system meets all of the conditions above, contact your authorized Stratus service representative to advise you on a recovery process.

If you have decided to force a VM to boot, be sure to prepare for it by performing the prerequisite procedures.

Prerequisites:



- Manually check all volumes to ensure that you can safely override them. For example, the volume state should be green-checked, and disk synchronization should be finished.
- Determine if both AX components of the VM can communicate and can allow the system processes to determine the state of each volume. To prevent a split-brain condition, you must ensure that the two AX components of the VM can communicate status and can determine which AX has good data and good boot volumes.
- Ensure that the system is configured with two nodes.
- Contact your authorized Stratus service representative.

To force a VM to boot

After you have consulted with your authorized Stratus service representative, and you have decided to force a VM to boot, perform the following procedure. In the examples, node0 is offline, node1 is the primary, and VM-1 is stopped.

1. In the ztC Edge Console of a system configured with two nodes, click **Virtual Machines** in the left panel.
2. Navigate to the **Virtual Machines** page.
3. On the **Virtual Machines** page, select the VM that is stopped and that you want to force to boot (for example, VM-1).
4. In the bottom panel, click the **Start** button.

The VM begins to boot. It continues booting until the time-out limit is reached, possibly as long as 5 minutes. When the time-out limit is reached, the **Force Boot** button becomes active.

5. To force the VM to boot, click **Force Boot**.


A warning appears, asking you if you are positive that you know which node has the most up-to-date VM data. The warning also tells you to be aware that data loss is possible. In addition, a message tells you the node on which you can force the VM to boot.



Caution: If you select the wrong node during **Force Boot**, data is damaged.

You must type the node (node0 or node1) as indicated in the message. The following message is an example:

Force Boot VM-1



DO NOT PROCEED UNLESS YOU ARE POSITIVE YOU KNOW WHICH NODE HAS YOUR MOST UP TO DATE VM DATA. BE AWARE THAT DATA LOSS IS POSSIBLE.

Only node1 can be force-booted.

If you would like to boot the VM on node1, type **node1**:

[OK button] [Cancel button]

6. Click **OK** to force the node (for example, node1) to boot. (Click **Cancel** to cancel the procedure.) As the force-boot process begins and continues, additional confirmation messages appear before the VM starts and the data is marked as valid to the system.

The VM begins to run. On the **Virtual Machines** page, the VM is listed with a warning because the node (for example, node0) is still offline.

Once the secondary node is brought back in to the system, all data synchronizes from the node running the VM. In this example, all data synchronizes from node1 to node0.

Related Topics

[Advanced Topics \(Virtual Machines\)](#)

[Managing the Operation of a Virtual Machine](#)

Changing the Protection Level for a Virtual Machine (HA or FT)

You can change the protection level of guest VMs from high availability (HA) to fault tolerance (FT), or vice versa.

To change the protection level

1. On the **Virtual Machines** page, select a stopped VM (marked "stopped" in the **Activity** column). (See [Shutting Down a Virtual Machine](#) for information about stopping a VM.)
2. In the bottom pane, click **Config** to open the **Reprovision Virtual Machine** wizard.
3. On the **Name, Description and Protection** page, select the **HA** or **FT** button.
4. Continue clicking through the wizard pages to the last page. Press **Finish** and then **OK** (if the reconfiguration was successful).

Related Topics

[Modes of Operation \(HA or FT\)](#)

[Advanced Topics \(Virtual Machines\)](#)

[Managing the Operation of a Virtual Machine](#)

Configuring the Boot Sequence for Virtual Machines

Configure the boot sequence of virtual machines to set the order in which guest operating systems and applications are started on the ztC Edge system.

Determine the required boot sequence, then configure the boot settings for each virtual machine accordingly.

To set the boot sequence for a virtual machine

1. On the **Virtual Machines** page, select a virtual machine.
2. In the bottom pane, click the **Boot Sequence** tab.
3. Configure the boot settings, as described below.
4. Click **Save**.

The boot settings are as follows:

- **Priority Group** enables users to specify the order in which virtual machines boot after powering on the ztC Edge system or after a failover, which requires restarting virtual machines. Some business solutions require specific virtual machines to be running before starting others. Group **1** is the highest priority and **none** is the lowest. The Stratus Redundant Linux software waits for the **OS and Application Start Time** to elapse before starting virtual machines in the next priority group.

Boot sequence example:

VM	Priority Group	OS and Application Start Time
DNS	1	2 mins
App	2	30 secs
DB	2	10 mins
Web	3	0

- 1 ztC Edge boots the DNS VM.
- 2 2 minutes after the DNS VM is started, ztC Edge starts the App and DB servers in group 2.
- 3 10 minutes after the DB VM is started, ztC Edge starts the Web VM in group 3.

- **OS and Application Start Time** should be set to the time it takes from starting the virtual machine until the guest operating system and applications are fully functional.

Related Topics

[Advanced Topics \(Virtual Machines\)](#)

[Managing the Operation of a Virtual Machine](#)

Resetting MTBF for a Failed Virtual Machine

Reset the mean time between failure (MTBF) counter for a virtual machine to attempt to restart a failed virtual machine.

If a virtual machine's guest OS crashes, ztC Edge automatically restarts it, unless it has fallen below its MTBF threshold. If the virtual machine is below the MTBF threshold, ztC Edge leaves it in the crashed state. If necessary, you can reset the MTBF counter and restart the virtual machine.



Caution: Do not reset the MTBF counter unless instructed to do so by your authorized Stratus service representative, as doing so may affect the continuous uptime of your system.

Notes:



1. The **Reset Device** button is displayed only if the virtual machine falls below its MBTF threshold.
2. The **Clear MTBF** button is displayed only if the system software supporting a VM on one physical machine falls below its MBTF threshold.

To reset the MTBF counter for a virtual machine

1. On the **Virtual Machines** page, select a virtual machine.
2. Click **Reset Device**.

If the system software supporting a VM on one physical machine fails too often, perform the steps below to reset its MTBF counter.

To reset the MTBF counter for a VM on one physical machine

1. On the **Virtual Machines** page, select a virtual machine.
2. Click **Clear MTBF**.

Related Topics

[Advanced Topics \(Virtual Machines\)](#)

[Managing the Operation of a Virtual Machine](#)

[Creating a Diagnostic File](#)

Attaching a USB Device to a Virtual Machine

Attach a USB device to a virtual machine (VM) in order to enable the VM to use the device. A USB device may be needed, for example, when a USB-based license is required to install an application in a guest operating system. When you no longer need the USB device, detach it.

(If you need to mount a USB device on the ztC Edge system to use the device for exporting or importing VMs, see [Mounting a USB Device or Network-mounted Folder on the ztC Edge System.](#))

Caution:



When you attach a USB device to a running, fault-tolerant (FT) VM, it prevents the Stratus Redundant Linux software from migrating the VM to a different physical machine in the event of a failure. To restore fault-tolerant operation, detach and remove the USB device as soon as you finish using it.

Notes:

1. You can attach only supported USB devices to a guest operating system. For a list of the USB devices that ztC Edge systems support, see [System Specifications](#).

Note that ztC Edge systems do not support USB 3.2 Gen 2 (10 Gbps), or higher, devices in the guest operating system. However, you can insert a Gen 2 or higher device into a USB 3.2 Gen 1 (5 Gbps) host port, which forces the device to operate at the Gen 1 (5 Gbps) speed; in this case, you can attach the device to a guest operating system. (USB 3.2 Gen 1 (5 Gbps) devices are formerly referred to as USB 3.1 Gen 1 devices, and USB 3.2 Gen 2 (10 Gbps) devices are formerly referred to as USB 3.1 Gen 2 devices.)

2. Do not attach a USB-attached SCSI (UAS) compliant device to a VM because the system does not support UAS devices.



3. The VM must be running in order for you to attach a USB device to it.
4. By default, USB devices are enabled for attachment to VMs. To change this configuration, see [Configuring VM Devices](#).
5. Use either of the following methods to detach (that is, eject) a supported USB device from a Windows-based VM:
 - Clicking Eject in File Explorer—If you eject the device from File Explorer, you must detach it in the ztC Edge Console using the procedure below. Then, physically remove it from the ztC Edge system and reinsert it before reattaching to the same or another VM.
 - Clicking Safely Remove Hardware and Eject Media in the taskbar—If you eject the device from the taskbar, you must detach it in the ztC Edge Console using the procedure below. You do not need to physically remove it from the ztC Edge system before reattaching it to the same or another VM.

To attach a USB device to a VM

1. Insert the USB device into the primary (active) node for the VM.

The **Virtual Machines** page displays the primary node for each VM as the **Current PM**. (This node may be different from the current primary node for the ztC Edge system, as displayed on the **Physical Machines** page.)

Confirm that the system displays the USB device. Navigate to the **Physical Machines** page. Click the node into which you inserted the device, and in the lower pane, select the **USB Device** tab. The USB device you inserted should appear in the tab's display.

2. On the **Virtual Machines** page, select a VM.
3. In the bottom pane, click the **CD Drives & USB Devices** tab.
4. On the **USB** line of the **CD Drives & USB Devices** tab, select a USB device from the pull-down menu.
5. Click **Attach a USB** to attach the USB device to the VM.
6. A **Confirm** dialog box appear, asking if you are sure you want to attach the device and displaying a warning that the guest goes simplex while the USB device is in use. Click **Yes** to attach the device.

After the system attaches the USB device to the VM, the USB device name appears in the list of USB devices on the **CD Drives & USB Devices** tab for the VM.

To detach a USB device from a VM

1. On the **Virtual Machines** page, select the VM to which the USB device is attached.
2. In the bottom pane, click the **CD Drives & USB Devices** tab.
3. On the **USB** line of the **CD Drives & USB Devices** tab, click **Detach USB device**. If necessary, select the USB device from the pull-down menu.
4. A **Confirm** dialog box appear, asking if you are sure you want to detach the device. Click **Yes** to detach the device.

After the system detaches the USB device to the VM, the USB device name no longer appears in the list of USB devices on the **CD Drives & USB Devices** tab for the VM.

Related Topics

[Managing Virtual Machines](#)

7

Chapter 7: Maintaining Physical Machines

You can maintain physical machines (PMs), or nodes, in a ztC Edge system by replacing or recovering them.

To replace a failed PM, use one of the following procedures:

- [Replacing Physical Machines \(Automated\)](#) (Recommended)

Describes how to replace a failed PM with the automated node replacement process. This help topic supplements the information in [ztC Edge 100i/110i Systems: Replacing a Node](#) (R013Z) or [ztC Edge 200i/250i Systems: Replacing a Node](#) (R019Z), which is included with each replacement node.

- [Replacing Physical Machines \(Manual\)](#)

Describes how to replace a failed PM with the user-initiated replacement process, which you start and monitor from the ztC Edge Console. Avoid using this user-initiated procedure unless specifically instructed by your authorized Stratus service representative.

To recover the system software on a failed PM instead of replacing the PM hardware, see [Recovering a Failed Physical Machine \(Manual\)](#).

To add a node to a system configured with one node, see [Adding a Node to a Single-Node System](#).

Replacing Physical Machines (Automated)

This topic describes how to replace a failed physical machine (PM), or node, in a dual-node ztC Edge system with the automated node replacement process. It supplements information in the [replacing a node guide](#) for your system.

You replace a node in a dual-node system while the system is running.

Prerequisite: To request a replacement ztC Edge node, log on to your **Stratus Customer Service Portal** account, expand **Customer Support**, and click **Add Issue**. When creating the issue, please have the following information ready:



- **Asset ID**—Locate the **Asset ID** for your system in the masthead of the ztC Edge Console window.
- **Diagnostic file**—Generate and download a diagnostic file on the **Support Logs** page of the ztC Edge Console, as described in [Creating a Diagnostic File](#). Attach the diagnostic file to the issue that you add in the portal.

A customer service representative will contact you to diagnose the issue and provide a replacement node, if necessary.



Prerequisite: The replacement node must be factory fresh, installed with Release 2.3.0.0 or higher, and the same model as the healthy/running node. If you need to use a spare node that is imaged with any release prior to Release 2.3.0.0, you must exchange it for a factory-imaged Release 2.3.x.x node to support pairing with any Release 2.3.x.x primary node. Contact your authorized Stratus service representative for assistance.

To replace a node in a ztC Edge system

1. Locate the node to replace. The faulted node is either powered off (automatically) or powered on with the SYS LED off or solid green or yellow (not healthy). If the node is already powered off, skip to step 3.
2. If the faulted node is still powered on, open the ztC Edge Console to resolve any issues blocking shutdown. For example, a failed network connection on the healthy node can cause a dependency on the faulted node. Resolve any issues and shut down the faulted node.
3. Disconnect the power cable from the faulted node, disconnect the signal ground wire and network cables, and then remove the node from the system.
4. Add the replacement node to the system. Reconnect the network cables and signal ground wire, then reconnect power to automatically power on the node. The node replacement is complete. The system begins to synchronize with no user input required.

5. After 20 minutes, the SYS LED cycles from off to solid green or yellow to show that the software on the replacement node is starting. After another 15 minutes, the SYS LED starts flashing to show that the system is healthy.
6. Log on to the ztC Edge Console to confirm the system health. The virtual machines may continue to synchronize for hours. After synchronization completes successfully, the **Dashboard** should display green check marks with no outstanding issues.
7. If the replacement node does not automatically exit maintenance mode and begin synchronizing VMs, you might need to re-activate the product license for the ztC Edge system. On the **Preferences** page, click **Product License** and click **Check License Now** to automatically activate the license. If the system has no Internet access, activate the license as described in [Managing the Product License](#).



Note: The new node cannot exit maintenance mode and run VMs until the ztC Edge license is re-activated.

8. If needed, when you are ready to bring the replacement node online, open the **Physical Machines** page and click **Finalize** to exit maintenance mode. Verify that both PMs return to the **running** state and that the nodes finish synchronizing.

Replacing a Node Guides

[ztC Edge 100i/110i Systems: Replacing a Node](#) (R013Z)

[ztC Edge 200i/250i Systems: Replacing a Node](#) (R019Z)

Related Topics

[Maintenance Mode](#)

[Maintaining Physical Machines](#)

[ztC Edge Console](#)

[Physical Machines and Virtual Machines](#)

[Physical Machines Page](#)

Replacing Physical Machines (Manual)



Caution: If you need to recover or replace a PM in a ztC Edge system, use the instructions in [ztC Edge 100i/110i Systems: Replacing a Node \(R013Z\)](#) or [ztC Edge 200i/250i Systems: Replacing a Node \(R019Z\)](#). (If needed, see [Replacing Physical Machines \(Automated\)](#) for additional details.) Avoid using the manual procedure described in this topic unless specifically instructed by your authorized Stratus service representative.

You replace a physical machine (PM), or node, of a dual-node ztC Edge system while the system is running. (If you need to recover the system software on a failed PM instead of replacing the PM hardware, see [Recovering a Failed Physical Machine \(Manual\)](#).)

When you remove and replace a PM, the system completely erases all of the disks in the replacement PM in preparation for a full installation of the Stratus Redundant Linux system software. To install the software, you can allow the system to automatically boot the replacement node from a temporary Preboot Execution Environment (PXE) server on the primary PM. As long as each PM contains a full copy of the most recently installed software kit (as displayed on the **Upgrade Kits** page of the ztC Edge Console), either PM can initiate the replacement of its partner PM with PXE boot installation. If needed, you can also manually boot the replacement node from USB installation media.

Use one of the following procedures based on the media you want to use for the installation, either **PXE** or **USB** installation.



Caution: The replacement procedure deletes any software installed in the host operating system of the PM and all PM configuration information entered before the replacement. After you complete this procedure, you must manually re-install all of your host-level software and reconfigure the PM to match your original settings.



Caution: To prevent data loss, if the system log indicates that manual intervention is necessary to assemble a disk mirror, contact your authorized Stratus service representative for assistance. You may lose valuable data if you force a resynchronization and overwrite the most recent disk in the mirror.

Prerequisite: To request a replacement ztC Edge node, log on to your **Stratus Customer Service Portal** account, expand **Customer Support**, and click **Add Issue**. When creating the issue, please have the following information ready:



- **Asset ID**—Locate the **Asset ID** for your system in the masthead of the ztC Edge Console window.
- **Diagnostic file**—Generate and download a diagnostic file on the **Support Logs** page of the ztC Edge Console, as described in [Creating a Diagnostic File](#). Attach the diagnostic file to the issue that you add in the portal.

A customer service representative will contact you to diagnose the issue and provide a replacement node, if necessary.

Prerequisite: The replacement node must be factory fresh, installed with Release 2.3.0.0 or higher, and the same model as the healthy/running node. If you need to use a spare node that is imaged with any release prior to Release 2.3.0.0, you must exchange it for a factory-imaged Release 2.3.x.x node to support pairing with any Release 2.3.x.x primary node. Contact your authorized Stratus service representative for assistance.



Prerequisites: If you want to use a USB medium to install the system software on the replacement PM:



- Create a bootable USB medium as described in [Creating a USB Medium with System Software](#).

When creating the USB medium, ensure that it contains the most recently installed upgrade kit. For example, if the release shown in the masthead of the ztC Edge Console window is version 1.2.0-550, where 550 is the build number, the kit you select to create the USB medium on the **Upgrade Kits** page must also be version 1.2.0-550. If the system detects a different build on the replacement PM, it automatically restarts the replacement process, initializes all data on the replacement PM, and uses PXE boot installation to reinstall the most recently installed software kit on the PM with no user interaction.

- Connect a keyboard and monitor to the replacement PM to monitor the installation process and specify settings.

**Note:**

You must re-activate the product license for the ztC Edge system after replacing a PM.

To remove and replace a failed PM (with PXE boot installation)

Use the following procedure to replace a failed PM and reinstall the system software by using PXE boot installation from the software kit on the primary PM.

1. In the ztC Edge Console, click **Physical Machines** in the left-hand navigation panel.
2. Select the appropriate PM (node0 or node1) and then click **Work On**, which changes the PM's **Overall State** to **Maintenance Mode** and the **Activity** state to **running (in Maintenance)**.
3. After the PM displays **running (in Maintenance)**, click **Recover**.
4. When prompted to select the type of repair, click **PXE PM Replace - Initialize All Disks**.



Caution: Selecting **PXE PM Replace - Initialize All Disks** deletes all data on the replacement PM.

5. Select one of the following PXE Settings:

- **Only respond to PXE requests from the current partner node.**

Waits for a PXE boot request from the MAC address of the current partner node.

Select this option if you are recovering the existing PM by completely wiping and reinstalling it. This process deletes all data on the PM, but restores its current network configuration.

- **Only respond to PXE requests from the following MAC address.**

Waits for a PXE boot request from the MAC address that you specify. Select this option if you are replacing the PM with a new PM. Enter the MAC address of the specific network adapter that will initiate PXE boot.

- **Accept PXE requests from any system on priv0.**

Waits for a PXE boot request from priv0, the private network that connects the two ztC Edge nodes. Select this option if you are replacing the PM with a new PM, but you do not know the MAC address for the new PM.

6. Click **Continue** to begin the replacement process. The system shuts down and powers off the PM.
7. After the PM is powered off, install the replacement PM, if applicable:
 - a. Disconnect and remove the old PM, and then install the replacement PM.
 - b. Reconnect the network cables to their original ports, and then reconnect power.
8. If the PM does not automatically power on, press the power button.
9. The replacement process continues with no user interaction, as follows:
 - The replacement PM begins to boot from a PXE server that temporarily runs on the primary node.
 - The system automatically deletes all of the data on disks in the replacement PM.
 - The replacement PM reboots again and automatically starts the system software installation, which runs from a copy of the installation kit on the primary node.

You do not need to monitor the progress of the software installation or respond to prompts at the physical console of the replacement PM. The replacement process is automated, and it is normal for the PM to display a blank screen for a long period of time during the software installation.

10. When the software installation is complete, the replacement PM reboots from the newly installed system software.



Note: After the system software installation, the replacement PM may take up to 20 minutes to join the system and appear in the ztC Edge Console.

11. As the replacement PM joins the system, you can view its activity on the **Physical Machines** page of the ztC Edge Console. The **Activity** column displays the PM as **(in Maintenance)** after the recovery is complete.
12. To activate the replacement PM, re-activate the product license for the ztC Edge system. On the **Preferences** page, click **Product License** and click **Check License Now** to automatically activate the license. If the system has no Internet access, activate the license as described in [Managing the Product License](#).



Note: The new PM cannot exit maintenance mode and run VMs until the ztC Edge license is re-activated.

13. If applicable, manually reinstall applications and any other host-level software, and reconfigure the replacement PM to match your original settings.
14. When you are ready to bring the replacement PM online, open the **Physical Machines** page and click **Finalize** to exit maintenance mode. Verify that both PMs return to the **running** state and that the PMs finish synchronizing. The initial synchronization may take minutes or hours depending on your configuration, including the amount of storage and the number of VMs.



Note: When the replacement PM exits maintenance mode, the system automatically disables the PXE server on the primary node that was used for the replacement process.

To remove and replace a failed PM (with USB installation)

Use the following procedure to replace a failed PM and reinstall the system software by using a USB medium.

1. In the ztC Edge Console, click **Physical Machines** in the left-hand navigation panel.
2. Select the appropriate PM (node0 or node1) and then click **Work On**, which changes the PM's **Overall State** to **Maintenance Mode** and the **Activity** state to **running (in Maintenance)**.
3. After the PM displays **running (in Maintenance)**, click **Recover**.
4. When prompted to select the type of repair, click **USB PM Replace - Initialize All Disks**.



Caution: Selecting **USB PM Replace - Initialize All Disks** deletes all data on the replacement PM.

5. Click **Continue** to begin the replacement process. The system shuts down the PM in preparation for the system software reinstallation.
6. After the PM is powered off, install the replacement PM, if applicable:
 - a. Disconnect and remove the old PM, and then install the replacement PM. Connect a monitor and keyboard.
 - b. Reconnect the network cables to their original ports.

- c. Connect the bootable USB medium to the replacement PM, and then reconnect the power cable. If the PM does not automatically power on, press the power button.
7. As the replacement PM powers on, enter the firmware (UEFI) setup utility. In the **Save & Exit** menu, under **Boot Override**, select the **UEFI** entry for the USB medium to boot from the device one time during the next boot sequence. The PM restarts.



Note: Use the **Boot Override** property to temporarily change the boot device instead of modifying the persistent **BOOT ORDER Priorities** in the **Boot** menu. The top boot priority must remain **UEFI Network** (default) to support the automated node replacement that is typically performed on ztC Edge systems.

8. Monitor the installation process at the physical console of the replacement PM.
9. At the **Welcome** screen, use the arrow keys to select the country keyboard map for the installation.
10. At the **Install or Recovery** screen, select **Replace PM, Join system: Initialize Data** and press **Enter**. The replacement process continues with no user interaction.



Caution: Selecting **Replace PM, Join system: Initialize data** deletes all data on the replacement PM.

11. When the software installation is complete, the replacement PM reboots from the newly installed system software.



Note: After the system software installation, the replacement PM may take up to 20 minutes to join the system and appear in the ztC Edge Console.

12. As the replacement PM joins the system, you can view its activity on the **Physical Machines** page of the ztC Edge Console. The **Activity** column displays the PM as **(in Maintenance)** after the recovery is complete.
13. To activate the replacement PM, re-activate the product license for the ztC Edge system. On the **Preferences** page, click **Product License** and click **Check License Now** to automatically activate the license. If the system has no Internet access, activate the license as described in [Managing the Product License](#).



Note: The new PM cannot exit maintenance mode and run VMs until the ztC Edge license is re-activated.

14. If applicable, manually reinstall applications and any other host-level software, and reconfigure the replacement PM to match your original settings.
15. When you are ready to bring the replacement PM online, open the **Physical Machines** page and click **Finalize** to exit maintenance mode. Verify that both PMs return to the **running** state and that the PMs finish synchronizing.

Related Topics

[Maintenance Mode](#)

[Maintaining Physical Machines](#)

[ztC Edge Console](#)

[Physical Machines and Virtual Machines](#)

[Physical Machines Page](#)

8

Chapter 8: Monitoring the System, Windows-based VMs, and Applications

On systems licensed for monitoring, you can monitor information about performance (for example, CPU usage). You can set low and high values to create a range of parameter values to be monitored. You can also set a **Call home** and/or **e-Alert/Trap** message to be sent when a parameter's value is outside of the configured range.

You can monitor information about the following:

- The host operating system of the ztC Edge system—See [Monitoring the ztC Edge System](#).
- The Windows operating system on Windows-based VMs—See [Monitoring Windows-based Virtual Machines](#).
- Applications running on Windows-based VMs—See [Monitoring Applications on Windows-based Virtual Machines](#).



Note: If the system is not licensed for monitoring, the **Monitor** tab contents are grayed out. Contact your account representative for information about enabling the functionality.

For information about monitoring a system with ztC Advisor, a secure web-based portal that provides centralized visibility of your entire fleet of ztC Edge systems, see [Enabling ztC Advisor](#).

Monitoring the ztC Edge System

Monitor the host operating system of the ztC Edge system for information about OS performance (for example, CPU usage). After you set a monitoring parameter, its value is updated every 30 seconds.

To set and view parameters for monitoring the host operating system

1. In the ztC Edge Console, click **Physical Machines** in the left-hand navigation panel.
2. In the lower panel, click the **Monitor** tab.

The **Monitor** tab displays monitoring information for each running node.

3. To enable monitoring of a parameter on each running node, activate the **Enabled** box in the leftmost column for that parameter.
4. Set the parameter values, if applicable:

Parameter—**CPU Usage** and **Memory Utilization**. Display value (not settable).

Units—Percentage (%); the maximum is 100%. Display value (not settable).

Range:

Low—The low threshold of the range. Its value can be 0 or any positive number. The value applies to both nodes.

High—The high threshold of the range. Its value can be 0 or any positive number. The value must be greater than the **Low** value. The value applies to both nodes.

By default, range values are empty. To enter a value, click the cell space in the **Low** or **High** column of the parameter row. After you click the space, a box appears for you to type a value.

CallHome—A call-home message is sent to your authorized Stratus service representative when a value outside of the range is detected on either node.

E-Alert/Trap—An email alert (e-Alert) and an SNMP trap are sent when a value outside of the range is detected on either node.

First Seen—Date and time when the parameter value was first detected in the last 24 hours on an individual node. Display value (not settable).

Last Seen—Date and time when the parameter value was last detected in the last 24 hours on an individual node. Display value (not settable).

Last Event—The last threshold violation on an individual node: **Low** or **High**. An empty cell indicates that a threshold violation has not occurred. Display value (not settable).

Incident Count—The number of times the range was exceeded in the last 24 hours on one node. Display value (not settable).

Current Value—Indicates one of the following (display value; not settable).

- Current value for one node.
- **Unavailable**=This value is temporarily unavailable.

Status—Status for the parameter on one node. Display value (not settable).

- Expected (✓)=The parameter has not exceeded its range in the last 24 hours.
- Warning (⚠)=The parameter has exceeded its range in the last 24 hours, but no occurrences are now elevated.
- Out of range (✗)=Currently out of range.

5. Click **Save** to save changes, or click **Reset** to cancel any unsaved changes.

Related Topics

[Monitoring the System, Windows-based VMs, and Applications](#)

[Configuring e-Alerts](#)

[Configuring SNMP Settings](#)

[Managing Physical Machines](#)

Monitoring Windows-based Virtual Machines

Monitor the operating system on Windows-based VMs for information about OS performance (for example, CPU usage). Monitoring is available on VMs running these operating systems:

- Windows 10 Professional
- Windows 10 Enterprise
- Windows Server 2012 R2 Standard
- Windows Server 2016 Standard
- Windows Server 2019 Standard

After you have created Windows-based VMs, you can view and set monitoring parameters on the **Monitor** tab of the **Virtual Machines** page. After you set a monitoring parameter, its value is updated every 60 seconds.

You first need to install the guest monitoring agent, if it is not already installed.

To install the guest monitoring agent

1. In the ztC Edge Console, click **Virtual CDs**.
2. Confirm that the **guest_monitoring_agent_***n.n.n.n* VCD is listed.
3. In the left panel, click **Virtual Machines**.
4. Under **Virtual Machines**, select the VM on to which you want to install the guest monitoring agent.
5. Insert the VCD. See [Inserting a Virtual CD](#).
6. Open a VM console session. See [Opening a Virtual Machine Console Session](#).
7. In the VM console session, open a file explorer window and navigate to the *Monitoring Agent Installation* CD.
8. Double-click on the CD to open the **Monitoring Agent Service Setup Wizard**, and in the wizard, click **Next**.

The wizard installs the agent. When installation is complete, click **Finish**.
9. When the installation is complete, eject the VCD from the VM. See [Ejecting a Virtual CD](#).

Notes:



1. When a VM is renamed, the monitoring parameters disappear, but reappear after a minute or two.
2. You need to ensure that Performance Counters are enabled and functioning in the guest operating system in order for the Guest Monitoring Agent to obtain processor, memory, and disk usage information.

To set and view parameters for monitoring a VM

1. In the ztC Edge Console, click **Virtual Machines** in the left-hand navigation panel.
2. Select the appropriate VM.
3. In the lower panel, click the **Monitor** tab.

Under **Guest OS**, the tab displays parameters that you can view and set.

4. To enable monitoring of a parameter, activate the **Enabled** box in the left-most column.
5. Set the parameter values, if applicable:

Parameter—CPU Usage , **Used Disk Space**, and **Memory Utilization**. Display value (not settable).

Units—Percentage (%). Display value (not settable).

Range:

Low—The low threshold of the range. The value must be a positive integer between 0 and 100 (for 100%).

High—The high threshold of the range. The value must be a positive integer between 0 and 100 (for 100%), and the value must be greater than the **Low** value.

By default, range values are empty. To enter a value, click the cell space in the **Low** or **High** column of the parameter row. After you click the space, a box appears for you to type a value.

CallHome—A call-home message is sent to your authorized Stratus service representative when a value outside of the range is detected.

E-Alert/Trap—An email alert (e-Alert) and an SNMP trap are sent when a value outside of the range is detected.

First Seen—Date and time when the parameter value was first detected in the last 24 hours. Display value (not settable).

Last Seen—Date and time when the parameter value was last detected in the last 24 hours. Display value (not settable).

Last Event—The last threshold violation on an individual node: **Low** or **High**. An empty cell indicates that a threshold violation has not occurred. Display value (not settable).

Incident Count—The number of times the range was exceeded in the last 24 hours. Display value (not settable).

Current Value—Indicates one of the following (display value; not settable):

- Current value.
- **Not Responding**—The Guest Monitoring Agent is not responding on this VM because the agent is either not installed or is stopped. To monitor the guest, you must manually install or restart the Guest Monitoring Agent on this VM.
- **Not Running**—The guest is not in the running state.
- **Unavailable**—This value is temporarily unavailable.

Status—Display value (not settable).

- Expected (✓)=The parameter has not exceeded its range in the last 24 hours.
- Warning (⚠)=The parameter has exceeded its range in the last 24 hours, but no occurrences are now elevated.
- Out of range (✗)=Currently out of range.

6. Click **Save** to save changes, or click **Reset** to cancel any unsaved changes.

Related Topics

[Monitoring the System, Windows-based VMs, and Applications](#)

[Configuring e-Alerts](#)

[Configuring SNMP Settings](#)

[Configuring Windows-based Virtual Machines](#)

Monitoring Applications on Windows-based Virtual Machines

Monitor applications running on Windows-based VMs for information about application performance (for example, CPU usage).

After you have created Windows-based VMs, you can add applications on the **Monitor** tab of the **Virtual Machines** page, and then view and set monitoring parameters. After you set a monitoring parameter, its value is updated every 60 seconds.



Note: When a VM is renamed, the monitoring parameters disappear, but reappear after a minute or two.

To add or view application parameters for monitoring, or to remove a parameter, you need to know the name of the application's executable file (without the extension, as in, for example, mysqld). Obtain the name from a Windows utility. For example, in **Task Manager**, obtain the appropriate name from the list of names on the **Processes** tab.

To add, set, or view an application and its parameter

1. In the ztC Edge Console, click **Virtual Machines** in the left-hand navigation panel.
2. Select the VM that is running the application you are interested in.
3. In the lower panel, click the **Monitor** tab.

The **Applications** panel appears beneath the **Guest OS** panel. Applications are listed in the **Application** column with associated parameters. Beneath the list are add and remove buttons, which allow you to add applications and parameters to the list, or to remove them.

4. Add an application and parameter, if applicable:

- a. Click the  **Add** button.

Two boxes appear, with the active cursor in the first (left) box.

- b. Type the name of the application's executable file (without the extension, as in, for example, mysqld) in the first box or select a name from the drop-down list.
- c. Select the parameter that you want to monitor from the drop-down list of the second (right) box.
- d. Click **Save** to save the changes (or click **Reset** to cancel any unsaved changes). After you save changes, the new application appears in the list under **Applications**.

The new application appears after a short delay.

5. To enable monitoring of an application and parameter, activate the **Enabled** box in the leftmost column.
6. Set the parameter values, if applicable:

Application—Applications that are running on the VM and have been selected for monitoring.

Parameter—**CPU Usage** and **Memory Utilization**. Display value (not settable).

Units—Percentage (%). Display value (not settable).

Range:

Low—The low threshold of the range. The value must be a positive integer between 0 and 100 (for 100%).

High—The high threshold of the range. The value must be a positive integer between 0 and 100 (for 100%), and the value must be greater than the **Low** value.

By default, range values are empty. To enter a value, click the cell space in the **Low** or **High** column of the parameter row. After you click the space, a box appears for you to type a value.

CallHome—A call-home message is sent to your authorized Stratus service representative when a value outside of the range is detected.

E-Alert/Trap—An email alert (e-Alert) and an SNMP trap are sent when a value outside of the range is detected.

First Seen—Date and time when the parameter value was first detected in the last 24 hours. Display value (not settable).

Last Seen—Date and time when the parameter value was last detected in the last 24 hours. Display value (not settable).

Last Event—The last threshold violation on an individual node: **Low** or **High**. An empty cell indicates that a threshold violation has not occurred. Display value (not settable).

Incident Count—The number of times the range was exceeded in the last 24 hours. Display value (not settable).

Current Value—Indicates one of the following (display value; not settable):


- Current value.
- **Not Responding**—The Guest Monitoring Agent is not responding on this VM because the agent is either not installed or is stopped. To monitor applications on the guest, you must manually install or restart the Guest Monitoring Agent on this VM.
- **Not Running**—The guest is not in the running state.
- **Not Found**—The application is not found or is not running on the guest.
- **Unavailable**—This value is temporarily unavailable.

Status—Display value (not settable).

- Expected (✓)=The parameter has not exceeded its range in the last 24 hours.
- Warning (⚠)=The parameter has exceeded its range in the last 24 hours, but no occurrences are now elevated.
- Out of range (✗)=Currently out of range.

7. Click **Save** to save changes, or click **Reset** to cancel any unsaved changes. After a short delay, new values entered (if any) appear.

To remove a parameter

1. In the ztC Edge Console, click **Virtual Machines** in the left-hand navigation panel.
2. Select the VM that is running the application whose parameter you want to remove.
3. In the lower panel, click the **Monitor** tab. The **Applications** panel appears beneath the **Guest OS** panel.
4. Select an application/parameter row.
5. Click the  **Remove** button.

The application/parameter row disappears from the list of applications.

6. Click **Save** to save the changes (or click **Reset** to cancel any unsaved changes). After a short delay, the application/parameter row disappears (again) from the list of applications.

Related Topics

[Monitoring the System, Windows-based VMs, and Applications](#)

[Configuring e-Alerts](#)

[Configuring SNMP Settings](#)

[Installing Applications \(Windows-based VMs\)](#)

[Configuring Windows-based Virtual Machines](#)

Part 2: Supporting Documents

See the following support documents for release information, and reference and troubleshooting information.

- [Stratus Redundant Linux Release 2.3.0.0 Release Notes](#)
- [System Reference Information](#)
- [Security](#)
- [SNMP](#)

9

Chapter 9: Stratus Redundant Linux Release 2.3.0.0 Release Notes

These Release Notes (updated at 11:29 AM on 10/7/2024) are for Stratus Redundant Linux Release 2.3.0.0, which runs on ztC Edge systems. See the following sections:

- [New Features and Enhancements](#)
- [Bug Fixes](#)
- [CVE Fixes](#)
- [Important Considerations](#)
- [Known Issues](#)
- [Accessing Stratus Knowledge Base Articles](#)
- [Getting Help](#)

New Features and Enhancements

New in Stratus Redundant Linux Release 2.3.0.0

The following features are new in Stratus Redundant Linux Release 2.3.0.0:

- ztC Edge 200i and 250i systems
- [Deployment enhancements](#)
- Virtual Machines—Support for RHEL 7.9, RHEL 8.2, CentOS 7.9, and Debian 10.9 guest operating systems (full list in [Tested Guest Operating Systems](#)).
- Security improvements—337 [Fixed CVEs](#).

- VirtIO drivers installed as a VCD on the system during the initial system installation and upgrades.
- Traditional Chinese language support for the ztC Edge Console user interface.

New in Stratus Redundant Linux Release 2.2.0.0

For information, see [New in Stratus Redundant Linux Release 2.2.0.0](#).

New in Stratus Redundant Linux Release 2.1.0.0

For information, see [New in Stratus Redundant Linux Release 2.1.0.0](#).

Bug Fixes

Bugs Fixed in Stratus Redundant Linux Release 2.3.0.0

ZTC-9370: Display of PM Details data on the Systems page at sites in time zones with daylight saving time (DST) is incomplete.

ZTC-8354: Correct the check for Virtual Technology (VT) being supported and enabled.

ZTC-8097: Add the ability to clear the Service Expired clock on the masthead.

ZTC-7532: Live Dump Status line on VM Summary tab should not be present when activity timeout occurs.

ZTC-5945: Correct the platform variant implementation to properly identify all ztC hardware such that SNMP OIDs and values are correct for all ztC platforms.

ZTC-5872: Loss of internet connectivity during an upgrade kit download can prevent future upgrade kit downloads.

ZTC-5824: The Check For Updates function will now cleanly exit if the system is not connected to the internet.

ZTC-5667: VM statistics on System page can fail to be displayed after VM migrates back to rebooted node.

ZTC-5218: Update VirtIO drivers to virtio-win-0.1.171-1.

ZTC-4514: Node fails to go into Maintenance if business network cable that is used by VMs is pulled on peer node.

ZTC-4461: Importing a VM may result in an invalid disk image when it is larger than 145GB.

ZTC-4458: The upgrade kit Qualify function has been enhanced to identify broken networks and when appropriate to fail the qualification.

ZTC-3888: GRUB2 has been updated to address CVE-2020-10713.

ZTC-3590: It is no longer necessary to mirror the root, swap, and diagdata partitions to a second logical disk in the Initial Storage group.

ZTC-3007: The VirtIO driver VCD is now created on install and upgrade.

ZTC-459: Automatic rolling unit reboot is not possible if any unused business network has a fault on it.

Bugs Fixed in Stratus Redundant Linux Release 2.2.0.0

For information, see [Bug Fixes in Stratus Redundant Linux Release 2.2.0.0](#).

Bugs Fixed in Stratus Redundant Linux Release 2.1.0.0

For information, see [Bug Fixes in Stratus Redundant Linux Release 2.1.0.0](#).

CVE Fixes

For a list of the CVE fixes, see [Fixed CVEs](#).

Important Considerations

Upgrading to Release 2.3.0.0

To upgrade to Stratus Redundant Linux Release 2.3.0.0, follow the upgrade path for the release that is running on your system:

- Releases 2.2.0.0, 2.1.0.0, 2.0.1.0, and 2.0.0.0—Upgrade directly to Release 2.3.0.0 following instructions in [Upgrading Stratus Redundant Linux Software Using an Upgrade Kit](#).
- Releases earlier than Release 2.0.0.0—Upgrade to Release 2.0.1.0, and then upgrade to Release 2.3.0.0. For information on upgrading to Release 2.0.1.0, see the [Release 2.0.1.0 Release Notes and Help](#).

Determining the Version of System Software

To determine the version of Stratus Redundant Linux running on a ztC Edge system, log on to the ztC Edge Console for the system and check the system information in the masthead:

```
ocean.abc.com
IP: 123.109.50.34 | Asset ID: ze-12345
Version: n.n.n-nnn | Alias Name: ze-12345
```

Alternatively, you can click **Software Updates** on the **Preferences** page, which also displays the current version number of the Stratus Redundant Linux software on your system.

If the software release is lower than Release 2.3.0.0, download the Stratus Redundant Linux 2.3.0.0 Upgrade Kit from the **Downloads** page at <https://www.stratus.com/services-support/downloads/?tab=ztcedge> and upgrade the software on the system as described in [Upgrading Stratus Redundant Linux Software Using an Upgrade Kit](#).

During Upgrade, Refresh Browser and Accept New Certificate

During a Stratus Redundant Linux software upgrade, the browser may display a stale status after the first node has been upgraded and become the new primary node. This incorrect browser display status can occur if the browser has a new certificate from Stratus that needs to be accepted. You should refresh the browser and, if prompted, accept the new certificate. After you have accepted the new certificate, the browser displays the correct status of the upgrade.

SNMP Disabled by Default on ztC Edge Systems

SNMP is disabled by default on ztC Edge systems. Starting with Stratus Redundant Linux Release 2.3.0.0 or higher, the SNMP process is also stopped in the console operating system on each node. For security reasons, if you need to enable SNMP, you should disable SNMP v1 and v2, and enable only version 3 by using the SNMP **Restricted** configuration. For details, see [Configuring SNMP Settings](#) and [Security Hardening](#), as well as [KB0015428](#).


ztC Edge Deployment Enhancements

With Release 2.3.0.0 or higher, ztC Edge has been enhanced to provide greater flexibility in node deployment and inventory management. You can now deploy any factory-fresh node installed with Release 2.3.0.0 or higher as a single-node system, as the second node in a dual-node system, or as a replacement node.


For the updated procedures, see [Deploying the System](#), [Adding a Node to a Single-Node System](#), and [Replacing Physical Machines \(Automated\)](#).

Power Connections on ztC Edge200i and 250i Nodes

If you install a ztC Edge200i or 250i system in an environment that provides DC power, you need to supply a power source at 9 to 36 VDC and a power cord with the correct wiring for each node. The following diagram shows the pin assignments for the DC input power connector on each 200i or 250i node.



If you are connecting a node to a site DC power supply with user-supplied materials, fasten four separate wires (two positive (+) and two negative (-) wires) from the DC power supply to the power connector terminals. The wires must be a minimum of 18 AWG with a maximum length of 5 ft (1.5m). If the wire length is more than 5 ft (1.5m), increase the wire gauge for a maximum voltage drop of 1 V at 6.5 A. For best results, also terminate each wire with a ferrule sized and crimped as specified by the ferrule manufacturer. The following diagram illustrates the recommended AC power adapter and site DC power connections.



For additional system specifications, see [System Specifications](#).

Audio Ports Are Not Supported

The audio ports on ztC Edge systems are inactive and not supported. For additional system specifications, see [System Specifications](#).

Using Intel Active Management Technology (AMT) for Lights-Out Support

ztC Edge systems incorporate Intel Active Management Technology (AMT) lights-out support for remote power management, remote console, and remote media. For important information about AMT configuration and restrictions, see [KB0014200](#).

Deploying ztC Edge Nodes at Separate Physical Sites

When you deploy a ztC Edge system in a redundant, dual-node configuration, you must deploy both nodes at the same site and directly connect the A-links between the blue (A2) and yellow (A1) network ports of each node. If you want to set up a ztC Edge system in an automated local site recovery (ALSR) configuration, where each node is located at a separate physical site for increased redundancy, contact your authorized Stratus service representative for assistance. Because of the geographic separation, an ALSR configuration requires careful planning of component placement and networking topologies.

Enabling ztC Advisor

Stratus Redundant Linux Release 2.2.0.0 or higher introduces support for ztC Advisor, a secure web-based portal that provides centralized visibility of your entire fleet of ztC Edge systems. Through an intuitive, user-friendly dashboard, you can assess at a glance, the health, resource usage, and software version of each system.

For information about registering for and using ztC Advisor, see the following web page:

<https://www.stratus.com/solutions/ztc-advisor>. To enable or disable ztC Advisor for a system, see [Enabling ztC Advisor](#).

Tested Guest Operating Systems

For a list of the guest operating systems tested with the current release, see [Tested Guest Operating Systems](#). For information on guest operating systems tested or supported in previous releases, go to <http://ztcedgedoc.stratus.com>, select the appropriate release, and then search for the guest operating system.

Maximum vCPU Limits for a Virtual Machine

The Stratus Redundant Linux software has a maximum limit of 8 vCPUs per VM in Fault Tolerant (FT) mode and 20 vCPUs per VM in High Availability (HA) mode. If you create a VM that exceeds these maximums, you could cause performance issues on all running VMs. For more information about VM limits, see [Virtual Machine Recommendations and Limits](#).

Known Issues

Increasing MTU on the P1 interface Can Cause Disruption or Halt of Network Traffic

On ztC Edge systems, if you increase the maximum transmission unit (MTU) of the P1 (*ibiz0*) network interface from its default of 1500 to 9000 as described in [Setting the MTU](#), the network connection might go down and up randomly followed by a complete halt of network traffic over the P1 interface.

This issue affects all access to the node management IP address. On a single-node ztC Edge system, you also lose access to the system IP address, the ztC Edge Console, and any VM that depends on the P1 interface for its network connection.

For more information about this issue, see [KB0015385](#).

After Upgrading to a Dual-Node System, VMs Display Warning Icon

When you upgrade a single-node system to a dual-node system, the VMs remain running, but the Dashboard displays the VM state with a warning icon (⚠️). The warning indicates that the VMs are running with only one or no A-Links because, during the upgrade, the system does not add A-Link1. If you encounter this problem, stop and restart the VMs after the upgrade.

Removable Media and Migrating a PM or VM Using the P2V Client

Before migrating a PM or VM using a bootable P2V client (**virt-p2v**) ISO file, check if any removable media (for example, floppy disks, DVD drives, or external USB disks) are attached to the source image. If removable media are attached to the source image when you attempt to migrate a PM or VM to the ztC Edge system, the error message **Conversion failed** appears. To prevent this issue, deselect the media in the **virt-p2v** window before starting the migration. To do so, access the **virt-p2v** window with the sections **Target properties** and **Fixed hard disks**, and then beneath **Fixed hard disks**, uncheck the box in the **Convert** column next to the removable media. See [Migrating a Physical Machine or Virtual Machine to a System](#), particularly the section **To migrate a PM or VM to the ztC Edge system**, for more information on using **virt-p2v**.

"The VM *name* has failed to start" Alert While Running the P2V Client Is Normal

While using the P2V client to migrate a VM from an everRun or ztC Edge system, it is normal if the source system displays the alert "The VM *name* has failed to start" during the migration process, because although the source VM is powered on and running the P2V client, the guest operating system does not start.

Maximum Path Length When Importing a VM

When you import a VM using the **Import/Restore Virtual Machine** wizard, the maximum length of the path to the VM, including the VM name, is 4096 characters for the import options **Import from remote/network Windows Share(CIFS/SMB)** and **Import from remote/network NFS**.

Cannot Import RHEL 8.x VMs

You cannot import a VM running RHEL 8.x (with BIOS boot firmware) from a VMware ESXi 6.7.0 server to a ztC Edge system.

Maximum Resolution of a UEFI VM Console Session

On the **Virtual Machines** page of the ztC Edge Console, you can open a VM console session to display the console of the guest operating system running in the VM. When you open a console session to access a guest VM with a UEFI boot type, the console session has a maximum resolution of 800x600. For a higher resolution, connect to the VM using a Remote Desktop Connection.

Restart VMs for `vmgenid` Support

After a system is upgraded from Release 2.0.1.0 or earlier to Stratus Redundant Linux Release 2.2.0.0 or higher using an upgrade kit, support for `vmgenid` on VMs running Windows Server 2019, Windows Server 2016, or Windows Server 2012 is not present until after the VMs are restarted. Therefore, you must restart such VMs to enable `vmgenid` support after the upgrade. If you are upgrading from Release 2.1.0.0, you do not need to restart such VMs if they had previously been restarted on the system running Release 2.1.0.0.

Creating VCD Fails With Microsoft Edge Console Browser

When you are using Microsoft Edge as the browser for the ztC Edge Console you cannot create a VCD: the process will fail. Instead, use another compatible browser (see [Compatible Internet Browsers](#)).

In a Single-Node System, VM Creation Wizard Display of Added vCPUs Is Incorrect

When you create a VM on a system configured for one node, the **VM Creation Wizard** displays that it is adding two vCPUs to the number vCPUs you specify. However, once the VM is created, the user-specified number of vCPUs is attached to the VM. The additional two (incorrectly displayed) vCPUs are not added.

Mapping of Japanese Keyboards 106 and 109 For Console in IE10, IE11, or Firefox May Be Incorrect

The mapping of the Japanese keyboards 106 and 109 may be incorrect when using IE10, IE11, or Firefox to access the ztC Edge Console. Use Chrome or remote connection software (VNC or RDP), instead.

Cannot Enable SNMP Requests Without Traps

If you create an SNMP request in the ztC Edge Console, you must also create a trap; otherwise, the ztC Edge Console displays the error "Problem encountered updating SNMP. Make sure your settings are correct. Error: Configure SNMP failed." As a workaround, when creating a new SNMP request, click **Enable SNMP Requests** and **Enable SNMP traps**, do not define a Version 3 user, keep the default of **Restricted** requests, and specify at least one trap recipient. Adding a Version 3 user or clicking **Unrestricted** during the initial configuration might cause the configuration to fail. After the initial configuration is complete, you can then modify it to specify any settings that you require.

Migrating a VM With Monitoring Set Causes "No response"

When monitoring on a VM is set for all three parameters (CPU, Memory, and Disk), and the VM is migrated to the other node, the **Monitor** tab displays **No response from guest agent**. It may take several minutes for the guest agent to reconnect.

VMs Reported as Broken Instead of Degraded When A-Link Is Offline

If an A-link cable or network is disconnected on one node, the state of a VM on that node may be reported as broken (✖) in the ztC Edge Console, even though the VM still has another active A-link connection. The availability of the VM is unaffected.

Ejected VCD Still Displayed in a Linux-based VM Console

If you use the ztC Edge Console to eject a VCD from a VM running a Linux-based guest operating system, the VCD may still be displayed in the guest operating system. If needed, you can eject the VCD in the guest operating system to stop displaying the VCD.

Some Browsers Unable to Connect a VNC When Using https

If you are connected to the ztC Edge Console using an **https** URL in a Microsoft Internet Explorer or Mozilla[®] Firefox[®] browser, and you click **Console** after selecting a running VM from the **Virtual Machines** page, the message **VNC: Unable to connect, retrying in *n* seconds** may appear. To enable the VNC connection, click the https link to the VNC console page in the upper right-hand corner of the masthead,

and continue with the appropriate procedure below (procedure in your browser may differ, depending on the version of your browser):

- In Internet Explorer, the **Security Alert** wizard appears:
 - a. Click **Continue to this website (not recommended)**.
 - b. Click **OK**.
- In FireFox, the **Your connection is not secure** window appears:
 - a. Click **Advanced**. A message about an invalid security certificate appears.
 - b. Click **Add Exception**. The **Add Security Exception** dialog box appears with the console's location in **Location**.
 - c. Click **Confirm Security Exception**.

The VNC console appears.

Reboot Required When Changing Node IP Address or Netmask Network Settings

When you change the IP address or netmask settings of a node as described in [Configuring IP Settings](#), both the old and new settings are in effect until you reboot the node. Having both settings active may cause routing or connection issues.

Accessing Stratus Knowledge Base Articles

The **Stratus Customer Service Portal** provides a searchable **Knowledge Base** with technical articles about all Stratus products, including ztC Edge. In some cases, the online Help directly references these Knowledge Base articles (for example, KBnnnnnnn). You can access the **Stratus Customer Service Portal** and its Knowledge Base by using your existing portal credentials, or by creating a new user account, as follows.

To access the Knowledge Base

1. Log on to the **Stratus Customer Service Portal** at <https://service.stratus.com>.

If needed, create a new account as follows:

- a. Click **Register**.
- b. Enter your contact information including your company email address and registration code, and then click **Submit**.

Your company email address must include a domain name (for example, stratus.com) for a company that is a registered customer of Stratus. The portal sends an email to administrators of the company's account to approve the request.

- c. Upon approval, click the link in the email that you receive from Stratus.
- d. Enter a new password and finish configuring your account.

If you need assistance creating an account, contact your authorized Stratus service representative.

2. In the portal, do one of the following:

- In the **Search** box, enter keywords or the KB article number (KBnnnnnnnn) associated with the information you need, and then click the search button.
- Click **Knowledge**, click the name of a product, and then browse available articles.

Getting Help

If you have a technical question about ztC Edge systems, you can find the latest technical information and online documentation at the **Downloads** page at <https://www.stratus.com/services-support/downloads/?tab=ztcedge>. You can also search the **Knowledge Base** in the **Stratus Customer Service Portal** at <https://service.stratus.com>.

If you cannot resolve your questions with these online resources, and the system is covered by a service agreement, contact your authorized Stratus service representative. For information, see the **ztC Edge Support** page at <https://www.stratus.com/services-support/customer-support/?tab=ztcedge>.

10

Chapter 10: System Reference Information

See the following topics for reference information

- [Tested Guest Operating Systems](#)
- [Important Physical Machine and Virtual Machine Considerations](#)
- [Accessing Knowledge Base Articles](#)
- [Creating an ALSR Configuration](#)
- [Fixed CVEs](#)
- [REST API](#)

Tested Guest Operating Systems

The following table lists the guest operating systems for virtual machines (VMs) that Stratus has tested on the current release of Stratus Redundant Linux software. Guest operating systems not listed have not been tested by Stratus and must be tested locally.



Note: For the latest information about guest operating systems that have been tested with the Stratus Redundant Linux software, see the ztC Edge Supported Guest Operating Systems web site at <https://www.stratus.com/services-support/customer-support/platform-support/ztc-edge-guest-operating-system-support/>.

Operating System	Version(s)	Boot Firmware Interface
CentOS 7	7.5, 7.6, 7.7, 7.8, 7.9 (all 64-bit)	BIOS
CentOS 6	6.9, 6.10 (both 64-bit)	BIOS
Debian 10	10.9.0-i386	BIOS
Microsoft Windows Server 2019 (Standard, Data-center)	64-bit	BIOS UEFI ¹
Microsoft Windows Server 2016 (Standard, Data-center)	64-bit	BIOS UEFI ²
Microsoft Windows Server 2012 (Standard, Data-center)	64-bit R2	BIOS
Microsoft Windows 10 Desktop	64-bit	BIOS
Red Hat Enterprise Linux 8 (Workstation, Server)	8.1, 8.2 (both 64-bit)	BIOS
Red Hat Enterprise Linux 7 (Workstation, Server)	7.5, 7.6, 7.7, 7.8, 7.9 (all 64-bit)	BIOS
Red Hat Enterprise Linux 6 (Workstation, Server)	6.10 (64-bit)	BIOS
SUSE Linux Enterprise Server (SLES)	12 SP2 64-bit	BIOS
Ubuntu Server	18.042 LTS (64-bit)	BIOS

¹You can import a VMware VM that has a UEFI boot firmware interface and that is running Windows Server 2019 to a system running Stratus Redundant Linux Release 2.3.0.0 (or later) only if the VM was exported from a VMware server that is running vSphere Release 6.7.

²You can import a VMware VM that has a UEFI boot firmware interface and that is running Windows Server 2016 to a system running Stratus Redundant Linux Release 2.3.0.0 (or later) only if the VM was exported from a VMware server that is running vSphere Release 6.7.

Important Physical Machine and Virtual Machine Considerations

For optimal implementation of physical machines and virtual machines, be aware of the configuration maximums and requirements described in the following sections:

- [Virtual Machine Recommendations and Limits](#)
- [Important Considerations](#)

Virtual Machine Recommendations and Limits

Virtual machines (VMs) require certain [CPU core resources](#). In addition, only some models of dual-node systems allow both High Availability (HA) and Fault Tolerant (FT) operation, while others allow only HA operation. Single-node systems do not allow HA or FT operation.

Systems and HA or FT Operation

System Model	HA Operation	FT Operation
100i	Yes	No
110i	Yes	Yes
200i	Yes	No
250i	Yes	Yes

For more information, see [Modes of Operation](#).

Recommended Number of CPU Cores

Stratus recommends using only as many threads for workloads as physical threads on a ztC Edge system. The number of threads per system are as follows:

ztC Edge System Model	Total Number of Physical Threads
100i	8
110i	12

ztC Edge System Model	Total Number of Physical Threads
200i	12
250i	20

The number of cores recommended for ztC Edge workloads depends upon the number of vCPUs in each VM and the types of the VMs, as described below:

Examples

The following examples apply to dual-node ztC Edge 100i and 200i systems:

- Four 2-vCPU HA guests typically require 8 threads, total.
- Two 3-vCPU HA guests and one 2-vCPU HA guest typically require 8 threads, total.
- Two 4-vCPU HA guests typically require 8 threads, total.
- One 8-vCPU HA guest typically requires 8 threads, total.

The following examples apply to dual-node ztC Edge 110i systems and 250i systems, in addition to the examples above:

- One 4-vCPU FT guest typically requires 6 threads, total.
- Six 2-vCPU HA guests typically require 12 threads, total.
- One 2-vCPU FT guest requires 4 threads and two 2-vCPU HA guests require 4 threads, for 8 threads, total.

On a single-node system, each vCPU counts as one thread. The following examples apply to single-node ztC Edge 100i and 200i systems:

- Four 2-vCPU guests typically require 8 threads, total.
- Two 3-vCPU guests and one 2-vCPU guest typically require 8 threads, total.
- Two 4-vCPU guests typically require 8 threads, total.
- One 8-vCPU guest typically requires 8 threads, total.

The following example applies to single-node ztC Edge 110i systems and 250i systems, in addition to the examples above: six 2-vCPU guests typically require 12 threads, total.

Important Considerations

Note the following important considerations.

Feature	Comment
USB Devices	USB keyboards, CD/DVD drives, disk drives, and thumb drives are supported for importing/exporting VMs and for system restoration.
Console Connectivity	Each PM's text console is available for the host operating system. However, VGA mode is not supported; that is, the PM must be at run-level 3 and cannot run at run-level 5. See "System Management" below.
System Management	ztC Edge system management does not work at run-level 5.
Volumes	For exporting, importing, or restoring a volume, the maximum volume size is 2TB.

Creating an ALSR Configuration

This topic and its subtopics describe how to create an automated local site recovery (ALSR) configuration.

For general information about quorum servers, see [Quorum Servers](#) as well as [ALSR and Quorum Service](#).



Note: Before you create an ALSR configuration, read this topic and all of its subtopics and then plan your ALSR configuration, as described in the topics. Create the configuration only after you are certain that your planned configuration complies with the information in this topic and its subtopics.

An ALSR configuration exists if either of the following is true:

- The two nodes of a dual-node system are connected using network infrastructure rather than direct cables.
- The length of the A-Link (direct connect) cables connecting the two nodes is greater than 10m (for example, in two separate buildings within a campus).

These configurations provide better disaster tolerance and hardware redundancy as well as redundancy of physical computer rooms and the buildings containing them.

Stratus recommends that an ALSR configuration include a third computer, which is a quorum server. The quorum server is located in a physical location that is removed from the physical location of both node0 and node1.



Note: This topic and its subtopics describe an ALSR configuration with a quorum server. Stratus highly recommends that an ALSR configuration include a quorum server. If you want to consider creating an ALSR configuration without a quorum server, access the Knowledge Base to search for the article *Considerations if deploying ALSR without quorum* ([KB0014557](#)), and also contact your authorized Stratus service representative. For information about accessing Knowledge Base articles, see [Accessing Knowledge Base Articles](#).

Because of the geographic separation of these physical machines, creating an ALSR configuration requires careful planning of component placement and more complex networking topologies.

The topics below describe how to create a ALSR configuration. To perform the procedures in the topics, you should be familiar with ztC Edge software and the hardware it runs on, and you should be familiar with the network infrastructure of your system and its location.



Note: These topics cannot describe every vendor and model of network switches, routers, and other hardware. Consult the documentation that pertains to your infrastructure if you need more information about how to configure it according to the requirements in these Help topics.

- [Creating the Configuration](#)
- [Meeting Network Requirements](#)
- [Locating and Creating the Quorum Server](#)
- [Completing the Configuration](#)
- [Understanding Quorum's Effect on System Behavior](#)

The following table lists and defines terms associated with creating an ALSR configuration.

Term	Meaning
Active node	The node where a guest VM is currently running. Each guest VM may have a different active node. The opposite of <i>active</i> is standby (see Standby node).

A-Link	Availability link. A direct network connection between the two computers that form a ztC Edge system. (The computers of a system are also referred to as <i>physical machines</i> (PMs) or <i>nodes</i> .) A-Links must be connected point-to-point, and A-Link traffic cannot be routed. A ztC Edge system requires two A-Links. On some systems, these connections have blue and yellow cables (and ports). You can use VLAN connections for A-Links in a distributed local site deployment (see VLAN).
Alternate quorum server	The alternate quorum server is used when the preferred quorum server is not available (see Preferred quorum server).
Automated local site recovery (ALSR)	<p>An ALSR configuration exists if either of the following is true:</p> <ul style="list-style-type: none"> • The two nodes of the ztC Edge system are connected using network infrastructure rather than direct cables. • The length of the A-Link (direct connect) cables connecting the two nodes is greater than 10m (for example, in two separate buildings within a campus). <p>An ALSR configuration is typically used to provide better disaster tolerance, at the expense of more network setup and more extensive configuration options. An ALSR configuration requires a third computer, which is a quorum server (see Quorum server).</p>
AX	The container layer that resides within the ztC Edge system and controls the behavior of the guest VM. AX is responsible for keeping a VM synchronized between the active node and the standby node. Each VM has its own AX pair (see VM , Active node , and Standby node).
Business network (ibiz)	A network connection from the ztC Edge system to a LAN that also has other traffic that can include management messages as well as traffic for applications and other clients and servers. The ztC Edge system typically has two ports for business network connections. Business networks can be assigned to one or more guest VMs for their use, or to no guest VMs. You must connect the first business network (ibiz0) to a LAN so that you

	can manage the system from a web browser.
Fault	Any potential degradation in a system's ability to execute a guest VM (see VM). Disk failure, network loss, or power outage are all examples of faults detected by the system.
Node0 and node1	The two computers that form the ztC Edge system are labeled internally as node0 and node1. (These computers are also sometimes referred to as physical machines or PMs.) The choice of node0 and node1 is arbitrary and is made when the system is configured for the first time. Constant traffic flowing between node0 and node1 communicates state information for the system as well as for each running guest VM (see VM).
Preferred quorum server	The preferred quorum server is used when it (the preferred quorum server) is available. If the preferred quorum server is not available, the alternate quorum server (if it exists) is used (see Alternate quorum server).
Primary node	When the system's computers are paired, only one computer responds to management messages. This computer is the primary node. The System IP address, which is assigned when the system is initially deployed, applies to the primary node. The primary node can switch between node0 and node1 as different fault conditions occur (see Fault). Note that the primary node is not necessarily the active node for a guest VM (see Active node and VM).
priv0	A network for private management traffic between the two nodes. For more information, see A-Link and Private Networks .
Quorum server	A third computer that helps arbitrate which AX should be active for each guest VM (see Active node and VM). Correct use of a quorum server is the only guaranteed way to prevent split-brain conditions (see Split-brain).


RTT	Round-trip time. The elapsed time required for a network message to travel from a starting point to a destination and back again. The time is typically measured in milliseconds (ms).
Split-brain	The condition that occurs when both AX's of a guest VM's AX pair are active simultaneously, which produces divergent copies of data within each active guest (see AX and VM). Split-brain can occur when all communication paths between node0 and node1 are disconnected (see Node0 and node1). Using the quorum service prevents a split-brain condition (see Quorum server).
Standby node	The node that is not the active node for a guest VM. The standby node is kept synchronized through AX communications via A-Link connections (see AX and A-Link). The AX pair for each guest VM determines which node is active and which is standby (see Active node).
System management	System management is the layer within Stratus Redundant Linux software that is responsible for maintaining the overall state of the system. Determining which node is primary is part of system management (see Primary node). System management is also responsible for displaying information within the ztC Edge Console.
UPS	Uninterruptable power supply. An external battery backup for electrical equipment that prevents short power outages from affecting availability.
VLAN	Virtual LAN. A VLAN is a set of devices on one or more LANs that are configured to communicate as if they were attached to the same cabled network, when in fact they are located on different LAN segments. VLANs are configured at the network infrastructure level, not within the ztC Edge system. In an Automated local site recovery (ALSR) configuration, the A-Link connections are implemented as isolated VLANs (see A-Link).
VM	Virtual Machine (also referred to as a guest). A system typically has one or more VMs (or guests) allocated and running applications via guest operating systems.

Creating the Configuration

To create an ALSR configuration, first consider the configuration of a typical ztC Edge system configuration and the VLAN requirements of an ALSR configuration. Then, observe a well-planned ALSR configuration, which includes a quorum server, and become familiar with the configuration's VLAN requirements. You must also become familiar with the entire process of deploying a typical ztC Edge system and then creating an ALSR configuration. The sections below provide this information.

A Typical ztC Edge System


In a typical ztC Edge system configuration, two PMs are directly connected by a pair of network cables for A-Links. One A-Link typically serves as the private network (priv0). The two PMs have additional network connections for business networks, which the ztC Edge Console and guest VMs hosted by the system use. The following figure illustrates a typical configuration.



The physical distance between the PMs in a typical configuration is limited by the length of a single A-Link network cable, which is approximately 33 ft (10m). This distance may be significantly shorter when the physical environment and ambient electrical noise is accounted for.

An ALSR Configuration With a Quorum Server

A well-planned ALSR configuration consists of the two nodes at two different locations, and a third computer that runs the quorum service at a third location. All of these computers are networked together with appropriate network switching equipment, so that no single point of failure exists within the ALSR configuration. The following figure illustrates such a configuration, which includes node0 at Site A, node1 at Site B, and the quorum server at Site C.



alsr002

Notes:



1. Each A-Link should be connected on its own VLAN configured between switch A and switch B.
2. DNS servers and gateways are not included in the illustrations, for clarity, but you must ensure that the ALSR configuration includes a connection to a DNS server and a gateway in the event of a network failure.
3. For maximum protection, you should install redundant switches at each at site though the illustration does not show these switches. For the illustrated configuration, site A and site B would *each* include two switches. The A-Links are routed through one switch and the business networks are routed through the other switch. If possible, use different circuits to power the switches or use a UPS to prevent brief power loss failures.

ALSR VLAN Requirements

The A-Link connections between switch A and switch B require a VLAN configuration on the switches. A-Link traffic is not routable, and the connection should emulate a single long network cable. Each A-Link must be isolated on its own VLAN.

If you cannot create VLANs between the switching equipment, you can use Ethernet-to-fiber media converters to create a longer fiber connection between the two PMs. However, you should not route the two A-Link fiber connections through the same physical conduit, as this creates a single point of failure.

Additionally, the quorum service computer should not share a switch with either node0 or node1 because a shared switch creates a single point of failure.

See [Meeting Network Requirements](#) for more information about the latency requirements of the A-Links and quorum connections.

From Initial Deployment to Completing the ALSR Configuration

When creating an ALSR configuration, you should first deploy and register a typical ztC Edge system, initially without the ALSR configuration. The figure in [A Typical ztC Edge System](#) illustrates this system. For simplicity, install the nodes side-by-side, using the provided cables. See [Getting Started](#).

After the typical system is operating normally, create the ALSR configuration.

1. Read [Creating an ALSR Configuration](#) and all of its subtopics, if you have not already done so.
2. Install the quorum computer and enable the quorum server. Comply with all information in:
 - [An ALSR Configuration With a Quorum Server](#)
 - [ALSR VLAN Requirements](#)
 - [Meeting Network Requirements](#)
 - [Completing the Configuration](#)
3. Verify that the quorum server has access to both nodes.
4. Properly shutdown one node. See [Shutting Down a Physical Machine](#).
5. Relocate the shutdown node to the far site.
6. Connect the infrastructure. The [ALSR-configuration illustration above](#) shows the connections, which include:
 - The priv0 connection to port **A2**
 - The second A-Link connection to port **A1**
 - The ibiz0 connection to port **P1**
7. Power on and (re-)join the nodes. See [Powering On a Physical Machine](#).
8. Verify the configuration. Ensure that:
 - The shared networks pair properly—In the ztC Edge Console, navigate to the **Networks** page and ensure that the state of each network is green-checked. If necessary, troubleshoot any infrastructure problems.

- Quorum connections are remade—In the console, navigate to the **Quorum Servers** page by clicking **Preferences** and then **Quorum Servers**. Ensure that the state of the quorum server is green-checked. If necessary, troubleshoot any infrastructure problems.
 - The primary node can shift from node0 to node1, and the console can connect in both configurations—Place each node in Maintenance Mode (see [Maintenance Mode](#)).
9. (Re-)join the VMs—Migrate the VMs from node to node (see [Migrating a Physical Machine or Virtual Machine to a System](#)). Verify the correct network failover of VM networking.
 10. Assess the status of network and validate Ethernet failover (see the [Networks Page](#)).

Meeting Network Requirements

This topic describes the network requirements and considerations of A-Links, business networks, the quorum server connections, and the management network for a successful ALSR configuration. (For general information about these networks, see [Network Architecture](#).)



Prerequisite: Plan and create an ALSR configuration by first reading [Creating an ALSR Configuration](#) and following its instructions, if you have not already done so.

A-Link network connections must meet the following requirements:

- The A-Links use IPv6 addressing.
- Each A-Link must be connected on its own VLAN. A-Link traffic is not routable.
 - FT VMs require less than 2ms RTT A-Link latency (only available on 110i systems).
 - HA VMs require less than 10ms RTT A-Link latency (available on all ztC Edge systems).
 - You need to provide enough bandwidth to meet the needs of all VMs on the system, and you need to provide a speed of at least 1Gb per A-Link.
 - When planning your network infrastructure, you need to account for the uplink bandwidth between the switch and the network backbone across all the ports in use on that switch.

If these requirements are not met, guest VMs may run more slowly due to limited synchronization bandwidth between the two nodes.

The first business network (ibiz0) is used for communication between the nodes and to the quorum server.

The ibiz0 network must meet the following requirements:

- The two nodes must be on the same subnet.
- The network must allow IPv6 multicast traffic between the two nodes.
- The two nodes can access the quorum server using IPv4 network addressing.

Network connections for the quorum server must meet the following requirements:

- Access to the quorum service must be provided using ibiz0, using IPv4 network addressing.
- Two UDP ports must be open and available for communication between the nodes and the quorum service, including in the firewalls. By default, these ports are 4557 and 4558. If you want to change these ports, see [Configuring the Quorum Service Port](#) (on the quorum computer) and [Configuring the Quorum Server Within the ztC Edge Console](#).
- Latency between a ztC Edge node and the quorum computer should be less than 500ms RTT.
- Throughput is not an important consideration. 10Mb Ethernet, or even T1 bandwidth is adequate.
- Quorum computers are common to all VMs on the same ztC Edge system.
- Quorum computers may be shared among many ztC Edge systems.
- Quorum computers must never be implemented as a VM on the same ztC Edge system that uses it.
- Use different network infrastructure, don't share. A ztC Edge node should not depend on a gateway or switch/router on the partner node site for sustained access to a quorum services computer.



Note: Do not implement the quorum service as a guest VM on a different pair of nodes; a failure on those nodes would cause the VM running the quorum service to failover, which would create unnecessary complications for network topology and fault management. Additionally, a second quorum computer is needed to manage quorum for the ztC Edge system that is running the quorum service.

Management network connections must meet the following requirements:

- By default, the management network is shared with a business network. In this case, all requirements for a business network apply.
- Configure gateways to a business LAN for remote management.

Locating and Creating the Quorum Server

In a well-planned ALSR configuration, a third computer hosts the quorum service. The quorum service processing requirement is small, so any other existing computer or VM that meets all network and

operating requirements can host the quorum service. An effective quorum server depends upon the location of the quorum computer within your network.

After you have determined an effective location for the quorum computer (and an alternate quorum computer, if desired) and ensured that the computer meets the requirements of the quorum service, you can create the quorum server.



Prerequisite: Plan and create an ALSR configuration by first reading [Creating an ALSR Configuration](#) and following its instructions, if you have not already done so.

Locating the Quorum Computer

Locate the first quorum computer in a third site within your network, as [An ALSR Configuration With a Quorum Server](#) illustrates. If a third site is not available, locate the quorum computer in a physical location that is different from the physical location of node0 and node1. Locating the quorum computer in a unique site maximizes the chance of the system surviving a problem that causes the loss of both nodes and the quorum computer (for example, a transient electrical, plumbing, or other problem that causes loss of network connectivity).

You should connect the quorum computer to an electrical circuit that is different from the electrical circuit that powers node0 or node1. In addition, you should connect the quorum computer to a UPS unit.

Caution: If both AX's lose connectivity with the quorum server, they will attempt to select an alternate quorum server. If no quorum server can be selected, the VM is downgraded to simplex mode, to prevent a split-brain condition if another failure occurs.



If one node shuts down and the VM (AX) on the remaining node cannot reach either the quorum server or its peer, it will shut itself down to avoid the risk of a split-brain condition.

When locating the quorum computer:

- Ensure that the quorum computer does not share a switch (or router) with either node0 and node1.
- Do **not** use a guest VM within the ztC Edge system to run the quorum service.

See [Understanding Quorum's Effect on System Behavior](#) for a description of system behavior and failure modes.

Adding an Alternate Quorum Computer

You can add another quorum computer (with its switch) to your system to create an alternate quorum service. The most common use of an alternate quorum server is when, for example, operating system updates are being applied to the preferred quorum computer. When the preferred quorum computer restarts, the alternate quorum computer is selected and no downgrade occurs. When the preferred quorum is recovered, the selection moves back to the original preferred quorum computer.

When creating a second quorum service, you must follow all of the requirements for the network and quorum placement. If both nodes can communicate with each other and with the same quorum server (either the preferred or alternate quorum server), the system can maintain VM redundancy, even if one quorum connection is lost. Preferred quorum server selection occurs when both nodes have access to each other and to the preferred quorum server. Thus, if the preferred quorum service is lost at the same time a node is lost, the remaining node shuts down the VM even if a second, non-preferred quorum service is available. However, if the preferred quorum service is lost *before* a node is lost, and if both nodes can continue to contact the alternate quorum server, the selection is moved to the alternate quorum server. Fault handling occurs in a context of the selected quorum server only.

If you create an alternate quorum service, you need to add a second quorum IP address when adding the quorum service in the ztC Edge Console.

Quorum Computer Requirements

You can install quorum service software on any general-purpose computer, laptop, or VM that is running the Windows operating system and that meets these requirements:

- The computer can continually remain powered on and connected to the network such that the ibiz0 network of the ztC Edge system can always access the quorum server.
- The computer has a static IPv4 network address. Do not use DHCP.
- The operating system is Windows Server 2019, Windows Server 2016, Windows Server 2012, or Windows 10; Embedded versions of the Windows OS are not supported.
- A minimum of 100 MB disk space is available.
- Two UDP ports must be open and available for communication between the nodes and the quorum service, including in the firewalls. By default, these ports are 4557 and 4558. To change these ports, see [Configuring the Quorum Service Port](#) (on the quorum computer) and [Configuring the Quorum Server Within the ztC Edge Console](#).

Downloading and Installing the Quorum Service Software

After you have determined an appropriate location for the quorum computer, download and install the required software to create the quorum server.

To download and install the quorum server software

1. Open the **Downloads** page at <https://www.stratus.com/services-support/downloads/?tab=ztcedge>.
2. Scroll down to the **Drivers and Tools** section and then click **Quorum Service** to download the quorum server software installer file to the quorum server.
3. On the quorum server, double click the installer file.
4. Move the downloaded file to an accessible location.
5. Log in to the quorum computer.
6. Navigate to the quorum service installer and double-click it.
7. Follow the prompts to complete the installation.

The product name *everRun* may appear when installing the quorum service.



Note: When upgrading to a more recent version of quorum server software, you do **not** need to uninstall the previous version.

Completing the Configuration

After you have created the ALSR configuration, change the quorum service port, if necessary. Then, enable quorum within the ztC Edge Console. Finally, verify the configuration and (re-)join VMs.



Prerequisite: Plan and create an ALSR configuration by first reading [Creating an ALSR Configuration](#) and following its instructions, if you have not already done so.



Note: The port configured for quorum service on the quorum computer and the port configured for the quorum server within the ztC Edge Console must be the same port numbers. If you change the quorum service ports on the quorum computer, you must change the quorum service ports on all ztC Edge systems (using the ztC Edge Console) that connect to that quorum computer so that both the quorum computer and the ztC Edge systems use the same port numbers. See [Configuring the Quorum Server Within the ztC Edge Console](#).

Configuring the Quorum Service Port

By default, the quorum service listens on UDP port 4557.

In most cases, you do not need to change the default port. However, you can change the port, if the network configuration requires you to:

To change the port number on the quorum server

1. Log on to the quorum computer using an account with administrative privileges.
2. Open a command window in administrative mode.
3. Stop the quorum service by typing:

```
net stop sraqserver
```

4. Change the port by typing (replacing *nnnn* with the new port number):

```
sraqserver -install nnnn
```

5. Restart the quorum service by typing:

```
net start sraqserver
```

Verifying the Quorum Service Port

If you need to verify the quorum service port, check this Windows registry key:

```
HKEY_LOCAL_MACHINE\SYSTEM\CurrentControlSet\Services\Sraqserver\Parameters\QSServerPortForReceive
```

Configuring the Quorum Server Within the ztC Edge Console

Once the quorum service is running, you should enable the quorum service within the ztC Edge Console.

You can also remove a quorum server.

To enable the quorum service:

1. Login to the ztC Edge Console with an account that has administrative privileges.
2. Click **Preferences** in the left-hand navigation panel, to open the **Preferences** page.
3. Click **Quorum Servers**. The quorum configuration page opens.
4. Click **Add Quorum Server** at the left side of the page.

5. In the **Add Preferred Quorum Server** dialog box, enter the following values (if a preferred quorum server already exists, the **Add Alternate Quorum Server** dialog box appears):
 - **DNS or IP Address**—Type the fully-qualified **DNS** host name or **IP address** for the preferred quorum server.
 - **Port** —The default port is 4557. Type a port number if you need a port that is different from the default. You need to type only one port number. The quorum service will open the port number for **Port** and the next port (for example, 4557 and 4558)



Note: The port number must match the port that the quorum service is listening on.
(If necessary, you can [change the port on the quorum server.](#))

Click **Save** to save the values.

6. Repeat steps 4 and 5 to configure a second, alternate quorum server. Stratus recommends configuring two quorum servers.
7. To enable quorum service, select the **Enabled** check box and click **Save**.

Changes to the quorum configuration do not effect running VMs. You must stop and restart any running VMs after changing the quorum configuration.

To remove a quorum server



Caution: If you remove the preferred quorum server, the alternate quorum server becomes the preferred quorum server. If no alternate quorum server exists, removing the preferred quorum server automatically disables quorum service.

1. Navigate to the **Preferences** page of the ztC Edge Console.
2. Click **Quorum Servers**.
3. Locate the entry for the quorum server you want to remove.
4. In the right-most column, click **Remove**.



Note: If a VM is using the quorum server that you are removing, you must reboot the VM so that it no longer recognizes the quorum server, which allows the removal process to finish. The VM will downgrade to simplex mode until it is restarted with no quorum servers configured.

Verify the Configuration and (Re-)Join VMs

Verify the configuration and (re-)join VMs. Follow the appropriate steps in [From Initial Deployment to Completing the ALSR Configuration](#).

Understanding Quorum's Effect on System Behavior

A quorum server in an ALSR system changes the system's availability and recovery behavior. To understand the quorum's effect on system behavior, you first need to understand the behavior of a system that does not have a quorum server.



Prerequisite: Plan and create an ALSR configuration by first reading [Creating an ALSR Configuration](#) and following its instructions, if you have not already done so.


A ztC Edge system is designed to provide high availability for one or more guest VMs, which allows the VMs to continue to run even during failures that would otherwise create application downtime. The ztC Edge system can continue to run guest VMs even with, for example, the loss of a single network connection, a hard disk, or even an entire computer.

However, if more catastrophic faults occur (for example, the loss of all possible network paths), the ztC Edge system attempts to determine the overall state of the total system. The system then takes the actions necessary to protect the integrity of the guest VMs.

The following examples illustrate the system's process during a catastrophic fault.


Example 1: A System Without a Quorum Server Experiences a Split-brain Condition

In this ALSR example, the ztC Edge system includes node0 and node1, but does not include a quorum server. Operation is normal; no faults are currently detected. The two nodes communicate their state and availability over the A-Link connections, as they do during normal (faultless) operation. The following illustration shows normal connections.



A Catastrophic Fault

A careless fork-truck operator crashes through the wall, severing all of the network connections (both business and A-Links), while leaving the power available and the system running. The following illustration shows the fault condition.



Fault Handling

The two nodes handle the fault, as follows:

- Node0—The AX on node0 detects the loss of both A-Links as well as all other network paths. Since the node0 AX can no longer detect the presence of its partner, the node0 AX becomes active and

runs the guest VM. The application inside the guest VM continues to run, perhaps in a limited capacity due to the loss of the network.

- **Node1**—The AX on node1 also detects the loss of both A-Links, but ibiz0 remains available. As its partner does not respond to messages on ibiz0, the node1 AX is now active. The application inside the guest VM continues to run, perhaps not noticing any problems with the system.

From the perspective of an application client or an external observer, the guest VMs are both active and generate network messages with the same return address. Both guest VMs generate data and see different amounts of communication faults. The states of the guest VMs becomes more divergent over time.

Recovery and Repair

After some time, network connectivity is restored: the wall is repaired and the network cables are replaced.

When each AX of the AX pair realizes that its partner is back online, the AX pair with the fault handler rules choose the AX that continues as active. The choice is unpredictable and does not include any consideration for which node's performance was more accurate during the split-brain condition.

The data that was generated from the (now) Standby node is overwritten by the resynchronization of the Active node, and thus the data on the (now) Standby node is lost forever.

After a split-brain condition, the system requires several minutes to resynchronize, depending on how much disk activity needs to be sent to the standby node. If several guest VMs are running with different Active nodes, synchronization traffic may occur in both directions.




Note: In some cases, the ztC Edge system may not be able to determine the best way to proceed after a catastrophic fault. In this case, a person needs to recover the system. The recommended recovery method is to use the ztC Edge Console to shut down and reboot one node while the other node continues to run. This method typically forces the running node to become Primary and the AX on that node becomes Active. After the running node becomes Primary, a person can power on the other node. Do not shut down either node if resynchronization is already in progress.

Example 2: An ALSR System With a Quorum Server Avoids a Split-brain Condition


In this ALSR example, the ztC Edge system includes node0 and node1 with connections identical to those of the system in Example 1. In addition, the system in Example 2 includes a quorum server. The following

illustration shows these connections.



A Catastrophic Fault

That careless fork-truck operator crashes through the wall again, severing all of the network connections while leaving the power available and the system running. The following illustration shows the fault condition.



Fault Handling

The two nodes handle the fault, as follows:

- Node0—The AX on node0 detects the loss of both A-Links as well as all other network paths. Since the node0 AX can no longer detect the presence of its partner, the node0 AX attempts to contact the

quorum server. In this case, the quorum server is also unavailable. Therefore, the node0 AX decides to shut down. The shutdown is not a graceful Windows shutdown, but is, instead, an abrupt stop, which causes the application inside the guest VM to stop.

- **Node1**—The AX on node1 also detects the loss of both A-Links, but ibiz0 remains available. The node1 AX tries to contact the quorum server, which responds, so the node1 AX remains active. The application inside the guest VM runs, perhaps not noticing any problems with the system.



Note: If the node1 AX was not previously active and the guest VM is an HA VM, the guest VM on node1 might need to boot from node1's hard drive. In this case, the application experiences a brief period of downtime while the guest VM boots. (FT VMs continue to run.)

From the perspective of an application client or an external observer, the guest VM on node1 remains active and generates data while the VM on node0 is shut down. No split-brain condition exists.

Recovery and Repair

After some time, network connectivity is restored: the wall is repaired and the network cables are replaced.

When the node1 AX realizes that its partner is back online, the node0 AX becomes Standby. Because node0 was not previously running, data synchronization begins from node1 to node0.


Since a split-brain condition did not occur, no data is lost.

The system requires a few minutes to resynchronize, depending on how much disk activity needs to be sent to the standby node.

Example 2, Modified: The Quorum Server Is Unreachable During the Catastrophic Fault

In an ALSR system with a quorum server, the quorum server may be offline or otherwise unreachable when the catastrophic fault severs all of the network connections, though the power remains available and the system is still running. The following illustration shows a system in this situation with a quorum server that is offline.

Example 2, Modified: The Quorum Server Is Unreachable With No Catastrophic Fault



The fault handling is similar to Example 2 fault handling, with one important difference for node1:

The node1 AX also detects the loss of both A-Links, but ibiz0 remains available. The node1 AX tries to contact the quorum server, but the communication fails. The AX terminates the guest VM.

In this case, the guest VM is shut down on both node0 and node1, preventing split-brain from occurring.

The tradeoff is that the guest VM is unavailable until the connection to either node0 or to the quorum server is restored.

In this case, determine the node that you do not wish to operate and power it down. Then, forcibly boot the node that you wish to operate, and then forcibly boot the VM. For information on shutting down a VM and then starting it, see [Managing the Operation of a Virtual Machine](#).)

Example 2, Modified: The Quorum Server Is Unreachable With No Catastrophic Fault

In some situations, the quorum server might be unreachable even without a catastrophic physical failure. One example is when the quorum computer is rebooted for routine maintenance such as applying an OS patch. In these situations, the AX detects that the quorum service is not responding and so the AX suspends synchronization traffic until the connection to the quorum server is restored. The guest VM continues to run on the node that was active when the connection was lost. However, the guest VM does not move to the standby node because additional faults may occur. After the quorum service is restored, the AX resumes synchronization and normal fault handling, as long as the connection to the quorum server is maintained.

Recovering From a Power Failure

If you restart the system after a power loss or a system shutdown, the ztC Edge system waits indefinitely for its partner to boot and respond before the system starts any guest VMs. If the AX that was previously active

can contact the quorum server, the AX starts the guest VM immediately without waiting for the partner node to boot. If the AX that was previously standby boots first, it waits for its partner node.

If the system receives a response from either the partner node or the quorum server, normal operation resumes and the VM will start, subject to the same fault handler rules that apply in other cases.

If the system does not receive a response from the quorum server, or if the system does not have a quorum server, then a person must forcibly boot a guest VM, which overrides any decisions made by the AX or the fault handler. You must ensure that two people do not forcibly boot the same guest VM on node0 and node1. Doing so inadvertently causes a split-brain condition.

Accessing Knowledge Base Articles

The **Stratus Customer Service Portal** provides a searchable **Knowledge Base** with technical articles about all Stratus products, including ztC Edge. In some cases, the online Help directly references these Knowledge Base articles (for example, KBnnnnnnn). You can access the **Stratus Customer Service Portal** and its Knowledge Base by using your existing portal credentials, or by creating a new user account, as follows.

To access the Knowledge Base

1. Log on to the **Stratus Customer Service Portal** at <https://service.stratus.com>.

If needed, create a new account as follows:

- a. Click **Register**.
- b. Enter your contact information including your company email address and registration code, and then click **Submit**.

Your company email address must include a domain name (for example, stratus.com) for a company that is a registered customer of Stratus. The portal sends an email to administrators of the company's account to approve the request.

- c. Upon approval, click the link in the email that you receive from Stratus.
- d. Enter a new password and finish configuring your account.

If you need assistance creating an account, contact your authorized Stratus service representative.

2. In the portal, do one of the following:
 - In the **Search** box, enter keywords or the KB article number (KBnnnnnnn) associated with the information you need, and then click the search button.
 - Click **Knowledge**, click the name of a product, and then browse available articles.

Related Topics

[Supporting Documents](#)

Fixed CVEs

This topic lists Common Vulnerabilities and Exposures (CVE) fixed in the release(s) listed.

CVEs Fixed in Stratus Redundant Linux Release 2.3.0.0

The following table lists the fixed CVEs (click drop-down icon, if present)

CVEs Fixed in Release 2.3.0.0		
CVE-2013-2139	CVE-2015-2716	CVE-2015-6360
CVE-2016-5766	CVE-2017-12652	CVE-2017-15715
CVE-2017-18190	CVE-2017-18551	CVE-2018-1283
CVE-2018-1303	CVE-2018-11782	CVE-2018-15746
CVE-2018-19662	CVE-2018-20836	CVE-2018-20843
CVE-2019-2974	CVE-2019-5094	CVE-2019-5188
CVE-2019-5482	CVE-2019-6237	CVE-2019-6251
CVE-2019-6978	CVE-2019-7572	CVE-2019-7573
CVE-2019-7574	CVE-2019-7575	CVE-2019-7576
CVE-2019-7577	CVE-2019-7578	CVE-2019-7635
CVE-2019-7636	CVE-2019-7637	CVE-2019-7638
CVE-2019-8506	CVE-2019-8524	CVE-2019-8535
CVE-2019-8536	CVE-2019-8544	CVE-2019-8551
CVE-2019-8558	CVE-2019-8559	CVE-2019-8563

CVEs Fixed in Release 2.3.0.0		
CVE-2019-8571	CVE-2019-8583	CVE-2019-8584
CVE-2019-8586	CVE-2019-8587	CVE-2019-8594
CVE-2019-8595	CVE-2019-8596	CVE-2019-8597
CVE-2019-8601	CVE-2019-8607	CVE-2019-8608
CVE-2019-8609	CVE-2019-8610	CVE-2019-8611
CVE-2019-8615	CVE-2019-8619	CVE-2019-8622
CVE-2019-8623	CVE-2019-8625	CVE-2019-8644
CVE-2019-8649	CVE-2019-8658	CVE-2019-8666
CVE-2019-8669	CVE-2019-8671	CVE-2019-8672
CVE-2019-8673	CVE-2019-8674	CVE-2019-8675
CVE-2019-8676	CVE-2019-8677	CVE-2019-8678
CVE-2019-8679	CVE-2019-8680	CVE-2019-8681
CVE-2019-8683	CVE-2019-8684	CVE-2019-8686
CVE-2019-8687	CVE-2019-8688	CVE-2019-8689
CVE-2019-8690	CVE-2019-8696	CVE-2019-8707
CVE-2019-8710	CVE-2019-8719	CVE-2019-8720
CVE-2019-8726	CVE-2019-8733	CVE-2019-8735
CVE-2019-8743	CVE-2019-8763	CVE-2019-8764
CVE-2019-8765	CVE-2019-8766	CVE-2019-8768

CVEs Fixed in Release 2.3.0.0		
CVE-2019-8769	CVE-2019-8771	CVE-2019-8782
CVE-2019-8783	CVE-2019-8808	CVE-2019-8811
CVE-2019-8812	CVE-2019-8813	CVE-2019-8814
CVE-2019-8815	CVE-2019-8816	CVE-2019-8819
CVE-2019-8820	CVE-2019-8821	CVE-2019-8822
CVE-2019-8823	CVE-2019-8835	CVE-2019-8844
CVE-2019-8846	CVE-2019-9454	CVE-2019-9458
CVE-2019-10098	CVE-2019-10208	CVE-2019-11068
CVE-2019-11070	CVE-2019-11719	CVE-2019-11727
CVE-2019-11756	CVE-2019-12450	CVE-2019-12614
CVE-2019-12749	CVE-2019-14494	CVE-2019-14744
CVE-2019-14822	CVE-2019-14834	CVE-2019-14866
CVE-2019-14907	CVE-2019-14973	CVE-2019-15217
CVE-2019-15691	CVE-2019-15692	CVE-2019-15693
CVE-2019-15694	CVE-2019-15695	CVE-2019-15807
CVE-2019-15903	CVE-2019-15917	CVE-2019-16231
CVE-2019-16233	CVE-2019-16707	CVE-2019-16935
CVE-2019-16994	CVE-2019-17006	CVE-2019-17023
CVE-2019-17053	CVE-2019-17055	CVE-2019-17498

CVEs Fixed in Release 2.3.0.0		
CVE-2019-17546	CVE-2019-17563	CVE-2019-18197
CVE-2019-18282	CVE-2019-18808	CVE-2019-19046
CVE-2019-19055	CVE-2019-19058	CVE-2019-19059
CVE-2019-19062	CVE-2019-19063	CVE-2019-19126
CVE-2019-19332	CVE-2019-19447	CVE-2019-19523
CVE-2019-19524	CVE-2019-19530	CVE-2019-19532
CVE-2019-19534	CVE-2019-19537	CVE-2019-19767
CVE-2019-19807	CVE-2019-19956	CVE-2019-20054
CVE-2019-20095	CVE-2019-20382	CVE-2019-20386
CVE-2019-20388	CVE-2019-20485	CVE-2019-20636
CVE-2019-20811	CVE-2019-20907	CVE-2019-25013
CVE-2020-0427	CVE-2020-1472	CVE-2020-1749
CVE-2020-1927	CVE-2020-1934	CVE-2020-1935
CVE-2020-1971	CVE-2020-1983	CVE-2020-2574
CVE-2020-2732	CVE-2020-2752	CVE-2020-2780
CVE-2020-2812	CVE-2020-3862	CVE-2020-3864
CVE-2020-3865	CVE-2020-3867	CVE-2020-3868
CVE-2020-3885	CVE-2020-3894	CVE-2020-3895
CVE-2020-3897	CVE-2020-3899	CVE-2020-3900

CVEs Fixed in Release 2.3.0.0		
CVE-2020-3901	CVE-2020-3902	CVE-2020-5313
CVE-2020-6829	CVE-2020-7053	CVE-2020-7595
CVE-2020-8177	CVE-2020-8622	CVE-2020-8623
CVE-2020-8624	CVE-2020-8625	CVE-2020-8647
CVE-2020-8649	CVE-2020-8695	CVE-2020-8696
CVE-2020-8698	CVE-2020-9383	CVE-2020-10018
CVE-2020-10029	CVE-2020-10543	CVE-2020-10690
CVE-2020-10703	CVE-2020-10713	CVE-2020-10732
CVE-2020-10742	CVE-2020-10751	CVE-2020-10754
CVE-2020-10769	CVE-2020-10878	CVE-2020-10942
CVE-2020-11078	CVE-2020-11565	CVE-2020-11761
CVE-2020-11763	CVE-2020-11764	CVE-2020-11793
CVE-2020-12243	CVE-2020-12321	CVE-2020-12351
CVE-2020-12352	CVE-2020-12400	CVE-2020-12401
CVE-2020-12402	CVE-2020-12403	CVE-2020-12723
CVE-2020-12770	CVE-2020-12825	CVE-2020-12826
CVE-2020-13765	CVE-2020-13935	CVE-2020-14305
CVE-2020-14308	CVE-2020-14309	CVE-2020-14310
CVE-2020-14311	CVE-2020-14314	CVE-2020-14318

CVEs Fixed in Release 2.3.0.0		
CVE-2020-14323	CVE-2020-14331	CVE-2020-14345
CVE-2020-14346	CVE-2020-14347	CVE-2020-14351
CVE-2020-14355	CVE-2020-14360	CVE-2020-14361
CVE-2020-14362	CVE-2020-14363	CVE-2020-14364
CVE-2020-14372	CVE-2020-14385	CVE-2020-14779
CVE-2020-14781	CVE-2020-14782	CVE-2020-14792
CVE-2020-14796	CVE-2020-14797	CVE-2020-14803
CVE-2020-15436	CVE-2020-15705	CVE-2020-15706
CVE-2020-15707	CVE-2020-15862	CVE-2020-15999
CVE-2020-16092	CVE-2020-17507	CVE-2020-24394
CVE-2020-25211	CVE-2020-25212	CVE-2020-25632
CVE-2020-25637	CVE-2020-25643	CVE-2020-25645
CVE-2020-25647	CVE-2020-25648	CVE-2020-25656
CVE-2020-25684	CVE-2020-25685	CVE-2020-25686
CVE-2020-25692	CVE-2020-25694	CVE-2020-25695
CVE-2020-25705	CVE-2020-25712	CVE-2020-27749
CVE-2020-27779	CVE-2020-28374	CVE-2020-29573
CVE-2020-29599	CVE-2020-29661	CVE-2020-35513
CVE-2021-2144	CVE-2021-2163	CVE-2021-3156

CVEs Fixed in Release 2.3.0.0		
CVE-2021-20225	CVE-2021-20233	CVE-2021-20265
CVE-2021-20305	CVE-2021-25215	CVE-2021-27219
CVE-2021-27363	CVE-2021-27364	CVE-2021-27365
CVE-2021-27803		

CVEs Fixed in Stratus Redundant Linux Release 2.2.0.0

The following table lists the fixed CVEs (click drop-down icon, if present)

CVEs Fixed in Release 2.2.0.0		
CVE-2015-2716	CVE-2015-8035	CVE-2015-9289
CVE-2016-5131	CVE-2017-6519	CVE-2017-11166
CVE-2017-12805	CVE-2017-12806	CVE-2017-15412
CVE-2017-15710	CVE-2017-17807	CVE-2017-18251
CVE-2017-18252	CVE-2017-18254	CVE-2017-18258
CVE-2017-18271	CVE-2017-18273	CVE-2017-18595
CVE-2017-1000476	CVE-2018-1116	CVE-2018-1301
CVE-2018-4180	CVE-2018-4181	CVE-2018-4300
CVE-2018-4700	CVE-2018-5712	CVE-2018-5745
CVE-2018-7191	CVE-2018-7418	CVE-2018-7584
CVE-2018-8804	CVE-2018-9133	CVE-2018-10177
CVE-2018-10360	CVE-2018-10547	CVE-2018-10804

CVEs Fixed in Release 2.2.0.0		
CVE-2018-10805	CVE-2018-11362	CVE-2018-11439
CVE-2018-11656	CVE-2018-12599	CVE-2018-12600
CVE-2018-13139	CVE-2018-13153	CVE-2018-14340
CVE-2018-14341	CVE-2018-14368	CVE-2018-14404
CVE-2018-14434	CVE-2018-14435	CVE-2018-14436
CVE-2018-14437	CVE-2018-14567	CVE-2018-15518
CVE-2018-15587	CVE-2018-15607	CVE-2018-16057
CVE-2018-16328	CVE-2018-16749	CVE-2018-16750
CVE-2018-17199	CVE-2018-18066	CVE-2018-18544
CVE-2018-18751	CVE-2018-19622	CVE-22018-19869
CVE-2018-19870	CVE-2018-19871	CVE-2018-19872
CVE-2018-19873	CVE-2018-19985	CVE-2018-20169
CVE-2018-20467	CVE-2018-20852	CVE-2018-21009
CVE-2019-2737	CVE-2019-2739	CVE-2019-2740
CVE-2019-2805	CVE-2019-3820	CVE-2019-3880
CVE-2019-3890	CVE-2019-3901	CVE-2019-5436
CVE-2019-6465	CVE-2019-6477	CVE-2019-7175
CVE-2019-7397	CVE-2019-7398	CVE-2019-9024
CVE-2019-9503	CVE-2019-9924	CVE-2019-9956

CVEs Fixed in Release 2.2.0.0		
CVE-2019-9959	CVE-2019-10131	CVE-2019-10197
CVE-2019-10207	CVE-2019-10218	CVE-2019-10638
CVE-2019-10639	CVE-2019-10650	CVE-2019-10871
CVE-2019-11190	CVE-2019-11459	CVE-2019-11470
CVE-2019-11472	CVE-2019-11487	CVE-2019-11597
CVE-2019-11598	CVE-2019-11884	CVE-2019-12293
CVE-2019-12382	CVE-2019-12779	CVE-2019-12974
CVE-2019-12975	CVE-2019-12976	CVE-2019-12978
CVE-2019-12979	CVE-2019-13133	CVE-2019-13134
CVE-2019-13135	CVE-2019-13232	CVE-2019-13233
CVE-2019-13295	CVE-2019-13297	CVE-2019-13300
CVE-2019-13301	CVE-2019-13304	CVE-2019-13305
CVE-2019-13306	CVE-2019-13307	CVE-2019-13309
CVE-2019-13310	CVE-2019-13311	CVE-2019-13454
CVE-2019-13648	CVE-2019-14283	CVE-2019-14815
CVE-2019-14980	CVE-2019-14981	CVE-2019-15090
CVE-2019-15139	CVE-2019-15140	CVE-2019-15141
CVE-2019-15221	CVE-2019-15605	CVE-2019-15916
CVE-2019-16056	CVE-2019-16708	CVE-2019-16709

CVEs Fixed in Release 2.2.0.0		
CVE-2019-16710	CVE-2019-16711	CVE-2019-16712
CVE-2019-16713	CVE-2019-16746	CVE-2019-16865
CVE-2019-17041	CVE-2019-17042	CVE-2019-17540
CVE-2019-17541	CVE-2019-17666	CVE-2019-18634
CVE-2019-18660	CVE-2019-19338	CVE-2019-19527
CVE-2019-19768	CVE-2019-19948	CVE-2019-19949
CVE-2020-0543	CVE-2020-0548	CVE-2020-0549
CVE-2020-1938	CVE-2020-2754	CVE-2020-2755
CVE-2020-2756	CVE-2020-2757	CVE-2020-2773
CVE-2020-2781	CVE-2020-2800	CVE-2020-2803
CVE-2020-2805	CVE-2020-2830	CVE-2020-2922
CVE-2020-5208	CVE-2020-5260	CVE-2020-5312
CVE-2020-7039	CVE-2020-8112	CVE-2020-8597
CVE-2020-8608	CVE-2020-8616	CVE-2020-8617
CVE-2020-9484	CVE-2020-10188	CVE-2020-10531
CVE-2020-10711	CVE-2020-10757	CVE-2020-10772
CVE-2020-11008	CVE-2020-12049	CVE-2020-12351
CVE-2020-12352	CVE-2020-12653	CVE-2020-12654
CVE-2020-12662	CVE-2020-12663	CVE-2020-12888

CVEs Fixed in Release 2.2.0.0		
CVE-2020-14364	CVE-2020-14556	CVE-2020-14577
CVE-2020-14578	CVE-2020-14579	CVE-2020-14583
CVE-2020-14593	CVE-2020-14621	

CVEs Fixed in Stratus Redundant Linux Release 2.1.0.0

The following table lists the fixed CVEs (click drop-down icon, if present)

CVEs Fixed in Release 2.1.0.0		
CVE-2016-3186	CVE-2016-3616	CVE-2016-10713
CVE-2016-10739	CVE-2017-5731	CVE-2017-5732
CVE-2017-5733	CVE-2017-5734	CVE-2017-5735
CVE-2017-14503	CVE-2017-17742	CVE-2018-0495
CVE-2018-0734	CVE-2018-1050	CVE-2018-1111
CVE-2018-1122	CVE-2018-1139	CVE-2018-1312
CVE-2018-3058	CVE-2018-3063	CVE-2018-3066
CVE-2018-3081	CVE-2018-3282	CVE-2018-3613
CVE-2018-5383	CVE-2018-5407	CVE-2018-5741
CVE-2018-6790	CVE-2018-6914	CVE-2018-6952
CVE-2018-7159	CVE-2018-7409	CVE-2018-7456
CVE-2018-7485	CVE-2018-7755	CVE-2018-8087
CVE-2018-8777	CVE-2018-8778	CVE-2018-8779

CVEs Fixed in Release 2.1.0.0		
CVE-2018-8780	CVE-2018-8905	CVE-2018-9363
CVE-2018-9516	CVE-2018-9517	CVE-2018-10689
CVE-2018-10779	CVE-2018-10853	CVE-2018-10858
CVE-2018-10904	CVE-2018-10907	CVE-2018-10911
CVE-2018-10913	CVE-2018-10914	CVE-2018-10923
CVE-2018-10926	CVE-2018-10927	CVE-2018-10928
CVE-2018-10929	CVE-2018-10930	CVE-2018-10963
CVE-2018-11212	CVE-2018-11213	CVE-2018-11214
CVE-2018-11645	CVE-2018-11813	CVE-2018-12015
CVE-2018-12121	CVE-2018-12181	CVE-2018-12327
CVE-2018-12404	CVE-2018-12641	CVE-2018-12697
CVE-2018-12900	CVE-2018-13053	CVE-2018-13093
CVE-2018-13094	CVE-2018-13095	CVE-2018-13346
CVE-2018-13347	CVE-2018-14348	CVE-2018-14498
CVE-2018-14598	CVE-2018-14599	CVE-2018-14600
CVE-2018-14625	CVE-2018-14647	CVE-2018-14651
CVE-2018-14652	CVE-2018-14653	CVE-2018-14654
CVE-2018-14659	CVE-2018-14660	CVE-2018-14661
CVE-2018-14734	CVE-2018-15473	CVE-2018-15594

CVEs Fixed in Release 2.1.0.0		
CVE-2018-15686	CVE-2018-15853	CVE-2018-15854
CVE-2018-15855	CVE-2018-15856	CVE-2018-15857
CVE-2018-15859	CVE-2018-15861	CVE-2018-15862
CVE-2018-15863	CVE-2018-15864	CVE-2018-16062
CVE-2018-16396	CVE-2018-16402	CVE-2018-16403
CVE-2018-16646	CVE-2018-16658	CVE-2018-16838
CVE-2018-16842	CVE-2018-16866	CVE-2018-16881
CVE-2018-16885	CVE-2018-16888	CVE-2018-17100
CVE-2018-17101	CVE-2018-17336	CVE-2018-18074
CVE-2018-18281	CVE-2018-18310	CVE-2018-18384
CVE-2018-18520	CVE-2018-18521	CVE-2018-18557
CVE-2018-18661	CVE-2018-18897	CVE-2018-19058
CVE-2018-19059	CVE-2018-19060	CVE-2018-19149
CVE-2018-19519	CVE-2018-19788	CVE-2018-20060
CVE-2018-20481	CVE-2018-20650	CVE-2018-20662
CVE-2018-20856	CVE-2018-20969	CVE-2018-1000073
CVE-2018-1000074	CVE-2018-1000075	CVE-2018-1000076
CVE-2018-1000077	CVE-2018-1000078	CVE-2018-1000079
CVE-2018-1000132	CVE-2018-1000876	CVE-2018-1000877

CVEs Fixed in Release 2.1.0.0		
CVE-2018-1000878	CVE-2019-0154	CVE-2019-0155
CVE-2019-0160	CVE-2019-0161	CVE-2019-0217
CVE-2019-0220	CVE-2019-1125	CVE-2019-1387
CVE-2019-1559	CVE-2019-2503	CVE-2019-2529
CVE-2019-2614	CVE-2019-2627	CVE-2019-2945
CVE-2019-2949	CVE-2019-2962	CVE-2019-2964
CVE-2019-2973	CVE-2019-2975	CVE-2019-2978
CVE-2019-2981	CVE-2019-2983	CVE-2019-2987
CVE-2019-2988	CVE-2019-2989	CVE-2019-2992
CVE-2019-2999	CVE-2019-3459	CVE-2019-3460
CVE-2019-3811	CVE-2019-3827	CVE-2019-3840
CVE-2019-3846	CVE-2019-3858	CVE-2019-3861
CVE-2019-3880	CVE-2019-3882	CVE-2019-3900
CVE-2019-5010	CVE-2019-5489	CVE-2019-6470
CVE-2019-7149	CVE-2019-7150	CVE-2019-7222
CVE-2019-7310	CVE-2019-7664	CVE-2019-7665
CVE-2019-9200	CVE-2019-9500	CVE-2019-9506
CVE-2019-9631	CVE-2019-9740	CVE-2019-9824
CVE-2019-9947	CVE-2019-9948	CVE-2019-10086

CVEs Fixed in Release 2.1.0.0		
CVE-2019-10126	CVE-2019-10216	CVE-2019-11043
CVE-2019-11135	CVE-2019-11236	CVE-2019-11599
CVE-2019-11729	CVE-2019-11745	CVE-2019-11810
CVE-2019-11833	CVE-2019-12155	CVE-2019-13616
CVE-2019-13638	CVE-2019-13734	CVE-2019-14287
CVE-2019-14378	CVE-2019-14744	CVE-2019-14811
CVE-2019-14812	CVE-2019-14813	CVE-2019-14816
CVE-2019-14817	CVE-2019-14821	CVE-2019-14835
CVE-2019-14869	CVE-2019-14895	CVE-2019-14898
CVE-2019-14901	CVE-2019-14906	CVE-2019-15239
CVE-2019-17133	CVE-2019-18397	CVE-2019-18408
CVE-2019-1000019	CVE-2019-1000020	CVE-2019-1010238
CVE-2020-2583	CVE-2020-2590	CVE-2020-2593
CVE-2020-2601	CVE-2020-2604	CVE-2020-2654
CVE-2020-2659		

CVEs Fixed in Stratus Redundant Linux Release 2.0.1.0

The following table lists the fixed CVEs (click drop-down icon, if present)

CVEs Fixed in Release 2.0.1.0		
CVE-2015-8830	CVE-2015-9262	CVE-2016-4913

CVEs Fixed in Release 2.0.1.0		
CVE-2016-9396	CVE-2017-0861	CVE-2017-3735
CVE-2017-10661	CVE-2017-16997	CVE-2017-17805
CVE-2017-18198	CVE-2017-18199	CVE-2017-18201
CVE-2017-18208	CVE-2017-18232	CVE-2017-18267
CVE-2017-18344	CVE-2017-18360	CVE-2017-1000050
CVE-2018-0494	CVE-2018-0495	CVE-2018-0732
CVE-2018-0737	CVE-2018-0739	CVE-2018-1050
CVE-2018-1060	CVE-2018-1061	CVE-2018-1092
CVE-2018-1094	CVE-2018-1113	CVE-2018-1118
CVE-2018-1120	CVE-2018-1130	CVE-2018-1139
CVE-2018-1304	CVE-2018-1305	CVE-2018-5344
CVE-2018-5391	CVE-2018-5407	CVE-2018-5729
CVE-2018-5730	CVE-2018-5742	CVE-2018-5743
CVE-2018-5803	CVE-2018-5848	CVE-2018-6485
CVE-2018-6764	CVE-2018-7208	CVE-2018-7568
CVE-2018-7569	CVE-2018-7642	CVE-2018-7643
CVE-2018-7740	CVE-2018-7757	CVE-2018-8014
CVE-2018-8034	CVE-2018-8781	CVE-2018-8945
CVE-2018-9568	CVE-2018-10322	CVE-2018-10372

CVEs Fixed in Release 2.0.1.0		
CVE-2018-10373	CVE-2018-10534	CVE-2018-10535
CVE-2018-10733	CVE-2018-10767	CVE-2018-10768
CVE-2018-10844	CVE-2018-10845	CVE-2018-10846
CVE-2018-10852	CVE-2018-10858	CVE-2018-10878
CVE-2018-10879	CVE-2018-10881	CVE-2018-10883
CVE-2018-10902	CVE-2018-10906	CVE-2018-10911
CVE-2018-10940	CVE-2018-11236	CVE-2018-11237
CVE-2018-11784	CVE-2018-12126	CVE-2018-12127
CVE-2018-12130	CVE-2018-12180	CVE-2018-12910
CVE-2018-13033	CVE-2018-13405	CVE-2018-13988
CVE-2018-14526	CVE-2018-14618	CVE-2018-14633
CVE-2018-14646	CVE-2018-14665	CVE-2018-15688
CVE-2018-15908	CVE-2018-15909	CVE-2018-15911
CVE-2018-16395	CVE-2018-16511	CVE-2018-16539
CVE-2018-16540	CVE-2018-16541	CVE-2018-16802
CVE-2018-16863	CVE-2018-16864	CVE-2018-16865
CVE-2018-16871	CVE-2018-16884	CVE-2018-17183
CVE-2018-17456	CVE-2018-17961	CVE-2018-17972
CVE-2018-18073	CVE-2018-18284	CVE-2018-18311

CVEs Fixed in Release 2.0.1.0		
CVE-2018-18397	CVE-2018-18445	CVE-2018-18559
CVE-2018-18690	CVE-2018-19134	CVE-2018-19409
CVE-2018-19475	CVE-2018-19476	CVE-2018-19477
CVE-2018-1000007	CVE-2018-1000026	CVE-2018-1000120
CVE-2018-1000121	CVE-2018-1000122	CVE-2018-1000301
CVE-2019-2422	CVE-2019-2602	CVE-2019-2684
CVE-2019-2698	CVE-2019-2745	CVE-2019-2762
CVE-2019-2769	CVE-2019-2786	CVE-2019-2816
CVE-2019-2842	CVE-2019-3813	CVE-2019-3815
CVE-2019-3835	CVE-2019-3838	CVE-2019-3839
CVE-2019-3855	CVE-2019-3856	CVE-2019-3857
CVE-2019-3862	CVE-2019-3863	CVE-2019-5953
CVE-2019-6116	CVE-2019-6133	CVE-2019-6454
CVE-2019-6778	CVE-2019-6974	CVE-2019-7221
CVE-2019-8322	CVE-2019-8323	CVE-2019-8324
CVE-2019-8325	CVE-2019-9636	CVE-2019-10132
CVE-2019-10160	CVE-2019-10161	CVE-2019-10166
CVE-2019-10167	CVE-2019-10168	CVE-2019-11085
CVE-2019-11091	CVE-2019-11477	CVE-2019-11478
CVE-2019-11479	CVE-2019-11811	CVE-2019-12735

CVEs Fixed in Stratus Redundant Linux Release 2.0.0.0

The following table lists the fixed CVEs (click drop-down icon, if present)

CVEs Fixed in Release 2.0.0.0		
CVE-2016-2183	CVE-2017-3636	CVE-2017-3641
CVE-2017-3651	CVE-2017-3653	CVE-2017-10268
CVE-2017-10378	CVE-2017-10379	CVE-2017-10384
CVE-2017-11600	CVE-2017-13215	CVE-2018-1336
CVE-2018-2562	CVE-2018-2622	CVE-2018-2640
CVE-2018-2665	CVE-2018-2668	CVE-2018-2755
CVE-2018-2761	CVE-2018-2767	CVE-2018-2771
CVE-2018-2781	CVE-2018-2813	CVE-2018-2817
CVE-2018-2819	CVE-2018-2952	CVE-2018-3133
CVE-2018-3136	CVE-2018-3139	CVE-2018-3149
CVE-2018-3169	CVE-2018-3180	CVE-2018-3183
CVE-2018-3214	CVE-2018-3620	CVE-2018-3639
CVE-2018-3646	CVE-2018-3665	CVE-2018-3693
CVE-2018-5390	CVE-2018-5740	CVE-2018-7550
CVE-2018-7566	CVE-2018-8088	CVE-2018-10194
CVE-2018-10675	CVE-2018-10873	CVE-2018-10897
CVE-2018-10915	CVE-2018-11235	CVE-2018-11806

CVEs Fixed in Release 2.0.0.0		
CVE-2018-12020	CVE-2018-12384	CVE-2018-14634
CVE-2018-15910	CVE-2018-16509	CVE-2018-16542
CVE-2018-1002200		

REST API

GET /system/overview

Description

Get system information, including physical machine properties, statistics, system performance, and current alert list. The response can be large (about 14KB).

Header

Header	Value	Required
Locale	de (German), en-US (English), ja (Japanese), zh-CN (Chinese), or pt-br (Portuguese). Default locale is en-US.	No
Content-type	application/json	Yes

Endpoint

GET /system/overview

Example

Request URL:

`https://{hostname or IP address}/restapi/system/overview`

11

Chapter 11: Security

To learn about additional configuration settings that you can implement to provide the highest level of security for a ztC Edge system, see [Security Hardening](#).

For additional information about security, see the following topics:

- [Fixed CVEs](#)
- [Managing IPtables](#)
- [Configuring Secure Connections](#)
- [Configuring Users and Groups](#)
- [Configuring Active Directory](#)
- [Audit Logs Page](#)

Security Hardening

Although Stratus ztC Edge systems provide a secure out-of-box experience, you can implement additional configuration settings as described below to provide the highest level of security.

Security is often a balance between protection and ease of use. ztC Edge systems are shipped with a set of default settings that balance these factors. For a more secure posture, follow the guidelines below, and continue to evaluate the security of the system throughout its life cycle, from the planning and configuration to operation and decommissioning.

The information below provides security hardening guidance based on Version 7.1 of *CIS Controls*, which are hardening recommendations developed by the Center for Internet Security (CIS), a community-driven nonprofit that leads and is recognized for best practices for securing IT systems and data. *CIS Benchmarks*

are also used to validate and create a baseline for a secure product. A list of CIS Controls is included below in [Best Practices and Standards of Standards Organizations](#).

The information below also provides hardening guidance based on industrial control systems cyber security standard ISA/IEC 62443, which was originally created by the International Society of Automation (ISA) and continues to be developed by the International Electrotechnical Commission (IEC). ISA/IEC 62443-4-2 has differing levels of security based on the sensitivity of data or intended threat actor adversary, and by implementing the recommendations and applying mitigating controls assists in achieving compliance for the required security level. A summary of ISA/IEC 62443-4-2 requirements is included below in [Best Practices and Standards of Standards Organizations](#).

This help topic contains the following sections:

- [Security Guidelines](#)
- [Advanced Security Guidelines](#)
- [Best Practices and Standards of Standards Organizations](#)

Security Guidelines

The following sections describe security guidelines for ztC Edge systems.

Note: Stratus has tested and supports the following guidelines. Any other update or modification not explicitly approved by Stratus could affect the normal operation of the system.



If you have any questions about these guidelines, and the system is covered by a service agreement, contact your authorized Stratus service representative for assistance. For information, see the **ztC Edge Support** page at <https://www.stratus.com/services-support/customer-support/?tab=ztcedge>

While implementing the security hardening guidelines, consider the following:

- The security guidelines refer to administrative tasks performed in the ztC Edge Console and in the host operating system. The ztC Edge Console is a browser-based interface that allows you to manage and monitor most aspects of the ztC Edge system from a remote management computer (see the [ztC Edge Console](#)). The host operating system runs on each node of the system. You can access the command line of the host operating system locally at the PM's physical console or remotely by using a secure shell (SSH) client (see [Accessing the Host Operating System](#)).

- Prior to making any configuration changes, record the current settings so that you can restore them, if necessary. Also, record any modifications that you are making in case the information is needed for troubleshooting.
- When changing the default system settings, particularly in the host operating system, you must make the changes on both nodes to prevent inconsistencies that could affect the normal operation of the system. Similarly, when changing the `root` password and other user account settings for the host operating system, you must do so on both nodes. The guidelines below indicate when these changes are needed.
- When you upgrade the system software or replace a node in the system, not all modifications for system hardening may be carried over. Similarly, some settings are shared across nodes, so shared resources could have conflicts. Therefore, after completing these procedures, you should verify that each node in the system has the correct settings and that the system is working properly.
- In some cases, the security guidelines directly reference Knowledge Base articles (for example, `KBnnnnnnn`) with more information about configuring ztC Edge systems and the Stratus Redundant Linux software. You can access the **Stratus Customer Service Portal** and its Knowledge Base by using your existing portal credentials, or by creating a new user account, as described in [Accessing Knowledge Base Articles](#).

Ports and Protocols

Any administrator making networking or communication changes to the system should be knowledgeable about the ports or protocols used by Stratus Redundant Linux. For details, see [KB0014311](#).

Network Segmentation

Connect the ztC Edge system only to networks with trusted devices, or to networks where devices require explicit permissions to communicate with each other. For more information on network segmentation, see the NIST special publications 800-125B and 800-39. For information about which Ethernet networks are available on ztC Edge systems, see [Network Architecture](#).

IP Tables/Firewall

Enable IP tables packet filtering for the system, and block all ports that are not used in normal operation. Malicious actors can leverage a potential security vulnerability on an unused interface as a backdoor. Limit the exposure by enabling IP tables for unused ports.

For details on how to implement IP tables, see [Managing IPtables](#).

Notes:



- The ICMP protocol is used for pinging within the ztC Edge system. If you set IP tables to drop ICMP traffic, the fault tolerance or failover support will not work properly.
- The SSH protocol is used for connecting to the host operating system. If you set IP tables to block SSH traffic, system administrators will be unable to access the host operating system.

User Account Creation

Create individual user accounts for each user authorized to access the system, and consider each user's role in the usage of the device. Maintaining individual user accounts also permits auditability or nonrepudiation, that by log review it can be determined which user accessed the device or made configuration changes.

For details on how to configure user settings, see [Configuring Users and Groups](#).

Notes:



- You cannot delete the default **admin** account, although you should change its name and password by editing the account settings.
- You must specify an email address for each user account, including **admin**, to enable the forgot password feature. Also, you must enable the mail server, as described in [Configuring the Mail Server](#); otherwise, the system cannot send password reset emails.
- If a user account is no longer needed or not actively being used, either remove or disable the user account to prevent any possibility of inappropriate use.
- Monitor login attempts to prevent brute-force attacks.

Password Creation

You must change the default passwords for the system.

The ztC Edge Console prompts you for a new **admin** password upon deployment. The password policy of the ztC Edge Console requires that your password meets the following conditions:

- Its minimum length is 8 characters.
- It must contain both upper- and lower-case characters.
- It cannot be the username.

The host operating system prompts you for a new `root` password upon the first login. When changing the `root` password for the host operating system, you must manually change it on both nodes. For details, see [Accessing the Host Operating System](#).



Note: When you change the `root` password for the host operating system, ensure that you remember the password, because the only way to recover a lost `root` password is to replace or reinstall the nodes.

For more information about controlling the quality of passwords in the host operating system, see [Advanced Security Guidelines](#).

Least Privilege

Limit each user's access to features applicable to their position or role.

Implementing least privilege prevents a non-privileged user from accessing services above their role.

For details on how to configure roles that define the privileges for each user, see [Configuring Users and Groups](#).

Active Directory

Active Directory integration presents a single point for centralized authentication and authorization. With Active Directory, you can create group policies for password complexity that are enforced based on your local security policy.

For details on how to add a ztC Edge system to an Active Directory domain, see [Configuring Active Directory](#).

Time Synchronization

Synchronization of time is important, as it provides a centralized reference point to ensure that operation and security processes work within the same time frame. Time referencing allows for confidence in the time of check and time of use when updating applications and ensuring that keys and certificates are still valid based on the time and date.

When you log on to a ztC Edge system for the first time, enable the Network Time Protocol (NTP) service to automatically set the system clock . Configure NTP to reference a known and trusted NTP server. For details, see [Configuring Date and Time](#).



Note: Use only the ztC Edge Console to properly configure the NTP settings; do not manually configure them in the host operating system.

Secure Connections

By default, the ztC Edge Console is configured to support only secure connections with the HTTPS protocol.

Enabling HTTPS on the ztC Edge system prevents common web security attacks to provide a level of confidentiality for each web session. HTTPS encrypts web session traffic, provides data integrity, and increases the overall security of the web traffic.

When HTTPS is enabled, it supports only TLSv1.2, which is currently the strongest encryption suite recommended. Ciphers include:

TLSv1.2:

ciphers:

TLS_DHE_RSA_WITH_AES_128_CBC_SHA (dh 4096) - A
TLS_DHE_RSA_WITH_AES_128_CBC_SHA256 (dh 4096) - A
TLS_DHE_RSA_WITH_AES_128_GCM_SHA256 (dh 4096) - A
TLS_DHE_RSA_WITH_AES_256_CBC_SHA (dh 4096) - A
TLS_DHE_RSA_WITH_AES_256_CBC_SHA256 (dh 4096) - A
TLS_DHE_RSA_WITH_AES_256_GCM_SHA384 (dh 4096) - A
TLS_DHE_RSA_WITH_CAMELLIA_128_CBC_SHA (dh 4096) - A
TLS_DHE_RSA_WITH_CAMELLIA_256_CBC_SHA (dh 4096) - A
TLS_ECDHE_RSA_WITH_AES_128_CBC_SHA (secp256r1) - A
TLS_ECDHE_RSA_WITH_AES_128_CBC_SHA256 (secp256r1) - A
TLS_ECDHE_RSA_WITH_AES_128_GCM_SHA256 (secp256r1) - A
TLS_ECDHE_RSA_WITH_AES_256_CBC_SHA (secp256r1) - A
TLS_ECDHE_RSA_WITH_AES_256_CBC_SHA384 (secp256r1) - A
TLS_ECDHE_RSA_WITH_AES_256_GCM_SHA384 (secp256r1) - A

Also enable secure, encrypted connections when using a mail server or other types of server software. For information about configuring and enabling an encrypted connection for the mail server on a ztC Edge system, see [Configuring the Mail Server](#).

Updating SSL Certificate

The ztC Edge system comes with a self-signed SSL certificate, but this may be updated to any purchased or supplied certificate. Changing the SSL certificate allows the root of trust to be updated to the customer specification. For details, see [KB0014653](#).

SNMP Configurations

Simple Network Management Protocol (SNMP) is a standard protocol for receiving alarms, sending traps, and monitoring system status. SNMP draws upon system-defining information that is stored in hierarchically configured management information bases (MIBs).

For security reasons, SNMP is disabled by default on ztC Edge systems. In Stratus Redundant Linux Release 2.3 or higher, the SNMP process is also stopped in the console operating system on each node. For additional security, you can also disable all SNMP connections by adding rules to IPtables (see [Managing IPtables](#)) to block UDP ports 162, 161 and 199 and TCP ports 162 and 199.



Note: For security reasons, if you need to enable SNMP, you should disable SNMP v1 and v2, and enable only version 3 by using the **SNMP Restricted** configuration. For details, see [Configuring SNMP Settings](#).

Backups

Backups are important to have in case a security event occurs; a unit can be returned to a known good state for continuous operation. Any backups taken should be stored in a secure location.

To back up a VM and its guest operating system, see [Exporting a Virtual Machine](#). To restore the identical VM with the same SMBIOS UUID, system serial number, and MAC addresses as the original VM, see [Replacing/Restoring a Virtual Machine from an OVF File](#).



Note: Exporting VMs is particularly important for VMs on a single-node system. In the event of a failure or loss of the original VM, you can use the OVF and VHD files to restore the VM.

To back up the ztC Edge system preferences that you configured on the **Preferences** page, you can save the settings to a local storage device or to the cloud. For details, see [Saving and Restoring System Preferences](#).

On redundant, dual-node ztC Edge systems, each node also serves as a backup for the other node. If a node fails, you can replace a node in a system that is currently licensed, and the system automatically restores the node with an exact copy of the Stratus Redundant Linux software and the virtual machines from the running node.

Automated Local Site Recovery

An automated local site recovery (ALSR) configuration connects two physical machines at two separate sites. It is a disaster-tolerant deployment that maintains hardware redundancy as well as redundancy of physical computer rooms and the buildings containing them. Because of the geographic separation, an ALSR configuration requires careful planning of component placement and more complex networking topologies. For ALSR configurations, Stratus strongly recommends that you use the quorum service because an ALSR configuration exposes the A-Link networks to other potential failure scenarios. (ALSR configurations are not available to systems configured for one node.)

For details, see [Creating an ALSR Configuration](#).

Auditing

Implement auditing by a local policy to regularly collect and manage logs of events needed to detect, understand, and recover from a cyber attack.

The **Audit Logs** page displays a log of user activity in the ztC Edge Console. To open this page, click **Audit Logs** in the left-hand navigation panel. (To display information about events on the ztC Edge system, see the [Alerts History Page](#).)

Log information contains:

- Time—The date and time of the action.
- Username—The name of the user that initiated the action.
- Originating Host—The IP address of the host on which the ztC Edge Console was running.
- Action—The action performed in the ztC Edge Console.

You can also display information about audit logs by using `snmptable` (for details, see [Obtaining System Information with snmptable](#)).

Use logs for continuous monitoring of the ztC Edge system. To ensure prompt service in the event of a service call, also enable support notifications and periodic reporting for your system to keep Stratus informed about your system's health. For details, see [Configuring Remote Support Settings](#).

Login Banner Notice

Configure the Login Banner Notice to include important notifications to ztC Edge Console users. For details, see [Configuring the Login Banner](#).

Upgrades

Upgrade Stratus Redundant Linux on a regular basis to prevent security vulnerabilities from being exploited due to out-of-date components. Refer to your local security policies for information about frequency and methods.



Caution: Do not update the CentOS host operating system of the ztC Edge system from any source other than Stratus. Use only the release that is installed with the Stratus Redundant Linux software.

The **Upgrade Kits** page in the ztC Edge Console allows you to upload and manage upgrade kits that you use to upgrade the system to newer versions of the Stratus Redundant Linux software. You can also copy an upgrade kit to a USB medium in order to use the medium when reinstalling the system software.

To open the **Upgrade Kits** page, click **Upgrade Kits** in the left-hand navigation panel in the ztC Edge Console.

For information about upgrading the Stratus Redundant Linux software, see [Upgrading Stratus Redundant Linux Software Using an Upgrade Kit](#). For information about creating a USB medium, see [Creating a USB Medium with System Software](#).

Physical Security

Install each ztC Edge system in a secure location to prevent malicious users from accessing the nodes.

Secure each location with an auditable system to identify which personnel entered the area to identify malicious users.

Physical security is an important addition to tamper detection and alerting for any device, including ztC Edge nodes.

Advanced Security Guidelines

The following sections describe advanced security guidelines for ztC Edge systems.

Password Quality Recommendations

When setting passwords, recommendations include:

- Setting a minimum password length of at least 8 characters, of which three out of four of the following characteristics are required: one upper-case letter, one lower-case letter, one number, and one special character.
- Requiring users to reset passwords on a regular basis, such as every 30, 60 or 90 days. You can also forbid the reuse of passwords for a variable amount of password updating history.

To manually update password quality settings in the host operating system



Note: Apply the password quality settings on both nodes in the system.

1. Log on to the host operating system, as described in [Accessing the Host Operating System](#).
2. Open the `/etc/pam.d/system-auth` file with a text editor.
3. Modify the `pam_pwquality.so` module with the appropriate settings. For example, use settings similar to the following:

```
password requisite pam_pwquality.so try_first_pass local_
users_only retry=3 authtok_type= minlen=8 lcredit=-1
ucredit=-1 dcredit=-1 ocredit=-1 enforce_for_root
```

The previous example sets the following values:

`minlen=8` sets the minimum password length to 8 characters.

`lcredit=-1` sets the minimum number of lower-case letters in a password to one.

`ucredit=-1` sets the minimum number of upper-case letters in a password to one.

`dcredit=-1` sets the minimum number of digits in a password to one.

`ocredit=-1` sets the minimum number of other symbols such as `@`, `#`, `!`, `$`, `%` in a password to one.

`enforce_for_root` ensures that even if the `root` user is setting the password, the complexity policies should be enforced.

4. To restrict the password history, add or modify the `pam_pwhistory.so` module with the appropriate settings. For example, using settings similar to the following:

```
password requisite pam_pwhistory.so debug use_authok
remember=10 retry=3
```

5. Save the `/etc/pam.d/system-auth` file.

For more information about password policies in the host operating system, see the CentOS documentation:

https://wiki.centos.org/HowTos/OS_Protection#Password_Policies

Concurrent User Management

Continually monitor the audit logs to view which users have logged on to the machine and if they are still active.

Identify the users that are currently operating the system to legitimize and audit their usage.

Antivirus

Continually perform a network-based analysis for antivirus or malware detection.

Your network-based intrusion detection system supplements the ztC Edge capability to support verification of the intended operation of security functions. The detection system should search for anomalous network traffic and require investigation to validate any malicious intent.

SSH Access Restrictions

Several `/etc/ssh/sshd_config` parameters limit which users and groups can access the system by SSH. If none of the following parameters are present in the file, edit the file to set one or more of them to limit access:

`AllowUsers`

The `AllowUsers` parameter gives the system administrator the option of allowing specific users to use SSH to access the system. The list consists of space separated usernames. This parameter does not recognize numeric user IDs. To restrict user access further by permitting only the allowed users to log in from a host, the entry can be specified in the form of `user@host`.

AllowGroups

The `AllowGroups` parameter gives the system administrator the option of allowing specific groups of users to use SSH to access the system. The list consists of space separated group names. This parameter does not recognize numeric group IDs.

DenyUsers

The `DenyUsers` parameter gives the system administrator the option of denying specific users from using SSH to access the system. The list consists of space separated usernames. This parameter does not recognize numeric user IDs. If a system administrator wants to restrict user access further by specifically denying a user's access from a host, the entry can be specified in the form of `user@host`.

DenyGroups

The `DenyGroups` parameter gives the system administrator the option of denying specific groups of users from using SSH to access the system. The list consists of space separated group names. This parameter does not recognize numeric user IDs.

Restricting which users can remotely access the system using SSH will help ensure that only authorized users access the system.

MaxAuthTries

The `MaxAuthTries` parameter specifies the maximum number of authentication attempts permitted per connection. When the login failure count reaches half the number, error messages will be written to the `syslog` file detailing the login failure.

Setting the `MaxAuthTries` parameter to a low number will minimize the risk of successful brute force attacks to the SSH server. While the recommended setting is 4, set the number based on site policy. For example:

```
MaxAuthTries 4
```

IgnoreRhosts

The `IgnoreRhosts` parameter specifies that `.rhosts` and `.shosts` files will not be used in `RhostsRSAAuthentication` or `HostbasedAuthentication`.

Setting this parameter forces users to enter a password when authenticating with SSH. For example:

```
IgnoreRhosts yes
```

HostbasedAuthentication

The `HostbasedAuthentication` parameter specifies if authentication is allowed through trusted hosts by using `.rhosts` or `/etc/hosts.equiv` with successful public key client host authentication. This option applies only to SSH Protocol Version 2.

Even though the `.rhosts` files are ineffective if support is disabled in `/etc/pam.conf`, disabling the ability to use `.rhosts` files in SSH provides an additional layer of protection. For example:

```
HostbasedAuthentication no
```

For more information about `sshd_config` parameters, see the `sshd_config(5)` manual page.

Best Practices and Standards of Standards Organizations

The information in this topic is based on the following best practices and standards.

CIS Controls version 7.1

CIS controls is a prioritized set of best practices created to stop the most pervasive and dangerous threats of today. It was developed by leading security experts from around the world and is refined and validated every year. Further details may be found on the CIS website: <https://www.cisecurity.org>.

The CIS controls are:

Basic

1. Inventory and Control of Hardware Assets
2. Inventory and Control of Software Assets
3. Continuous Vulnerability Management
4. Controlled Use of Administrative Privileges
5. Secure Configuration for Hardware and Software on Mobile Devices, Laptops, Workstations and Servers
6. Maintenance, Monitoring and Analysis of Audit Logs

Foundational

7. Email and Web Browser Protections
8. Malware Defenses
9. Limitation and Control of Network Ports, Protocols and Services
10. Data Recovery Capabilities

11. Secure Configuration for Network Devices, such as Firewalls, Routers and Switches
12. Boundary Defense
13. Data Protection
14. Controlled Access Based on the Need to Know
15. Wireless Access Control
16. Account Monitoring and Control

Organizational

17. Implement a Security Awareness and Training Program
18. Application Software Security
19. Incident Response and Management
20. Penetration Tests and Red Team Exercises

ISA/IEC 62443-4-2

ISA/IEC 62443-4-2 details technical component requirements (CRs) associated with seven foundational requirements (FRs) for meeting control system capability security levels. Further details may be found on the IEC website: <https://www.iec.ch/>

The foundational requirements are:

1. Identification and authentication control (IAC)
2. Use control (UC)
3. System integrity (SI)
4. Data confidentiality (DC)
5. Restricted data flow (RDF)
6. Timely response to events (TRE)
7. Resource availability (RA)

1. Identification and authentication control (IAC)

Identification of users is used in conjunction with authorization mechanisms to implement access control for a component. Verifying the identity of users requesting access is necessary to protect against unauthorized users from gaining access to the component. Authorization is from access control lists for different users that log in and authenticate with passwords into the ztC Edge system.

2. Use control (UC)

Once the user is identified and authenticated, the component must restrict the allowed actions to authorized use of the component. The ztC Edge system has defined roles that implement the concept of least privilege. Creating multiple users with varying levels of access control also defines the authorized use of the component.

3. System integrity (SI)

The integrity of the device should not be compromised, both the software and the physical components in operational and non-operational states. ztC Edge 110i, 200i, and 250i systems implement secure boot, which verifies that the unit is being booted or started from a trusted state, and all ztC Edge systems validate the digital signatures of software components prior to an upgrade. Ensuring system integrity is important to protect against the unauthorized manipulation or modification of data or system.

4. Data confidentiality (DC)

The purpose is to ensure the confidentiality of information on communication channels and in data stored in repositories to protect against unauthorized disclosure. The ztC Edge system has HTTPS with TLS v1.2 for web communication, as well as SSH and SMTP with encryption, ensuring that information is protected from malicious persons.

5. Restricted data flow (RDF)

Restricted data flow is the segmentation of the control system through zones and conduits to limit the unnecessary flow of data. The ztC Edge network architecture supports the routing and switching as determined by the configuration of networking for the management of information flow as determined by the installed system engineer. Leveraging the networking capabilities of the ztC Edge system allows for network segmentation to limit data flow.

6. Timely response to events (TRE)

Although a system may begin operation in a secure state, vulnerabilities and security events can occur. The ztC Edge system has a Product Security Incident Response (PSIR) team to react to security incidents and report findings while solving issues in a timely manner. The ztC Edge system has alert logs that can be used to notify the appropriate channels for configuration changes that may indicate a security incident. The logs contain enough information for forensics, and these e-alert notifications are emailed.

7. Resource availability (RA)

The aim of this control is to ensure that the component is resilient against various types of denial of service events. The high availability of the ztC Edge system is the foundation of an “always on” state. It is

imperative that industrial control systems maintain a high availability state as there potentially are life safety impacts to systems. With a built-in virtualization and availability layer, automated data protection, and application recovery, Stratus Redundant Linux significantly reduces the dependence on IT for virtualized computing at the edge. Its self-protecting and self-monitoring features help reduce unplanned downtime and ensure the continuous availability of business-critical industrial applications.

12

Chapter 12: SNMP

Simple Network Management Protocol (SNMP) is a standard protocol for receiving alarms, sending traps, and monitoring system status. SNMP draws upon system-defining information that is stored in hierarchically configured management information bases (MIBs).

To configure an ztC Edge system to use SNMP, see [Configuring SNMP Settings](#).

For information on using the `snmptable` command to obtain information about the system, specifically information about alerts, audit logs, nodes, VMs, and volumes, see [Obtaining System Information with snmptable](#).

You can download a copy of the MIB file from the **Drivers and Tools** section of the **Downloads** page at <https://www.stratus.com/services-support/downloads/?tab=ztcedge>.

Obtaining System Information with snmptable



















You can issue the `snmptable` command to obtain information about the system, specifically information about alerts, audit logs, nodes, VMs, and volumes.



















To display alert information

To display information about alerts, issue the following command:

```
snmptable -v2c -m+/usr/smd/STRATUS-ZTC-EDGE-MIB.txt -c public  
localhost ztCEdgeAlertTable
```

The command output displays the following:

Field	Description												
ztCEdgeAlertIndex	The alert number.												
ztCEdgeAlertSeverity	<p>The alert severity (see <code>ztCEdgeAlertSeverityNum</code> for numerical value). Values are:</p> <table> <tr> <td>clear</td><td></td></tr> <tr> <td>informational</td><td></td></tr> <tr> <td>minor</td><td></td></tr> <tr> <td>major</td><td></td></tr> <tr> <td>serious</td><td></td></tr> <tr> <td>critical</td><td></td></tr> </table>	clear		informational		minor		major		serious		critical	
clear													
informational													
minor													
major													
serious													
critical													
ztCEdgeAlertType	<p>The type of alert. Examples are:</p> <ul style="list-style-type: none"> • <code>node_singleSystemDisk</code> • Node Maintenance • The Unit is not well balanced 												
ztCEdgeAlertSource	<p>The source of the alert. Examples are:</p> <ul style="list-style-type: none"> • <code>node0</code> or <code>node1</code> • ztC Edge system network name • network host name 												
ztCEdgeAlertDateTime	<p>The date and time of the alert, in the format <code>yyyy-mm-dd hh:mm:ss</code>, where <i>yyyy</i> is year, <i>mm</i> is month, <i>dd</i> is date, <i>hh</i> is hour, <i>mm</i> is minute, and <i>ss</i> is second (for example, 2017-11-03 23:49:45).</p>												
ztCEdgeAlertCallHomeSent	If <code>true</code> , Call Home was sent; if <code>false</code> , it was not sent												

Field	Description																		
ztCEdgeAlertEAlertSent	If true, e-Alert was sent; if false, it was not sent																		
ztCEdgeAlertSNMPTrapSent	If true, SNMP trap was sent; if false, it was not sent																		
ztCEdgeAlertInformation	<p>Information about the alert. Examples are:</p> <ul style="list-style-type: none">• Node node1 is in maintenance• node0 has a single system disk: Policy assumes this disk is redundant - if not, please add another internal disk• BUSINESS network net_728 is reporting a degraded link condition• The unit is not well load balanced																		
ztCEdgeAlertSNMPTrapOID	SNMP trap object identifier (OID) (for example, COMPANY-MIB::nodeSingleSystemDisk)																		
ztCEdgeAlertSeverityNum	<p>ztCEdgeAlertSeverity number. Values are:</p> <table><tr><td>0</td><td>Clear</td><td></td></tr><tr><td>1</td><td>Informational</td><td></td></tr><tr><td>2</td><td>Minor</td><td></td></tr><tr><td>3</td><td>Major</td><td></td></tr><tr><td>4</td><td>Serious</td><td></td></tr><tr><td>5</td><td>Critical</td><td></td></tr></table>	0	Clear		1	Informational		2	Minor		3	Major		4	Serious		5	Critical	
0	Clear																		
1	Informational																		
2	Minor																		
3	Major																		
4	Serious																		
5	Critical																		

To display audit log information

To display information about audit logs, issue the following command:

```
snmptable -v2c -m+/usr/smd/STRATUS-ZTC-EDGE-MIB.txt -c public  
localhost ztCEdgeAuditTable
```

The command output displays the following:

Field	Description
ztCEdgeAuditIndex	An incrementing number (1, 2, etc.) to indicate the audit log whose information is displayed..
ztCEdgeAuditDateTime	The date and time that the audit was generated, in the format <i>yyyy-mm-dd hh:mm:ss</i> , where <i>yyyy</i> is year, <i>mm</i> is month, <i>dd</i> is date, <i>hh</i> is hour, <i>mm</i> is minute, and <i>ss</i> is second (for example, 2017-11-03 23:49:45).
ztCEdgeAuditUsername	The name of the user that caused the audit to be generated (for example, <i>audit</i> or <i>admin</i>).
ztCEdgeAuditOriginatingHost	The IP address of the host that originated the audit.
ztCEdgeAuditAction	A description of the action being audited. Examples are: <ul style="list-style-type: none">• "Login user \"audit"• "Start virtual machine \"manager1"• "Remove all cleared alert"

To display node information

To display node information, issue the following command:

```
snmptable -v2c -m+/usr/smd/STRATUS-ZTC-EDGE-MIB.txt -c public  
localhost ztCEdgeNodeTable
```

The command output displays the following:

Field	Description
ztCEdgeNodeIndex	A number (typically 1 or 2) to indicate the node whose information is displayed.
ztCEdgeNodeId	The host ID of the node (for example, host : o34).
ztCEdgeNodeDisplayName	The node name, node0 or node1.
ztCEdgeNodeIsPrimary	If true, the node is primary. If false, the node is secondary.
ztCEdgeNodeStateNum	<p>Node state is:</p> <ul style="list-style-type: none"> 0 Normal (✓) 1 Warning (⚠) 2 Busy (🔄) 3 Broken (✗) 4 Maintenance (🔧)
ztCEdgeNodeActivityNum	<p>Node activity is:</p> <ul style="list-style-type: none"> 0 Imaging 1 Booting 2 Running 3 Stopping 4 Rebooting 5 Powered off 6 Failed 7 Firmware updating 8 Lost 9 Exiled 10 Unreachable

Field	Description
	11 Proto (initializing)
	12 Evacuating

To display VM information

To display VM information, issue the following command:

```
snmptable -v2c -m+/usr/smd/STRATUS-ZTC-EDGE-MIB.txt -c public
localhost ztCEdgeVMTable
```

The command output displays the following:

Field	Description
ztCEdgeVMIndex	An incrementing number (1, 2, etc.) to indicate the VM whose information is displayed.
ztCEdgeVMId	The VM ID (for example, vm:01467).
ztCEdgeVMDisplayName	The VM name (for example, MyVM).
ztCEdgeVMRunningNode	The node on which the VM is running, node0 or node1.
ztCEdgeVMAvailability	The VM availability, HA (High Availability) or FT (Fault Tolerant).
ztCEdgeVMStateNum	VM state is: 0 Normal (✓) 1 Warning (⚠) 2 Busy or synchronizing (🔄) 3 Broken or blacklisted (✗)
ztCEdgeVMActivityNum	VM activity is: 0 Installing 1 Booting

Field	Description
	2 Running
	3 Moving
	4 Stopping
	5 Stopped
	6 Exporting
	8 Paused
	9 Loading
	10 Crashing
	11 Crashed
	12 Dumping
	13 Waiting

To display volume information

To display volume information, issue the following command:

```
snmptable -v2c -m+/usr/smd/STRATUS-ZTC-EDGE-MIB.txt -c public
localhost ztCEdgeVolumeTable
```

The command output displays the following:

Field	Description
ztCEdgeVolumeIndex	An incrementing number (1, 2, etc.) to indicate the volume whose information is displayed.
ztCEdgeVolumeId	The volume ID (for example, volume:o588).
ztCEdgeVolumeDisplayName	The volume name (for example, root).
ztCEdgeVolumeSyncPercentage	The percentage of the volume that is synchronized.
ztCEdgeVolumeUsedBy	The name of the VM or host that is using the volume (for example, MyVM); none indicates that the

Field	Description								
	volume is not being used.								
ztCEdgeVolumeStateNum	<p>Volume state is:</p> <table><tr><td>0</td><td>Normal (✓)</td></tr><tr><td>1</td><td>Warning (⚠)</td></tr><tr><td>2</td><td>Busy or synchronizing (🔄)</td></tr><tr><td>3</td><td>Broken (✗)</td></tr></table>	0	Normal (✓)	1	Warning (⚠)	2	Busy or synchronizing (🔄)	3	Broken (✗)
0	Normal (✓)								
1	Warning (⚠)								
2	Busy or synchronizing (🔄)								
3	Broken (✗)								